




Alpha X200

True Wireless Earbuds

USER MANUAL



Please read this manual carefully before use and keep it well for future reference.

IMPORTANT)

* For Pairing Method, please refer to page 8.

If there is any question, please contact us at

support@ivankyo.com

CAUTIONS)

1. Do not try to disassemble the product by yourself, please contact VANKYO for more help.
2. This product is not designed to work underwater. Do not swim or shower with the earbuds.
3. Do not use the product in high temperature, and near heat or fire.
4. Please use the USB cable provided to charge the product.
5. Please keep the earbuds out of the reach of children to avoid choking hazard for the small parts contained in the product.
6. Long exposure to loud volume may cause hearing damage. It's advised you adjust the volume to a proper level for use.
7. Do not use the product while driving.
8. Please pay attention to the surroundings when you use the product in case of potential risks.




PACKING LIST »



Charging Case




True Wireless Earbud



USB Cable



Micro USB to USB Adapter



Spare Ear Tip Set
(Sx2, Mx2, Lx2)



User Manual


! Note:

If any part of your product is damaged or missing, please contact VANKYO customer service.



OVERVIEW)

Charging Case



- ① Opening Slot
- ② Micro USB Charging Port
- ③ Charging Slot for the Left Earbud
- ④ Left Earbud
- ⑤ LED Display
- ⑥ Right Earbud
- ⑦ Charging Slot for the Right Earbud



LED Display

Battery Percentage
of the Charging Case




Battery Level Indicator
of the Left Earbud

Battery Level Indicator
of the Right Earbud

* The **LED Display** will be off if there is no operation on the product. Just open or close the case to turn it on again.

Earbud

Ear Tip



Charging Pins

Touchpad



Microphone/LED Indicator



CHARGE »

Please charge the **Charging Case** and earbuds at your first use with the **USB Cable** provided.

Charge the Charging Case

1. Connect the **USB Cable** into the **Micro USB Charging Port** on the **Charging Case**.
2. Connect the other end into a USB wall charger or a compatible adapter with 5V/1A DC in. It takes around 4 hours to reach a full charge.



Charging:

The second number of the percentage keeps flashing.



Fully Charged:

The percentage reaches 100%.




Charge the Earbuds

The earbuds will be charged while they are in the Charging Case.

Step 1:

Align the **Charging Pins** on the earbud with the **Charging Pins** on the **Charging Slot** in the case.



Step 2:

Place the earbud into the case until it magnetically snaps into the **Charging Slot**.

Step 3:

Close the **Charging Case**.

Charging:

The **Battery Level Indicator** will keep flashing.



Fully Charged:


The **Battery Level Indicator** reaches 4 levels.
(1 level indicates 25% power.)



POWER ON))

Option 1:

The earbuds will be powered on automatically once you open the cover of the **Charging Case**. The solid blue **LED Indicator** for 1s indicates a successful powering on.



Option 2:

When the earbud is in power-off status, please tap and hold the **Touchpad** for 2s to power on. You will hear a voice prompt of "**Power On**" from the earbud.






! Note:

To hear the voice prompts, please make sure you are wearing the earbuds.

TWO EARBUDS PAIRING ☺


After the earbuds are powered on, the **LED Indicator** of either earbud will flash pink and blue quickly for around 10s to pair with each other automatically.

Solid pink and blue **LED Indicator** for 1s on both earbuds stands for a successful pairing.



CONNECT AND DISCONNECT WITH A MOBILE DEVICE ›

After earbuds pairing finishes, the LED Indicator of either earbud will flash red and blue alternatively and slowly, which indicates the earbuds are ready for connecting to a mobile device.



Connect

Turn on the Bluetooth on your device, search and connect to **Alpha X200**.



The **LED Indicator** on the earbud will be off and there is one beep from your earbuds if the connection is successful.

! Notes:

- 1** The earbuds will be automatically powered off if they are not connected with any device within 3 mins.
- 2** If the bluetooth is disabled on your device or you turned off the earbuds, it will take around 10s to automatically reconnect the earbuds with the device after you enable the bluetooth or turn on the earbuds again.


Disconnect

Go to the Bluetooth interface of your mobile device, select **Alpha X200** and **Disconnect/Upair** to disconnect the earbuds. You will hear a voice prompt of "**Disconnected**".

FIT THE EARBUD INTO YOUR EAR))



1. Insert the earbud gently so the ear tip can rest in the opening of the ear canal.
2. Gently and slowly adjust the earbud until it securely and firmly fits in your ear.






FUNCTIONS OF EARBUDS ›



Volume Function

 Volume +	Tap and hold the Touchpad of the Right Earbud until you get the desired volume
 Volume -	Tap and hold the Touchpad of the Left Earbud until you get the desired volume







Media Playing Function when listening to music

 Play/Pause	Tap the Touchpad of either earbud once
---	---



 Next	Tap the Touchpad of the Right Earbud twice
 Previous	Tap the Touchpad of the Left Earbud twice

Call Function

 Accept	Tap the Touchpad of either earbud twice
 End	Tap the Touchpad of either earbud twice
 Decline	Tap and hold the Touchpad of either earbud for 2s
 End & Accept	Tap the Touchpad of either earbud once
 Hold & Accept	Tap and hold the Touchpad of either earbud for 1s
 Swap	Tap and hold the Touchpad of either earbud for 1s



Activate Voice Control

Tap the **Touchpad** of either earbud for three times to wake up **Siri** or **Google Assistant**, then you can speak to your device.

Note:

Please use the earbuds near the device connected.

POWER OFF ☺

Option 1:

Place the earbuds into the **Charging Case** to power off.



Option 2:

Tap the **Touchpad** once, then tap and hold it for 2 seconds to power off.




Option 3:

The earbuds will be powered off if there is no connection with a Bluetooth device after powering on.

REPLACE THE EAR TIP 》

We have pre-assembled the ear tip on the earbuds. If the size doesn't fit you, please take off the original ear tip on the earbud, then replace it with the new one we provided in the package.



CHARGING CASE USED AS A POWER BANK)


You can use the **Charging Case** to charge your mobile devices.

Step 1:

Connect the **Micro USB to USB Adapter** into the **Micro USB Charging Port** on the **Charging Case**.

Step 2:

Connect one end of the USB cable to the adapter and the other end to the charging port on your mobile device.



SPECIFICATIONS)

Power Supply	DC 5V/1A
BT Version	BT5.0
Battery Capacity of the Charging Case	3500 mAh
Charging Time for the Earbud	1H
Charging Time for the Charging Case	4H
Call Time	5H
Playtime	Around 7H (with 60% volume)
Standby Time for the Charging Case	200H



IC STATEMENT

This device complies with RSS247 of Industry Canada. Cet appareil se conforme à RSS247 de Canada d'Industrie. This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device. appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes:

- ① le dispositif ne doit pas produire de brouillage préjudiciable, et
- ② ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:



CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

 The symbol indicates DC voltage

 RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



WARNING:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.





VANKYO

CUSTOMER SUPPORT

North America support@ivankyo.com

United Kingdom support.uk@ivankyo.com