




WALKER

Illustrated Parts Manual

C19i



Beginning S/N: 154995
P/N 6000-30

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
AT	All-Terrain
CCW	Counter-clockwise
Conn.	Connector
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal.	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz.	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt.	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
Spg.	Spring
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
Term.	Terminal
V	Volts
VLR	Very Low Restriction

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST

<i>Section of Tractor Covered</i>	<i>Page</i>
Decals	
Tractor Decals	2
Body / Chassis Assemblies	
Body / Chassis Assembly	4
Rear Body Assembly	6
Tractor Components	
Main Component Power Transmission	8
Engine Group	10
Engine Group (Fuel Components)	12
Hydrostatic Ground Drive Assemblies	14
Steering Control Assemblies	16
Throttle Control Assembly	18
Parking Brake Assembly	20
GHS Group	22
GHS Powerfil® Assembly (7.0)	24
GHS 7.0 Bushel Catcher Assembly	26


<i>Section of Tractor Covered</i>	<i>Page</i>
Electrical Components	
Electrical Assembly	28
Electrical Assemblies (GHS 7.0 Bushel Components)	30
Maintenance	
Lubrication Points	32
Wiring Schematic	34
Maintenance And Service Record Sheet	35
Warranty	
Limited Warranty	37

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQUIRED
Walker Product and Operation Decals				
1	8600-33	RH Fender	Body, RH Near Seat	1
2	5813-2	Decal, 4" Grass-Pak Powerfil®	Powerfil® Cover Plate	1
3	5800-11	Walker (8" Round)	7.0 Bushel Catcher (one on each side)	2
4	8600-37	LH Fender	Body, LH Near Seat	1
5	8821-18	Decal, C19i	Body	1
6	5856-1	Made in USA	Body	1
Danger Decals Warning Decals Caution Decals				
7	8600-10	Danger, Pinch Point	7.0 Bushel Catcher Mounting Frame Assembly (one on each side)	2
8	8600-4	Danger, Rotating Blower Blades	Body, Near Body Chute	1
9	8600-12	Danger, Engine Exhaust	Front Body, LH Side	1
10	5810-3	Decal, Hydro Warning	LH Gear Axle Drive Assembly	1
Maintenance Decals				
11	5855	Important, Engine Cooling	Engine	1
12	5869	Removable Screen	7.0 Bushel Catcher Removable Screen	1
13	8600-16	Front Body Closure	Rear Cross Member, Body	1
14	5810-1	Axle Oil Level	Gear Axle Drive Assemblies (one on each)	2
15	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1
16	6807-1	Oil Pressure	Body	1
17	5802-5	Engine Service Light	Body	1
18	5810-23	Reservoir	Hydrostatic Drives (one on each)	2
19	8600-30	Parking Brake	Body, RH Side Below Seat	1
20	7827	Oil Level	Jackshaft Support	1

NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR DECALS



BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly				36	5038-1	Axle Spacer Tube (6-5/8)	1
1	5103-3	Seat W/Switch	1	37	6307-2	Chassis Frame	1
2	7440-5	Shock Mount (1-1/4 x 3/4)	4	38	5075-3	LP Wheel & Tire (18 x 8.50-10)	2
Rear Bumper Assembly					5075-2	LP Tire (18 x 8.50-10)	*
3	7516-5	Catcher Pivot Bushing	2		5075-5	LP Wheel (10 x 7)	*
4	5517-8	7.0 Rear Bumper	1		5033-6	Wheel & Tire (18 x 7.00-8)	**
5	7517-3	Catcher Pivot Plate	2		5030-6	Standard Tire (18 x 7.00-8)	*
6	5162	Roller Wheel (5" Rubber)	2		5031-2	Standard Wheel (8 x 5-5)	*
Body Assembly					5030-4	Tire Tube (18 x 8.50-8)	*
7	7383-6	Body Latch Bracket, RH	1	Fasteners			
8	7383-5	Body Latch Lever	1	F002	10-24 Keps Nut		2
9	7383-7	Body Latch Bracket, LH	1	F004	1/4-20 Keps Nut		8
10	7222	Extension Spring (1/4 x 3)	1	F009	5/16-18 Whiz Locknut		10
11	5845	Rubber Bumper (1.50 OD x 1.25)	4	F012	3/8-16 Keps Nut		6
12	6101-9	Front Body Engine Guard	1	F014	3/8-16 ESNA Nut		4
13	NS	Body ID Plate	1	F016	1/2-13 Self-Locking Nut		1
14	5989-12	Dome Plug (3/16)	1	F020	5/16-18 ESNA Nut		1
15	5989-10	Dome Plug (9/16)	1	F025	10-24 x 3/8 PPHMS		2
16	8118	Heat Deflector	1	F029	1/4-20 x 1/2 Hex Bolt		6
17	5989-3	Dome Plug (5/16)	4	F031	1/4-20 x 5/8 Hex Bolt		2
18	5989-4	Dome Plug (3/8)	3	F038	3/8-16 x 1 Hex Bolt		8
19	6100-48	Front Body	1	F040	3/8-16 x 1-1/2 Hex Bolt		2
20	5146	10mm Ball Stud	2	F041	3/8-16 x 1-3/4 Hex Bolt		2
21	2145	Gas Spring Assembly (Includes Item # 20)	1	F042	3/8-16 x 2-1/4 Hex Bolt		2
22	5180	Edge Molding, Lever Opening	2	F050	1/4 SAE Washer		2
Tilt-Up Latch Assembly***				F051	3/8 SAE Washer		2
23	5847	Plastic Tip	1	F059	3/8 Wave Spring Washer		2
24	5744-20	Spring Arm, Tilt-Up Latch	1	F093	5/16-18 x 1 Hex Bolt		1
25	5744-10	Spring Pivot Bushing	1	F157	1/2-20 x 1-1/4 Wheel Lug Bolt		8
26	5744-15	Compression Spring (3/8 x 5/8)	1	F206	#2 x 3/16 Drive Pin		2
27	5744-13	Mount Angle, LH	1	F241	.375 x .875 x .10 Washer		4
28	5744-12	Hook, Tilt-Up Latch	1	F292	1/2-13 x 8-1/2 Hex Bolt, GR 5		1
29	5744-14	Mount Angle, RH	1	F341	Coil Roll Pin (7/64 x 9/16)		1
Chassis Assembly				F342	5/16 Conical Washer		2
30	5267-1	Retainer Collar (1") (Includes Item # F413)	1	F413	5/16-24 x 5/16 Set Screw		2
31	5270-1	Ball Bearing	2	F570	3/8-16 Flange Top Lock Nut		4
32	5420-2	Tail Wheel Fork	1	F630	Washer .835 x .505 x .080		2
33	8769-12	Bearing Cup (1/2 ID)	2	* Service Part Only			
34	5037-1	Bearing, Tail Wheel	2	** May be ordered as a factory-installed option or for dealer installation. Narrow Drive Tires are used when installing a 36" Deck. Contact your Walker dealer.			
35	5035	Tail Wheel & Tire Assembly (13 x 6.50-6)	1	*** Complete Tilt-Up Latch Kit available by ordering kit P/N 5747.			
	5035-1	Tail Wheel Tire (13 x 6.50-6)	*				
	5036	Tail Wheel & Hub (6 x 4.5)	*				

5

REAR BODY ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Rear Body Assembly

1	5976-2	Grommet (3/16 x 3/4)	1
2	5105-1	Rear Body Cover	1
3	8515-14	Catcher Handle Plate, RH	1
4	8389-5	Splash Guard	1
5	7146	13mm Ball Stud	2
6	7147	Spring Clip	2
7	7145	Gas Spring Assembly (Includes Items # 5 & 6)	1
8	7190-1	Insulation Foam Pad, LH	1
9	7190-2	Insulation Foam Pad, RH	1
10	5105	Rear Body, Catcher Support Frame	1
11	8515-13	Catcher Handle Plate, LH	1


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	4
F009	5/16-18 Whiz Locknut	2
F023	10-24 ESNA Nut	4
F026	10-24 x 1/2 PPHMS	4
F031	1/4-20 x 5/8 Hex Bolt	2
F032	1/4-20 x 3/4 Hex Bolt	1
F390	1/4-20 x 7/8 Carriage Bolt	2
F569	1/4-20 Flange Top Lock Nut	5
F615	1.0 x .255 x .125 Washer	1
F617	10-24 x 3/8 Truss Head Torx	4

NOTE: Rear Bumper Assembly for GHS Models is not shown here.
Refer to **BODY / CHASSIS ASSEMBLY**, Page 4.


REAR BODY ASSEMBLY



MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Clutch Lever Assembly				43	5221-1	Extension Spring (3/4 x 5)	2
1	8358-3	Clutch Lever (Includes Items # 2 & 3)	1	44	7833	Cable Clamp (7/8 x 1/4)	2
2	5830	Grease Fitting	7	45	8539	Starter Relay Mount	1
3	4850	Handle Grip, Black	1	46	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1
4	7303-10	Clutch Actuator Bolt (3/8)	1	47	5268	Bearing W/Collar (3/4)	2
5	7380-5	Knuckle Joint (3/8 ID)	1	48	8349	Transmission Belt Tightener Arm	1
6	7226-10	Compression Spring (3/4 x 2-1/2)	1	49	8393-7	Hydro Jackshaft Mount	1
7	8130-5	Pushrod, Clutch Actuator (Threaded Tube) (Includes Item # 2)	1		8394-1	Hydro Jackshaft Mount Assembly (Includes Items # 2, 9, 42, 47, 49 & 50)	*
8	8130-10	Clutch Actuator Rod Assembly (Includes Items # 2, 4-7, F054, F336 & F353)	1	50	8273	Jackshaft (3/4 x 7-1/2)	1
9	7201-3	Fiberglide Bearing	6	51	7240-4	Jackshaft Drive Pulley (3.3/3V) (Includes Items # F067 & F171)	1
10	7201-5	Inner Race (2-1/4)	1	Fasteners			
11	8368	PTO Belt Tightener	1		F002	10-24 Keps Nut	1
12	5841	Retainer Washer (3/8 x 1-1/4)	4		F003	1/4-28 Hex Nut	2
13	8243-1	Clutch Idler Pulley	1		F004	1/4-20 Keps Nut	3
	8243	Clutch Idler Pulley Assembly (Includes Items # 13-15 & F070)	*		F005	1/4-20 ESNA Nut	1
14	5265	Bearing (3/4)	1		F009	5/16-18 Whiz Locknut	3
15	8243-3	Hub, Idler Pulley	1		F012	3/8-16 Keps Nut	8
16	8375	PTO Belt Tightener Stop	1		F025	10-24 x 3/8 PPHMS	1
17	7377	Plastic Washer (1 x .438 x .025)	2		F029	1/4-20 x 1/2 Hex Bolt	1
18	7378	Pivot Bearing (7/16 x 9/16)	1		F034	5/16-18 x 3/4 Hex Bolt	2
19	5281-5	Clevis Pin (1/4 x 0.80)	2		F040	3/8-16 x 1-1/2 Hex Bolt	1
20	5280	Clevis (1/4)	2		F041	3/8-16 x 1-3/4 Hex Bolt	2
21	8305	Brake Actuator Rod	1		F042	3/8-16 x 2-1/4 Hex Bolt	3
22	8370	Bearing, Brake Actuator	1		F043	3/8-16 x 3 Hex Bolt	1
23	8250	Brake Spring (1/2 x 2-1/2)	1		F047	3/8-16 x 4-1/2 Hex Bolt	1
24	8369	Brake Actuator (Includes Items # 2 & 22)	1		F054	AN960616 Washer	3
PTO Drive Shaft Assembly					F061	1/4 Internal Star Lock Washer	1
25	7050-1	Dipstick, Gearbox	1		F067	3/16 x 3/16 x 1 Key	2
26	8371-1	Mount Bracket, Brake Band	1		F069	3/32 x 1/2 Cotter Pin	3
27	8377	Brake Band Guide	1		F070	1-3/4 Internal Snap Ring	1
28	8050-11	PTO Gearbox / Flange Pulley	1		F090	1/4-20 x 2-1/2 Hex Bolt	1
29	5245	Idler Pulley (3")	2		F116	1/4-20 x 1-1/4 Hex Bolt	1
30	7248	Ground Drive Belt, Micro-V	1		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
31	7275-9	Quick Coupler Installation Tool	**		F131	5/16-18 x 1/2 Hex Bolt	2
32	7275-16	Universal Joint Tube Assembly (Spline)	1		F132	1/4-20 x 2-3/4 Hex Bolt	1
33	8304	Brake Band (14-1/2)	1		F168	5/16 Split Lock Washer	14
34	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1		F171	5/16-18 x 3/8 Set Screw	4
35	6250-1	Drive Belt (3VX370)	1		F178	1/4 x 1 Fender Washer	1
36	7236-1	PTO Drive Pulley (4-1/2/3V) (Includes Items # F168 & F226)	1		F182	1/4 x 5/8 x 1/8 Washer	2
37	8237-2	Engine Pulley, Bolt On (4/3.8/3V) (Includes Items # F168 & F226)	1		F226	5/16-18 x 7/8 Hex Bolt	14
38	8230	Engine PTO Belt	1		F241	.375 x .875 x .10 Washer	1
Jackshaft Assembly					F261	AN960616L Washer	1
39	7245-1	Idler Pulley (3/8 Groove)	1		F336	3/8-16 Jam Nut	1
40	6325-2	Spacer Bushing (5/16)	2		F353	3/8-16 ESNA LP Nut	1
41	8349-4	Idler Arm	1	* Service Part Only			
42	7201-4	Inner Race (1-1/2)	2	** The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO gearbox.			

MAIN COMPONENT POWER TRANSMISSION



ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Precleaner Assembly

1	4090	Air Cleaner Assembly (90 Deg.) (Includes Items # 4, 8-12, F009 & F091)	*
2	6029	Hose Clamp (1-3/4 to 2-1/4)	1
3	6087-5	Air Intake Hose	1
4	NS	Air Cleaner Band	1
5	5090-5	Safety Filter Insert, VLR	1
6	5090-6	Air Cleaner Cartridge, VLR	1
7	5091-6	Air Flow Indicator W/Bracket	1
8	7334-3	Air Cleaner Bracket	1
9	7840-5	Hose Clamp (1-1/2 to 2)	1
10	M258	Vacuum Hose (17")	1**
11	5091-0	1/8 Pipe Thread Male W/Barb	1
12	5091-16	Street Elbow 90' (1/8 x 1/8)	1

Engine Assembly

13	5845	Rubber Bumper (1.50 x 1.25)	1
14	8010-2	Engine Bumper Mount	1
15	NS	Oil Filter (Kohler 2805001)	1
16	NS	19 HP Engine, EFI (Kohler)	1

Remote Oil Cooler Assembly

17	NS	Clamp	4***
18	NS	Oil Cooler Hose	2***
19	NS	Oil Cooler	1***
20	8016-8	Oil Cooler / Regulator Mount	1

Exhaust Assembly

21	NS	Gasket (Kohler 2404102)	2
22	NS	Nut (Kohler M-0841080)	4
23	6013-14	Muffler	1
24	6013-18	Muffler Heat Shield	1
25	6013-19	Muffler Brace	1
26	8021-2	Engine Brace, Chassis	1
27	8021-1	Engine Brace	1
28	NS	Sensor, Oxygen (Kohler)	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Fasteners

F004	1/4-20 Keps Nut	2
F009	5/16-18 Whiz Locknut	7
F029	1/4-20 x 1/2 Hex Bolt	2
F031	1/4-20 x 5/8 Hex Bolt	4
F034	5/16-18 x 3/4 Hex Bolt	2
F038	3/8-16 x 1 Hex Bolt	1
F049	5/16 SAE Washer	2
F050	1/4 SAE Washer	4
F051	3/8 SAE Washer	2
F063	3/8 Internal Star Lock Washer	2
F091	5/16-18 x 5/8 Hex Bolt	4
F151	3/8-16 x 7/8 Hex Bolt	2
F175	1/2 Split Lock Washer	4
F184	1/4-20 x 1/2 Hex Bolt, SS	3
F185	1/4 Int. Star Lock Washer, SS	3
F273	M6 x 1.0 Nut	4
F285	1/2-13 x 1-1/2 Hex Bolt	4
F482	8-32 Nylock Nut	2
F483	8-32 x 3/4 PPHMS	2
F547	M6 x 1.0 x 45 Stud	2
F570	3/8-16 Flange Top Lock Nut	1
F646	3/8-16 x 3/4 Serrated Hex Bolt	2


* Service Part Only

** **Required hose specifications:**
M258 - 7/64" ID automotive vacuum hose

*** Use the engine model and spec number from Kohler to order this item.

NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.

ENGINE GROUP



ENGINE GROUP (FUEL COMPONENTS)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Fasteners			
1	8018-4	Fuel Module Cover	1	F002	10-24 Keps Nut		4
2	8018-7	Fuel Module Bracket	1	F004	1/4-20 Keps Nut		2
3	8018-2	Fuel Bracket Spacer	1	F009	5/16-18 Whiz Locknut		2
4	M113	Fuel Line (3/16 x 12")	1**	F025	10-24 x 3/8 PPHMS		2
5	5879-4	Hose Clamp (7/16)	1	F029	1/4-20 x 1/2 Hex Bolt		2
6	8046-16	Quick Connector 5/16 x 5/16 - 45°	1	F034	5/16-18 x 3/4 Hex Bolt		2
7	8046-14	Quick Connector, Male (5/16)	1	F050	1/4 SAE Washer		2
8	5879-3	Hose Clamp (1/2)	6	F061	1/4 Internal Star Lock Washer		2
9	5879-5	Stepless Ear Clamp (5/8)	2	F079	A/A66D Aluminum Pop Rivet		1
10	M247	Fuel Line (5/16 x 6")	1**	F128	10-24 x 3/8 PTHMS		1
11	5975-3	Cable Tie (50# x 7")	2	F129	10-24 x 1/2 PTHMS		1
12	M246	Fuel Line (1/4 x 23")	1**	F398	1/4-20 x 2 Hex Bolt		2
13	M246	Fuel Line (1/4 x 6")	1**				
14	5020-3	Fuel Filter	1	* Service Part Only			
15	7833	Cable Clamp (7/8 x 1/4)	1				
16	6055-2	Fuel Tank, 4.0 Gallon, Gas (Includes Items # 17, 18, 21, 23, 25 & 26)	1	** Required hose specifications:			
17	5086-7	Hose (1/4 x 6)	1	M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)			
18	5020-2	Fuel Filter, In Tank	1	M246 - 1/4" ID low permeation (<15g/m ² /day) fuel hose (Parker 38904 or equivalent)			
19	8023	Fuel Tank Support	1	M247 - 5/16" ID low permeation (<15g/m ² /day) fuel hose (Parker 38905 or equivalent)			
20	5082-4	2-1/4 Ratchet Fuel Cap	*				
21	8043-8	Roll Over Valve	1				
22	M113	Fuel Line (3/16 x 26")	1**				
23	5977-7	Roll Over Grommet (.900 x 1-1/2)	1				
24	5083-1	Bushing, Rubber	*				
25	8055-2	Fuel Tank Gauge	1				
26	5083-8	Tank Tube (13")	1				
27	M246	Fuel Line (1/4 x 20")	1**				
28	8016-6	ECU Mount	1				

NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.



HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transmission Lockout Assembly				Transmission Repair Parts			
1	5028-3	Transmission Lockout Assembly (Includes Items # 2-5, F023, F027 & F081)	*	27	5025-13	Hydro Input Shaft (Includes Items # 28-30)	*
2	5847	Plastic Tip	2	28	5025-8	Bearing, Input Shaft	*
3	5057	Lockout Cam (Includes Item # F081)	2	29	5025-7	Snap Ring	*
4	5028-5	Lockout Lever	2	30	NS	Seal, Input Shaft	*
5	5027-5	Lockout Mount	1**	31	5022	Reservoir to Casting Gasket	*
Ground Drive Assemblies				32	5024	Reservoir Cap and Gasket	*
6	6209-5	Bridge Assembly	1	33	5023	Transmission Reservoir Kit	*
7	6209-10	Idler Pulley Mount	1	34	5023-1	Rubber Bladder	*
8	6243-2	Hydro Fan, CCW	1	35	5025-6	O-Ring & Plug Assembly	*
9	5026	Hydrostatic Drive, CW	1	36	5025-3	Seal, Control Shaft	*
10	6206-1	Air Vent Valve	*	Fasteners			
11	6200-9	Gear Axle Drive Assembly (Includes Items # 10 & 12)	2	F009	5/16-18 Whiz Locknut	2	
12	6207-12	Pipe Plug (1/4 NPTF)	*	F012	3/8-16 Keps Nut	1	
13	5126	Cable Retainer (Uses existing bolt on Gear Axle Drive Assembly)	1	F023	10-24 ESNA Nut	2	
14	6233-1	Pinion Gear	2	F027	10-24 x 5/8 PPHMS	2	
15	6234	Spacer, Pinion Gear	2	F034	5/16-18 x 3/4 Hex Bolt	2	
16	6201	O-Ring Seal	2	F036	1/4-20 x 1/2 SBH Screw	2	
17	7244	Hydro Pulley (3-7/8/MV) (Includes Items # F064 & F359)	2	F040	3/8-16 x 1-1/2 Hex Bolt	4	
18	6243-1	Hydro Fan, CW	1	F043	3/8-16 x 3 Hex Bolt	6	
19	5025	Hydrostatic Drive, CCW	1	F051	3/8 SAE Washer	2	
Deck Support Arm Assemblies				F053	7/16 Internal Star Lock Washer	4	
20	6430-10	Outboard Mount, LH	1	F063	3/8 Internal Star Lock Washer	16	
21	6431-1	Deck Support Arm, LH (Includes Item # 25)	1	F064	1/8 x 1/2 Woodruff Key (#3)	4	
22	5775-2	Hitch Pin (# 6)	2	F081	A/A45D Aluminum Pop Rivet	2	
23	6431-2	Deck Support Arm, RH (Includes Item # 25)	1	F160	External Snap Ring (.669 Shaft)	2	
24	6430-9	Outboard Mount, RH	1	F178	1/4 x 1 Fender Washer	2	
25	5830	Grease Fitting	2	F194	7/16 x 1-1/4 x 1/8 Washer	2	
26	6840-2	Support Arm Bushing (2-1/16)	2	F200	7/16-20 x 3 Grade 8 Bolt	2	
				F244	7/16-20 x 3/4 Hex Bolt	2	
				F262	3/8-16 x 4 Hex Bolt All Thread	2	
				F359	5/16-18 x 5/16 Set Screw (Knurl Point)	4	
				F579	3/8-16 x 1 Hex Bolt Grade 8	4	
				* Service Part Only			
				** Part not used on Jackshaft side of tractor.			



Beginning S/N 154995
Use only genuine **Walker®** replacement parts.

STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transmission Spring Assemblies				Steering Lever Assemblies			
1	6201-2	Shock Mount Gear Drive, RH	1	32	5223	Extension Spring (1/4 x 5-1/2)	2
2	5146	10mm Ball Stud	4	33	5450	D-Clip	2
3	5199-3	Steering Lever Dampener Assembly	2	34	5451-11	Steering Lever Assembly, LH / Adjustable (Includes Items # 9-11, 16, F034 & F582)	1
4	6201-1	Shock Mount Gear Drive, LH	1	35	5391-3	Steering Lever Support	1
5	5214-2	Ball Joint (5/16-24) Nylon Lined	2	36	5217	Pivot Pin, Steering Lever	1
6	6212-6	Transmission Control Arm, LH	1	37	5453-10	Steering Lever Handle, Adjustable (Includes Items # 14 & F345)	2
7	5213-3	Control Rod (6")	1	38	5450-11	Steering Lever Assembly, RH / Adjustable (Includes Items # 9-11, 16, F034 & F582)	1
8	5665-1	Compression Spring (2-1/2)	2	Fasteners			
9	7201-2	Fiberglide Bearing 1/2"	2		F004	1/4-20 Keps Nut	4
10	5463-5	Steering Arm Pivot Bearing (SS)	2		F007	5/16-18 Jam Nut	2
11	5463-4	Steering Lever Actuator	2		F008	5/16-24 Keps Nut	2
12	5213-4	Control Rod (14-3/4")	1		F009	5/16-18 Whiz Locknut	7
13	5212-6	Transmission Control Arm, RH	1		F010	5/16-24 ESNA Nut	2
Forward Speed Control Assemblies					F012	3/8-16 Keps Nut	2
14	5850-2	Handle Grip, Foam (5-1/2)	3		F024	5/16-24 Jam Nut	4
15	7170-2	FSC Lever Assembly (Includes Item # 16)	1		F029	1/4-20 x 1/2 Hex Bolt	2
16	5830	Grease Fitting	6		F032	1/4-20 x 3/4 Hex Bolt	2
17	5975-3	Cable Tie (50# x 7")	1		F034	5/16-18 x 3/4 Hex Bolt	4
18	5214-4	Ball Joint (5/16-24) W/O Stud	2		F038	3/8-16 x 1 Hex Bolt	2
19	5219	Extension Spring (3/4 x 6-3/4)	1		F050	1/4 SAE Washer	1
20	5172	Bearing, Delrin (.250 x .375 x .250)	2		F051	3/8 SAE Washer	2
21	5141-1	FSC Actuator Block	1		F064	1/8 x 1/2 Woodruff Key (#3)	2
22	5140-9	FSC Brace	1		F068	1/8 x 1 Cotter Pin	1
23	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	2		F069	3/32 x 1/2 Cotter Pin	1
24	5142-8	FSC Key	1		F093	5/16-18 x 1 Hex Bolt	1
	5140-12	FSC Control Assembly (Includes Items # 16, 23-25, 28, F182, F192 & F193)	*		F146	1/4-20 Jam Nut	1
25	5140-30	FSC Friction Body (Includes Item # 16)	1		F182	1/4 x 5/8 x 1/8 Washer	1
26	5141-2	FSC Actuator Rod	1		F183	.312 x .700 x .074 Washer	3
27	5281-5	Clevis Pin (1/4 x 0.80)	1		F186	5/64 x 1/2 Cotter Pin	1
28	5142-9	FSC Actuator Cam	1		F188	1/4-20 Self-Locking Nut	4
29	5141-3	Spacer	1		F192	3/8-24 Self-Locking Nut	1
30	5141-4	FSC Rod	1		F193	3/8 Belleville Spring Washer	3
31	5470-2	Speed Control Stop	1		F198	.250 x .625 x .040 Washer, SS	2
					F226	5/16-18 x 7/8 Hex Bolt	1
					F316	5/16-18 x 1-3/4 Hex Bolt	1
					F345	1/4-20 x .770 Knurled Bolt	4
					F350	1/4-20 LP Nylock	1
					F353	3/8-16 ESNA LP Nut	2
					F401	.504 x .751 x .030 Washer	1
					F562	5/16-18 x 1 Set Screw	1
					F582	Washer 5/16 x 7/8 x .125	2

* Service Part Only


[illegible]

17

THROTTLE CONTROL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Throttle Control Assembly				Fasteners			
1	8121-1	Throttle Cable	1		F002	10-24 Keps Nut	2
2	5172	Bearing, Delrin (.250 x .375 x .250)	1		F005	1/4-20 ESNA Nut	1
3	5108-7	Control Lock Tab	1		F025	10-24 x 3/8 PPHMS	2
4	5108-10	Friction Washer (.125)	1		F050	1/4 SAE Washer	1
5	5108-1	Control Lever, Throttle & Choke	1		F164	10-24 x 1/4 x 3/8 SHL Bolt	1
6	5108-5	Throttle Control Knob, Red	1		F201	1/4 Belleville Spring Washer	2
7	5108-11	Friction Washer (.062)	1				
8	5108-8	Control Bracket	1				
9	7108	Control Assembly	1				
		(Includes Items # 3-5, 7, 8 & F201)					
	8121	Throttle Control and Cable Assembly (Includes Item # 6)	*				
10	8123	Insulation Sleeve (3/8 x 6)	1				
11	5975-3	Cable Tie (50# x 7")	1				
12	5975-1	Cable Tie (18# x 3-3/4")	1				
				*	Service Part Only		


THROTTLE CONTROL ASSEMBLY



PARKING BRAKE ASSEMBLY


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				Fasteners			
1	7406-1	Handle Grip, Red	1	F002	10-24 Keps Nut		2
2	7406-9	Parking Brake Lever	1	F003	1/4-28 Hex Nut		1
3	7406-10	Lever Mount	1	F004	1/4-20 Keps Nut		4
4	5830	Grease Fitting	1	F025	10-24 x 3/8 PPHMS		2
5	7407	Clevis Pin (3/16 x 1/2)	2	F029	1/4-20 x 1/2 Hex Bolt		3
6	7404-6	Brake Actuator Arm	2	F032	1/4-20 x 3/4 Hex Bolt		1
7	7405	Pin, Transmission Lock	2	F054	AN960616 Washer		2
8	7402	Clevis	2	F072	1/4 "E" Retainer Ring		2
9	7408	Compression Spring (1/2 x 3/4)	2	F086	#10 SAE Washer		4
10	7415	Rubber Dust Shield (5/8 x 3/8 x 1/32)	2	F109	1/8 x 5/8 Roll Pin		2
11	5567-3	O-Ring (1/4 x 3/8)	4	F111	1/8 x 3/4 Cotter Pin		1
12	7403	Plunger Bushing, Gear Axle	2	F112	5/8 x 1-1/4 x .03 Washer		2
13	7404-7	Brake Actuator Mount	2	F127	1/16 x 1/2 Cotter Pin		4
14	7412	Clevis Pin (3/16 x 5/8)	2	F261	AN960616L Washer		5
15	5833	Cable Clamp (1/4)	2	F287	1/4-28 Keps Nut		1
16	7410	Brake Control Cable, LH (25.5")	1				
17	7409	Brake Control Cable, RH (20.5")	1				
18	7401-3	Cable Mount Bracket	1				
19	7401-1	Cable Pull Rod	1				
20	5552	Ball Joint (1/4-28)	1				

PARKING BRAKE ASSEMBLY



GHS GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Delivery Chute Assembly				Fasteners			
1	5515-4	Elbow Delivery Spout	1	F002	10-24 Keps Nut		4
2	5592-24	Backing Plate, Grass-Pak® Switch	1	F004	1/4-20 Keps Nut		3
3	5592-23	Grass-Pak® Housing Spacer	1	F009	5/16-18 Whiz Locknut		7
4	5578	Rear Clip, Chute Mount	1	F012	3/8-16 Keps Nut		3
5	5577	Side Clip, Chute Mount	2	F023	10-24 ESNA Nut		2
6	7511-5	Outside Chute Cover Lip	1	F029	1/4-20 x 1/2 Hex Bolt		3
7	7511-4	Inside Chute Cover Lip	1	F034	5/16-18 x 3/4 Hex Bolt		1
8	7511-1	Delivery Chute W/Clips, 7.0 (Includes Items # 4, 5, F079 & F411)	1	F039	3/8-16 x 1-1/4 Hex Bolt		1
9	7530-4	Body Chute (10.5 Blower)	1	F040	3/8-16 x 1-1/2 Hex Bolt		1
Blower Belt Tightener Assembly				F042	3/8-16 x 2-1/4 Hex Bolt		1
10	7238-6	Blower Drive Pulley (Includes Items # F075, F114 & F231)	1	F050	1/4 SAE Washer		1
11	7234-2	Blower Belt (Micro-V)	1	F051	3/8 SAE Washer		1
12	7239-1	Blower Pulley (Micro-V) (Includes Items # F067, F075 & F114)	1	F054	AN960616 Washer		1
13	7364-2	Torsion Spring	1	F067	3/16 x 3/16 x 1 Key		1
14	7201-3	Fiberglide Bearing	2	F075	5/16-18 x 1/2 SQH Set Screw		2
15	5830-3	Grease Fitting (45 Degree)	1	F079	A/A66D Aluminum Pop Rivet		8
16	7364-1	Blower Belt Tightener Arm	1	F090	1/4-20 x 2-1/2 Hex Bolt		1
17	7201-4	Inner Race (1-1/2)	1	F114	5/16-18 x 5/8 SQH Set Screw		2
18	5841-1	Retainer Washer	1	F128	10-24 x 3/8 PTHMS		4
19	5245	Idler Pulley (3")	1	F131	5/16-18 x 1/2 Hex Bolt		3
Blower Assembly				F132	1/4-20 x 2-3/4 Hex Bolt		1
20	7544	Blower Assembly (10.5") (Includes Items # 21-25, F004, F009, F029, F050, F131, F168 & F426)	*	F168	5/16 Split Lock Washer		3
21	5268	Bearing W/Collar (3/4)	2	F217	7/16-14 Hex Nut		1
22	7544-3	Blower Housing (10.5")	1	F218	7/16 Split Lock Washer		1
23	7545-2	Blower Output Shaft (10.5")	1	F231	1/4 x 3/4 Woodruff Key (# 806)		1
24	7545	Blower Wheel (10.5")	1	F281	7/16-14 x 1-3/4 Hex Bolt		1
25	7543-1	Blower Faceplate (10.5")	1	F411	3/16 Bulbex Rivet		6
26	7526	Intake Tube (10.5" Blower)	1	F426	1/4-20 x 1/2 Carriage Bolt		1
27	5595-2	Intake Cover, GHS	**	F577	10-24 x 5/8 Carriage Bolt		2
28	7528-5	Skid Bar	1	* Service Part Only			
				** Plugs Blower when GHS is not in use. Furnished only with Mulching Decks, SD Decks used on a GHS Tractor, Rotary Broom Attachment and Snowblower Attachment. Use of this part may be replaced by installing Blower Lockout Kit (P/N 7541-1).			



GHS POWERFIL® ASSEMBLY (7.0)



ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
7.0 GHS Powerfil® Assembly				Fasteners			
1	5552	Ball Joint (1/4-28)	2		F003	1/4-28 Hex Nut	2
2	5553-3	Bushing, Powerfil® Actuator	4		F023	10-24 ESNA Nut	10
3	5553-1	Compression Spring (1/2 x 2)	2		F054	AN960616 Washer	1
4	5558-2	Powerfil® Actuator Rod	1		F085	3/16 Rivet Backup Washer	1
	5549	Actuator Rod Assembly (Includes Items # 1-5 & F003)	*		F101	10-24 x 1-1/4 SHC Screw	1
5	5558-1	Powerfil® Push Rod	1		F109	1/8 x 5/8 Roll Pin	1
6	5551-3	Bearing Cap, Powerfil®	1		F261	AN960616L Washer	1
7	5551-1	Pivot Bearing (#S3PP)	2		F287	1/4-28 Keps Nut	2
8	5518-2	Pivot, Delivery Spout	1		F612	10-24 x 5/8 Truss Head Torx	7
9	5517-2	Pivot Mount	1		F613	10-24 x 1/2 Truss Head Torx	2
10	5519-5	Actuator Motor (12V) (Includes Items # 11 & 12)	1	*	Service Part Only		
11	5519-2	Motor Mount Washer	*				
12	5519-3	Motor Mount Nut (5/8-24)	*				
13	5554	Actuator Arm	1				

GHS POWERFIL® ASSEMBLY (7.0)

Refer to
Electrical Assemblies
(GHS 7.0 Bushel Components)




Refer to
GHS 7.0 Bushel
Catcher Assembly



GHS 7.0 BUSHEL CATCHER ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Upper Baffle Screen Assembly (Removable)				39	7510-2	7.0 Bushel Catcher Box	1
1	7512-12	Removable Screen (3/16 Hole) (Includes Items # 2, F190 & F617)	1**		7502-5	7.0 Catcher W/Powerfil® (Includes Door)	*
2	7506	Knob / Threaded Insert (10-24)	2	40	7607-8	Powerfil® Cover Plate	1
3	7509-7	Channel Top, LH	1	41	7608-4	Hinge Plate, RH	1
4	8606-2	Channel Bottom	2	42	8155-8	7.0 Gas Spring Cover, RH	1
5	6856-1	Edge Molding (21-3/4")	1	43	7607-14	Catcher Door Arm, RH	1
6	6507	Screen Seal (23-1/4")	1	44	7584-3	Reinforcing Strap	1
7	7505	Mustache Spring	2	45	5801-3	Decal Plate, Round (Set of 2)	1
8	7509-6	C-Channel With Spring (Includes Items # 7 & F340)	1	46	7608-5	Door Arm Stop	2
9	7509-8	Channel Top, RH	1	5598-2 Optional Dump Bag (Not Shown)			
7.0 Exhaust Deflector Door Assembly				May be ordered as an option. Contact your Walker dealer.			
10	7607-3	Upper Door Seal	1	Fasteners			
11	7510-4	7.0 Catcher Box Door (Includes Frame) (Includes Items # 10, 12, 13, 15, F085, F330 & F411)	1	F020	5/16-18 ESNA Nut		2
12	5583	Handle	1	F023	10-24 ESNA Nut		28
13	7607-6	Lower Door Stiffener (7.0)	1	F029	1/4-20 x 1/2 Hex Bolt		2
14	8607-8	Door Guide	1	F031	1/4-20 x 5/8 Hex Bolt		2
15	7607-5	Upper Door Stiffener	1	F049	5/16 SAE Washer		4
GHS 7.0 Bushel Catcher Assembly				F050	1/4 SAE Washer		4
16	7503-8	Center Strap (7.0)	1	F079	A/A66D Aluminum Pop Rivet		4
17	7503-6	Upper Frame Doubler (7.0)	2	F085	3/16 Rivet Backup Washer		4
18	7503-5	Lower Frame Doubler (7.0)	2	F094	8-32 x 1/2 PTHMS		6
19	7503-4	Outside Box Strap (7.0)	2	F190	#10 Internal Star Lock Washer		2
20	8608-4	Center Frame Doubler	1	F196	1/4-20 x 1 PPHMS, SS		4
21	8608-11	Catcher Door Finger	1	F230	1/4-20 x 1-1/4 PPHMS, SS		4
22	7503-11	Catcher Mount	1	F242	1/4-20 x 7/8 PPHMS, SS		8
23	7610-4	Catcher Dump Flap Spacer (7.0)	1	F275	5/16-18 x 2 Hex Bolt		2
24	7610-8	Catcher Dump Flap With Plate	1	F330	3/16D x 21/32L Rivet, SS		4
25	8610-3	Backing Plate / Dump Flap	1	F340	Rivet, Aluminum		4
26	7620-3	Pivot Bushing (1/2 x 9/16)	4	F351	Aluminum Pop Rivet		6
27	7607-7	Bushing	2	F360	1/4-20 x 3/8 Hex Bolt		2
28	7608-3	Hinge Plate, LH	1	F390	1/4-20 x 7/8 Carriage Bolt		4
29	7607-15	Catcher Door Arm, LH	1	F411	3/16 Bulbex Rivet		32
30	8155-7	7.0 Gas Spring Cover, LH	1	F442	1/4-20 x 5/8 PTHMS		2
31	5155-5	Gas Spring	2	F524	3/16 x 3/8 Aluminum Rivet, Black		6
32	5155-13	3/4 Ball Stud	2	F540	1/4-20 x 1-3/4 PPHMS, SS		1
33	5523-6	Gas Spring Plate	2	F551	5/16-18 Flange Top Lock Nut		2
34	5155-12	5/16 Ball Stud	2	F569	1/4-20 Flange Top Lock Nut		25
35	5155-15	Box Support, Gas Spring	2	F612	10-24 x 5/8 Truss Head Torx		4
36	7532-1	Handle, Catcher Lift	2	F613	10-24 x 1/2 Truss Head Torx		10
37	7511-6	Chute Cover	1	F617	10-24 x 3/8 Truss Head Torx		4
38	7557-1	7.0. Wire Harness Channel	1	F618	10-24 x 3/4 Truss Head Torx		12
				* Service Part Only			
				** This screen can be replaced by P/N 7512-13 Removable Screen (3/4" holes) for improved air flow performance in wet conditions.			




Beginning S/N 154995
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Harness Assembly				Fasteners			
1	7941-3	Boot, Circuit Breaker	1	F002	10-24 Keps Nut		10
2	7941-5	Circuit Breaker (7 Amp)	1	F004	1/4-20 Keps Nut		3
3	8990-1	Hourmeter (Global)	1	F009	5/16-18 Whiz Locknut		1
4	8996-9	Red Indicator Light Assembly	1	F019	1/4-20 ESNA Wing Nut		2
5	5835-3	Cable Clamp (1/2) .218 Hole	3	F025	10-24 x 3/8 PPHMS		2
6	7834-2	Wire Saddle (2 Wires)	1	F026	10-24 x 1/2 PPHMS		7
7	6105-3	Harness Clip	1	F031	1/4-20 x 5/8 Hex Bolt		2
8	6104-12	Adapter Harness	1	F032	1/4-20 x 3/4 Hex Bolt		1
9	8960-15	Ignition Switch (With Keys) (Includes Items # 10, 11 & F349)	1	F050	1/4 SAE Washer		2
10	8960-3	Key Set W/Umbrella	1	F079	A/A66D Aluminum Pop Rivet		1
11	7854	Plastic Tip, Red	1	F093	5/16-18 x 1 Hex Bolt		1
12	8536-2	Warning Horn Assembly	1	F129	10-24 x 1/2 PTHMS		1
13	5942-8	Safety Switch (NO), Delta Side Mount	3	F182	1/4 x 5/8 x 1/8 Washer		2
14	5975-3	Cable Tie (50# x 7")	4	F232	10-32 Keps Nut		2
15	8941	Circuit Breaker (30 Amp) Auto Reset / Sealed	1	F349	Washer .835 ID 1.122 OD, SS		1
16	6942	Relay Switch 20/40 Amp (NC)	3	F505	6-32 x 7/8 Hex Trim MS, SS		6
17	7948-6	Time Delay Module (.5 Second Delay)	1	F506	6-32 Nylock Nut		6
18	7948-3	Time Delay Harness	1	* Service Part Only			
19	5832	Cable Clamp (1/2)	5				
20	8018-3	Wire Extension	1				
21	NS	Rectifier	*				
22	8012-7	Ground Wire	1				
23	8012-5	Regulator Adapter Harness	1				
24	6940-14	Wire Harness (Prior to S/N 163871)	1				
	6940-17	Wire Harness (Beginning S/N 163871)	1				
Battery Assembly							
25	8943	Battery Lead Wire (+)	1				
26	5975-1	Cable Tie (18# x 3-3/4")	3				
27	5844-3	Battery Hold-Down Bar	1				
28	5839	Hook Bolt	2				
29	6390-2	Battery Pan	1				
30	NS	Battery (12V/350 CCA/Wet/SP-40)	1				
31	5932	Battery Terminal Insul., Black (-)	1				
32	5933	Battery Terminal Insul., Red (+)	1				
33	6923	Battery Cable (-)	1				

ELECTRICAL ASSEMBLY



Beginning S/N 154995
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Horn & Harness Channel Assemblies

1	5536-2	Horn, Full Signal	*
2	5976-2	Grommet (3/16 x 3/4)	2
3	5975-1	Cable Tie (18# x 3-3/4")	1

Harness & Grass-Pak® Switch Assemblies

4	8950-4	Powerfil Wire Harness (7.0/10.0)	1
5	5833	Cable Clamp (1/4)	2
6	5594-6	Aluminum Shaft & Vane Assembly	1
7	5592-20	Grass-Pak® Switch Assembly	1


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Fasteners

F002	10-24 Keps Nut	1
F023	10-24 ESNA Nut	3
F025	10-24 x 3/8 PPHMS	1
F508	4-40 Keps Nut, SS	2
F509	4-40 x 1/2 Hex Head, SS	2
F612	10-24 x 5/8 Truss Head Torx	1
F613	10-24 x 1/2 Truss Head Torx	2

* Service Part Only


ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)



LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES	ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
Lubrication Points				17	Brake Actuator Pivot	Grease	1
1	Steering Lever Pivot	Grease	4	18	Catcher Hinge Point	Oil	2
2	Body Hinge Point	Oil	2	19	Engine Dipstick / Oil Fill	Oil**	1
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1	20	Throttle Control Cable Ends	Oil	2
4	FSC Actuator Rod Pivot Pins	Oil	2	21	Belt Tightener Pivot, Blower Drive	Grease	1
5	(FSC) Friction Body Pivot	Grease	1	22	Belt Tightener Pivot, Ground Drive	Grease	1
6	FSC Lever Pivot	Grease	1	23	PTO Gearbox Dipstick	Oil**	1
7	Deck Support Arm Pivot	Grease	2	24	Hydrostatic Drive	Oil**	2
8	Gear Axle	Oil**	2	25	Throttle Control Pivot	Oil	1
9	Universal Joint Tube Assembly	Grease*	1	* Grease every 25 hours.			
10	Parking Brake Lever	Grease	1	** See Operator's Manual for procedure for checking and changing oil in Engine Crankcase, Hydrostatic Transmissions, and Gear Axles.			
11	Universal Joint Quick Connect Spline (Grease Slide Area)	Grease	1	NOTE: See Model C19i Operator's Manual (P/N 6000-25) for proper lubrication intervals.			
12	Belt Tightener Pivot, Jackshaft Drive	Grease	1				
13	PTO Clutch Lever Pivot	Grease	1				
14	Clutch Actuator Push Rod	Grease	2				
15	Belt Tightener Pivot, PTO Clutch	Grease	1				
16	Brake Actuator Rod and Brake Band Pivot Pins (Clevis)	Oil	3				

LUBRICATION POINTS



WIRING SCHEMATIC

WALKER MODEL C19i Beginning S/N 154995


IGNITION SWITCH CIRCUITS	
OFF	G + M
START	B + A / S1 + S2
RUN	B + A

S1 = START CIRCUIT
S2 = START/ACCESSORY CIRCUIT
M = MAGNETO GROUND CIRCUIT
B = BATTERY CIRCUIT
A = ACCESSORY CIRCUIT
G = GROUND CIRCUIT

RELAY - A	
IGNITION RELAY	
OFF	30 + 87A
START	30 + 87A
PTO ON	OPEN

RELAY - B	
START RELAY	
OFF	OPEN
START	30 + 87
PTO ON	OPEN

RELAY - C	
DELAY RELAY	
OFF	30 + 87A
START	OPEN
RUN	OPEN



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER COMMERCIAL RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within two (2) years* after the date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty except the following components which are warranted separately by their respective manufacturers:

Kohler Engine
Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* Extended warranties are offered for the following powertrain components:

- A three (3) year unlimited hour warranty is offered for the Walker P/N 6200-9 Gear Axle Assembly.
- A three (3) year or 3000 hour (whichever comes first) warranty is offered for Eaton Model 7 Hydrostatic transmissions; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 3000 hours.

2. WHAT THIS WARRANTY DOES NOT COVER:


- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 061620 PRINTED IN USA www.walker.com ©2020 WALKER MFG. CO