

## **CONTENTS**

CONTENTS1
I. Precautions before using the system2
II.Introduction and operation of the main page features4
III.Introduction to radio features and operation6
IV. Brief introduction and operation of Bluetooth function7
V. Function introduction and operation of USB flash disk \SD card8
VI.Function introduction and operation of Phone link11
VII. Introduction and operation of setting menu function13
VIII. Brief introduction and operation of learning function of direction control14
IX. Brief introduction and operation of remote control function15
X. Introduction to interface definition




## Important security information

Please read and fully understand the following information before use, and keep this manual next to the product for reference.

- ★ Warning
- Do not install or repair the product by yourself.
- Personnel who are not trained in repairing electronic equipment and auto parts may cause danger when installing or repairing this product.
- For the personal security of you and others, it is forbidden to watch videos and perform related operations while driving according to relevant national laws and regulations. Please do not watch the screen and do related operations while driving the car.
- Please take note of all the precautions in this manual and strictly follow the operating instructions.
- Do not tap liquids, as this product may be short-circuited or damaged.
- ◆ Security statement
- The reversing camera function in this system should only be used as an auxiliary reference while driving, so please pay attention to the actual situation.
- ★ Note
- Do not expose this product to moisture.
- The date of the different screens displayed by the main unit must be manually adjusted to display accurately when the product is first turned on and used or when the vehicle has been disconnected and reconnected for use.

- ◆ Ensuring safe driving
- Always obey safe driving regulations and current traffic rules.
- Do not continue to use this product if its use, including use of the back-up camera function, interferes with your security and concentration while driving.
- If you need to watch the screen to do so, park the vehicle in a safe place and make sure the parking brake is applied.
- When using this product, do not set the volume too high, or you will not be able to hear the traffic and emergency signals outside the vehicle.
- When the vehicle is running, some functions (such as video playback, etc.) cannot be realized for the sake of driving security.
- ◆ Other security information
- The system automatically detects the speed at which the vehicle is traveling, and when the speed is above a certain value, the system will prevent you from using the video playback feature while driving. If you want to watch a video, pull over at Security and use the parking brake.
- Use the system when starting the engine to prevent battery exhaustion.

# II.Introduction and operation of the main page features



## 1.Home key

Tap this key to return to the main interface;

## 2. Volume key

Tap the volume key to display the current volume information; You can adjust the volume \ switch mute \ \ display the current volume status.

#### 3. Radio mode icon

Tap the radio mode icon to enter the radio operation interface.

#### 4.Bluetooth mode icon

Tap the Bluetooth mode icon to enter the Bluetooth operation interface.

## 5.Backlight mode icon

Tap the backlight mode icon to switch between day and night or turn off the backlight mode.

## 6. Displays the device connection status

Displays the connection status of Bluetooth or USB. When Bluetooth or USB is connected, the corresponding icon will be highlighted on the screen, otherwise it will not be displayed.

## 7.USB mode icon

Tap the USB mode icon to enter the USB operation interface.

## 8. Time display

Displays the current system time; Tap it to switch the clock format \ digital format display.

#### 9. Phone link mode icon

Tap the mode icon of Phone link to enter the operation interface of Phone link:

#### 10.SD card mode icon

Tap the SD card mode icon to enter the SD card operation interface;

## 11.Setting mode icon

Tap the setting mode icon to enter the setting mode for operation;

#### 12.AUX mode icon

Tap the AUX mode icon to enter the AUX operation interface;

#### 13.FCAM mode icon

Tap the FCAM mode icon to enter the FCAM operation interface;

## 14. DSP mode icon

Tap this DSP icon to Audio regulation

## III.Introduction to radio features and operation



- 1. Tap this key to browse the stored station information; long-tap this key for one second to search the station from the lowest to the highest frequency, and save the searched information to the search list, and the list will be refreshed and replaced;
- 2. Tap this key to cycle through FM > AM > FM modes;
- Tap this key to switch to stereo/mono;
- 4. Tap this key to toggle remote/near distance;
- 5. Htt Tap this key. The frequencies can be moved backward, long-touch for one second to search backward, and automatically stop when a valid station is found.
- 6. Tap this key. The frequencies can be moved forward, long-touch for one second to search forward, and automatically stop when a valid station is found.
- 7.Radio Storage Area. 18 stations can be stored in FM and 12 in AM; (AM function is optional).
- 8. Tap this key to Browse the radio

- 9. Tap this key to Audio regulation
- 10. Tap this key to RDS Function setting

# IV. Brief introduction and operation of Bluetooth function

Introduction of Bluetooth Function:

The system is compatible with Bluetooth V4.2+BR+EDR and supports A2DP\AVCTP\AVDTP\AVRCP\HFP\SPP\ATT\GAP\GATT\RFCOMM\SDP\L2CAP



- 1. Tap this key to enter the Bluetooth extraction interface;
- 2. Tap this key to enter the Bluetooth call recording interface;
- 3. Tap this key to enter the Bluetooth phone book interface;
- 4. **Tap this key to enter the Bluetooth music interface**;
- 5. Tap this key to enter the Bluetooth connection interface;
- 6. Tap this key to delete the connected phone's information;
- 7. Tap this key to disconnect the connected phone \reconnect the phone to Bluetooth;

# V. Function introduction and operation of USB flash disk \SD card

1. Introduction and operation of the music playback function.

Introduction to the music playback feature.

Supports playing MP3\WMA\AAC\WAVE\FLAC\APE\OGG\M4A(QT)\RA;



- 1.1. Tap this key to enter the audio setting interface;
- 1.2. Tap this key to toggle the single song loop/ folder loop/ all loop function:
- 1.3. Tap this key to switch to the previous song to play;
- 1.4. Tap this key to turn on the random play function;
- 1.5. Tap this key to toggle on the pause/play function;
- 1.6. Tap this key to turn on the \ Off numeric keyboard function;
- 1.7. Tap this key to switch to the next song;
- 1.8. Tap this key to turn on the d\ off the song list function;
- 1.9. Tap this key to enter the d\exit file list screen;

## 2. Introduction and operation of the video playback function

Video playback function overview:

Support playing DIVX\AVI\MKV\QT\MPG\ASF\FLV\RMVB\TS;





- 2.1. Tap this key to switch to the previous song;
- 2.2. Tap this key to toggle the pause/play function;
- 2.3. Tap this key to switch to the next song;
- 2.4. Tap this key to toggle between single loop/ folder loop/ all loop function;
- 2.5. Tap this key to turn on random play;
- 2.6. Tap this key to zoom in on the video;
- 2.7. Tap this key to switch to the next SOD;
- 2.8. Tap this key to enter the audio setting interface;
- 2.9. Tap this key to enter the interface of display settings;
- 2.10. Tap this key to turn on/off the numeric keypad function;
- 2.11. Tap this key to turn on/off the song list function;
- 2.12. Tap this key to switch to the previous page of SOD;

## 3. Introduction and operation of picture playback function

Picture playback function description: support playing JPG\BMP\PNG;





- Tap this key to switch to the previous picture;
- 3.2. Tap this key to toggle the pause/play function;
- 3.3. Tap this key to switch to the next picture to be played;
- 3.4. Tap this key to turn on/off the numeric keyboard function;
- 3.5. Tap this key to switch to the next SOD;
- 3.6. Tap this key to zoom in on a picture;
- Tap this key to rotate the picture;
- 3.8. Tap this key to toggle between single song loop/ folder loop/ all loop functions;
- 3.9. Tap this key to turn on the random play function;
- 3.10. Tap it to switch to the previous page of the SOD;