


Interactive Solution Basics: SMART Board® 8070ie

SMART®



The SMART Board 8070ie interactive flat panel comes with SMART Meeting Pro™ software and integrates with an appliance that performs many of the functions of a computer. The appliance computing device eliminates the need for a dedicated meeting room computer and creates a secure, stand-alone system.

By touching the interactive surface with your finger or a pen from the pen tray you can:


- Open and close applications
- Conference with others
- Create new documents or edit existing ones
- Visit websites
- Manipulate objects
- Control video players

Two users can draw on the interactive surface at the same time, and you can use an array of touch and multitouch gestures to control software applications. You can easily save your work for future reference and distribution.


Waking up your interactive flat panel

Ensure the computer is on. Touch the interactive surface or press the **Power** button on the integrated control panel to wake your interactive flat panel from Standby mode.

Integrated control panel



Pen tray buttons



Interactive Solution Basics: SMART Board 8070ie

Writing and erasing notes

Pick up a pen from the bottom bezel and press one of the four color buttons to select the digital ink color.

To write over your desktop or an open application, begin writing with the pen on the interactive flat panel. To erase, pick up the eraser and move it in a smooth motion over your notes. You can also press your palm or fist on the interactive screen and move your hand over the notes to erase them.

If the interactive flat panel isn't registering your touch accurately, follow the orientation instructions at the end of this guide.


Getting started with SMART Meeting Pro software



SMART Meeting Pro is collaboration and meeting productivity software that helps transform meetings into collaborative work sessions where teams actively learn and share knowledge to enable faster, more effective decision-making. Take the *My Meeting* tutorial to learn how to use this software with the SMART solutions in your meeting room.

To take the tutorial on your interactive flat panel:

1. Press **Whiteboard** on the SMART Business Toolbar
2. Select **Help > Contents**




3. Press **Tutorials**, and then select the **SMART Meeting Pro software** link. The *My Meeting* tutorial opens in a new window.

To take the tutorial online, browse to smarttech.com/SMARTMeetingProTutorial.

Displaying content

You can switch between Whiteboard, Web, Presentation, PDF and Organizer modes using the SMART Meeting Pro business toolbar.



Use Whiteboard mode for brainstorming and Web mode for browsing the Internet. Use Presentation mode to view and deliver Microsoft® PowerPoint® presentations. Use PDF mode to view and write on PDF files. Organizer mode is your meeting dashboard. Use it to view meeting details and manage all connected displays.

Orientation

Orient your interactive flat panel whenever the mouse pointer isn't properly aligned with your finger or a pen when you touch the interactive surface.

To orient your interactive flat panel:

1. Press the **Orientation** button  on the bottom bezel. The orientation screen appears.
2. Pick up a pen from the bottom bezel
3. Begin at the top-left corner of the screen, and touch the center of the target firmly with the tip of the pen. When you remove the pen, the target moves to the next orientation point.
4. Repeat step 3 for each orientation target. When you complete the process, the orientation screen closes.

Resources

For more information on:

- Your interactive flat panel, download the user's guide at smarttech.com/support
- Connecting a guest laptop, visit smarttech.com/connectGoWire
- How Interactive visual collaboration solutions can transform the way you work, visit smarttech.com/trainingforbusiness