



Parent's Guide

Super Learning Phone



©2018 Frog Box/Entertainment One UK Limited

91-003605-000 UK

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® PJ Masks Super Learning Phone**. Join your **PJ Masks** heroes: Catboy, Owlette and Gekko to help them save the day as they stop Night Ninja, Romeo and Luna Girl from getting up to mischief!

The **PJ Masks Super Learning Phone** includes 3 learning games and 3 fun apps that help to test your skill with numbers, counting, matching, logic and more. You can also receive fun virtual voice messages from 6 of the PJ Masks characters and use voice activated play to make pretend phone calls.

Jump into the night to save the day with the **PJ Masks!**



INCLUDED IN THIS PACKAGE


- One VTech® PJ Masks Super Learning Phone
- One User's Manual

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.

Unlock the packaging locks:




① Rotate the packaging locks 90 degrees anti-clockwise

② Pull out the packaging locks

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is OFF.
2. Locate the battery cover on the bottom of the unit.
3. Open the battery cover by screw driver.
4. Install 2 new AAA (LR03/AM-4) batteries into the compartment as illustrated. (The use of new, alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover.



BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metal-hydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES

1. ON/OFF BUTTON

To turn the unit on, press the **On/Off Button**. Press the **On/Off Button** again to turn the unit off.

2. 6 CHARACTER BUTTONS



Press one of the **6 Character Buttons** (Catboy, Gekko, Owlette, Night Ninja, Luna Girl, Romeo) to hear a message from the character.

3. ACTIVITY BUTTONS



Press the **Activity Buttons** directly to play one of the 3 learning games, view the Photo Album or adjust the Settings.

4. NUMBER BUTTONS



Press the **Number Buttons** to learn numbers or to answer number-related questions.

5. LET'S CHAT BUTTON

Press the **Let's Chat Button** to enter the Let's Chat activity. This activity uses the voice activation feature. The LED will light up when this button is activated.

6. ENTER BUTTON

Press the **Enter Button** to confirm your choice.

7. LEFT/RIGHT BUTTONS

Press the **Left/Right Buttons** to make a selection in activities or menus.

8. PHONE CALL BUTTON

Press the **Phone Call Button** to make a virtual phone call. You will hear the phone ringing and will then be able to leave a message on the answering machine. You can also change the ringtone in the **Settings**.

9. CANCEL CALL BUTTON

Press the **Cancel Call Button** at any time to exit the current activity.

10. MICROPHONE

The **Microphone** is located on the top left and used for the voice activation feature. The suggested distance to keep between the microphone and your mouth is about 10-12 centimetres.



11. AUTOMATIC SHUT-OFF

To preserve battery life, the **PJ Masks Super Learning Phone** will automatically turn off after several minutes of inactivity. The unit can be turned on again by pressing the **On/Off Button**. The unit will also automatically turn off when the batteries are very low. A warning will be displayed on screen as a reminder to change the batteries.

Note: If the unit powers down while playing, we suggest changing the batteries.

ACTIVITIES

The **VTech® PJ Masks Super Learning Phone** includes the following activities and features:

1. Voice Messages

Press any of the **6 Character Buttons** (Catboy, Gekko, Owlette, Night Ninja, Luna Girl, Romeo) on the phone to listen to the character's voice message with related animation.

2. Night Ninja vs the HQ



Ninjalinos are taking over the Headquarters!

Some Ninjalinos are going in and out of the HQ. Watch carefully and decide how many Ninjalinos are still inside when they stop moving. Help take back the HQ by touching the **Number Buttons** to answer.

3. Matching Shapes



Owlette needs to help the butterflies. Blow into the **Microphone** to help Owlette remove the leaves. When the leaves are cleared Owlette discovers that the butterfly wings don't match. To match the wings, press **Left/Right Buttons** to choose, then press **Enter** to confirm.

4. Numbers in the Dark



Romeo has hidden some of the PJ Masks belongings in a locker in his lab and written down the passcode. Gekko has entered the lab but all the lights are turned off and he needs to find his way around in the dark. What is the passcode? Touch the **Number Buttons** to answer.

5. PJ Masks Photo Album



Let's look at some pictures of the PJ Masks! Press **Left/Right Buttons** to choose, then press **Enter** to confirm.

6. Settings



Press this activity button to adjust screen contrast, background music on/off, and choose one of the 5 ringtones to personalise your phone in the **Phone Call Button**.

7. Let's Chat



Let's call the PJ Masks! A phone number will be shown with beeping sounds, followed by a phone ringing sound and one of the PJ Masks will answer.

You will then be asked a series of questions. Speak into the **Microphone** to answer, or press the **Cancel Call Button** at any time to hang up.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the program/activity stops working or the unit stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing VTech products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

CLASS 1
LED PRODUCT



**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au



VTech and the VTech logo TM & © 2018 VTech Holdings Limited.

All rights reserved.

Printed in China.

©2018 Frog Box/Entertainment One UK Limited

91-003605-000 