



# VOYAGER™

QUICK START GUIDE




MCDD0014801 (1.4) H

Voyager™ is a trademark of Plantronics, Inc. used under license by Verizon Wireless.

# Getting to Know Your Phone



Touch Soft Keys:



Message Phone Menu Contacts

Steps in this guide are shown using the touch screen. Refer to the User Guide for more details.

# QWERTY Keyboard



\*Customizable

# Using the Touch Screen

## Touch Protection

The touch screen is automatically locked when the phone is closed or after the phone is inactive for 14 seconds (default).

## Unlocking the Touch Screen


- Tap **Unlock icon**  .  
– or –
- Slide the **Unlock Key**  on the left side of the phone downwards and release.



## Using the Touch Screen



- Use the tip of your finger to touch the center of a touch key.
- It's not necessary to press hard. A light tap will do.
- Press and *drag* your finger **up** or **down** to scroll.
- A beep will sound when you've reached the top or bottom of a menu.
- Press the **Power/End Key** at any time to return to the idle screen.

## Touch Screen Settings

- Tap **Menu icon** , **Settings & Tools**, then scroll down to **Touch Settings (8)** to adjust the touch screen's sound, vibration, and calibration.
- If the touch screen is not responding as you expect, calibrate the screen for touch accuracy.

# Making & Answering a Call




## Calling Someone in Your Contacts List

1. Unlock the phone.
2. Tap **Contacts icon** , then  for a quick jump, and choose a contact.
3. Tap the phone number you want to dial.


## Dialing a Call

1. Unlock the phone.
2. Tap **Phone icon** , then use the virtual keypad to enter a phone number.
3. Tap **Call** or press the **Send Key**.


## Checking Voicemail

1. Unlock the phone.
2. Tap **Phone icon** , then tap and hold .
3. Tap **Unlock icon** , then enter your password.



## Answering Calls

Press the **Send Key** or tap **Unlock icon** , then **Answer**.

**Note:** If the phone is ringing or vibrating, press the **Volume Keys** to quiet the phone.





## Subscribing & Watching TV

1. Unlock the phone, and tap the center of the touch screen to access the **Shortcut Menu**. Tap **Mobile TV** .
2. Rotate phone clock wise.
3. An introduction video clip will play (for the first time).
4. Tap **Subscribe Now**. Review base package and tap **Continue**.
5. Read the Terms and Conditions and tap **Agree**. Confirm selection and tap **Submit**.
6. From the V CAST screen, tap **Program Guide icon**  on the top left corner. Tap the show you want to watch.



# Browsing the Net

1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **Browser** .
4. Rotate phone clock wise.
5. Choose a category or tap **WWW**, then **Touch Here** to type in a specific web site using the virtual keyboard.
6. On a web page, drag **up** or **down** to scroll, or tap on a section in the thumbnail for a quick jump.




Back Refresh Home Zoom Favorites Thumbnail


To activate the thumbnail feature:

Tap **Menu** > **Settings (9)** > **Display (2)** > **Thumbnail (1)** > **On** or **Auto**.

**Note:** Browser supports full screen mode, sending URL via text messages, auto-complete feature, and Spanish input for text and browser search, other than URL.

# Getting Music


1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **My Music** .
4. Rotate phone clock wise.
5. Tap **Shop** to access V CAST Music.
6. Select a song from one of the categories and tap **Buy** to purchase it.
7. Tap **Buy This Song** to confirm purchase.
8. Tap **Download Now** to download the song. Downloaded songs are stored in **My Music**.





**Note:** Refer to the User Guide or Quick Reference Guide for instructions on how to sync music from PC to phone.



## Playing Music

1. Unlock the phone.
2. Tap the center of the touch screen to access the **Shortcut Menu**.
3. Tap **My Music** .
4. Rotate phone clock wise.
5. Select a song from one of the categories to play.
6. Use the **Volume Keys** to adjust volume when a song is playing.
7. Press the **Power/End Key** to exit the music player.




**Note:** With the flip closed, if you answer a call while playing music, browsing the net, watching TV/video, or using VZ Navigator,<sup>SM</sup> and end the call by pressing the external **End Key**, the touch screen will lock. Unlock the phone by sliding the **Unlock Key**  downwards.


## Taking a Picture/Recording a Video

1. Unlock the phone.
2. To activate camera mode: Press the **Key** located on the left side of the phone.  
To activate video mode: Press and *hold* the **Key**.
3. Rotate phone clock wise.
4. Use the **Volume Keys** to zoom.\* Tap **Options** to adjust other camera/video options.
5. Press the **Key** to take a photo or record a video.
6. You can save, send or erase the photo/video.

\*Camera setting of 1600x1200 pixels does not support zoom function.





# Bluetooth® Pairing

1. Set your Bluetooth accessory into pairing mode.\*
2. Unlock the phone.
3. Tap the center of the touch screen to access the **Shortcut Menu**.
4. Tap **Bluetooth** .
5. Tap **Add New Device (1)**.
6. If Bluetooth is set to off, you will be prompted to turn it on. Tap **Yes**.
7. Tap **OK**, and the phone will now search for the accessory. Once found, tap the accessory to pair.\*
8. Tap **Yes** to connect with the device.

*\*Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the passcode if asked (typically "0000" - 4 zeroes). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passcode.*

**Note:** Bluetooth accessories sold separately.



## Optional Accessories

Accessories for convenience and fashion are available at [www.VerizonWireless.com](http://www.VerizonWireless.com).



Bluetooth Headset




Bluetooth Stereo Headset



Bluetooth Stereo Speakers



Portable Stereo Speakers



Extended Li-Polymer Battery  
(1,500 mAh)



Swivel Holster with Kickstand

©2007 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.