



If the previous settings still remain, press the **Clear All** button.



10. Select a mailbox to which the data will be saved.




**NOTE:** If you have the optional Color Scanner Kit installed, the lower portion of the screen show above will be different. Consult the Scan chapter in the User Guide for more information.

11. If appropriate, select desired features from the various tabs.

Proceed to the next step.

12. Press the **Start** button to copy or scan the job.



**NOTE 1:** If a problem occurs, an error message appears in the display of the Touch Screen. Follow the instructions on the screen to correct the problem.

**NOTE 2:** At this time, you can program your next copy or scan job. For more information, refer to your User Guide.