



## FIRMWARE INSTALLATION GUIDE

RAZER HUNTSMAN MINI FIRMWARE UPDATER V1.32.00\_R2

---

## UPDATER INFORMATION

### APPLICABLE MODEL NUMBERS

1. RZ03-03390100
2. RZ03-03390200
3. RZ03-03390300
4. RZ03-03390400
5. RZ03-03390500

### UPDATER NAME AND VERSION

Razer Huntsman Mini Firmware Updater v1.32.00\_r2

Download the firmware here: <https://rzd.to/XmKwMq>

### RELEASE NOTES:

1. Fixed an issue where the taskbar lags re-plugging the keyboard in AMD systems.

---

## PREPARATIONS

- Ensure that you have downloaded the latest firmware version before starting the installation
- Ensure that Razer Synapse and all other running applications are closed before proceeding with the update.


---

## INSTALLATION PROCESS


1. Run the downloaded firmware (The installer will prompt you to close Synapse and all other applications, if you have already done so, left click "OK" to proceed).



2. Connect the Huntsman Mini and click Update.



3. Wait for the update to complete.



4. Once the firmware has been successfully applied, left-click "Close" to exit the installer.

