




COSTWAY




USER'S MANUAL
OFFICE DESK WITH 3 DRAWERS
CB10185

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!


Contact our friendly customer service department for help first.
Replacements for missing or damaged parts will be shipped ASAP!

FLOOR AREA
2MX2M



ASSEMBLED BY 2 ADULT

Follow Costway




Contact Us!

Do NOT return this item.




Contact our friendly customer service department for help first.








Before You Start



- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.



A1 x 50 	C2 x 16  5X13	N1 x 24  3.5X16
O2 x 6 	G2 x 60 	G1 x 14 
G0 x 14 	F1 12 	E1 x 12 
GM x 12 	M x 1 	T3 x 3 
T1 x 1 	GD x 6 	



①	x 1	900 mm	500 mm	16 mm
②	x 1	750 mm	444 mm	16 mm
③	x 1	750 mm	444 mm	16 mm
④	x 1	300 mm	444 mm	16 mm
⑤	x 3	300 mm	60 mm	16 mm
⑥	x 3	200 mm	328 mm	16 mm
⑦	x 3	100 mm	243 mm	16 mm
⑧	x 3	100 mm	400 mm	16 mm

⑨	x 3	100 mm	400 mm	16 mm
⑩	x 1	506 mm	285 mm	16 mm
⑪	x 1	532 mm	150 mm	16 mm
⑫	x 1	750 mm	444 mm	16 mm
⑬	x 3	405 mm	273 mm	3 mm
⑭	x 1	300 mm	80 mm	16 mm
⑮	x 1	670 mm	330 mm	3 mm

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

It is best to keep your furniture in a climate-controlled environment.

Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you **EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!**

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

**THANK
YOU**
😊