

Quick Start Guide




Bell Streamer




WHAT'S IN THE BOX



Bell Streamer



HDMI Cable




USB Cable +
Power Adapter



Batteries

REMOTE CONTROL



Google Assistant

With the Google Assistant built in you can quickly access entertainment, get answers, and control devices around your home. Find the latest blockbuster, check the score of the big game or dim the lights. Just press the Assistant button on your remote to get started.



Home button takes user to Fibe TV App Home screen/custom launcher.



App Buttons takes user to "Apps" Page in the Launcher.




The "Fibe" button takes users to last channel watched. If used for the first time, it will take user to the top trending live channel.

SETTING UP THE BELL STREAMER

OPERATING TEMPERATURE & CONDITION

- 1 Power on your TV and Bell Streamer.



- 2 Make sure your TV is set to the correct HDMI input.




Connect the Bell Streamer to your TV with the included HDMI cable.

- 3 Make sure your WiFi Router is set to On.

- 4 Follow on-screen setup instructions.

Rating	DC5V,1A
Operation Temperature	0~40°C
Max Altitude	5000m

TROUBLESHOOTING



1. Turn on the TV and the Bell Streamer.
2. Press and hold button (on Bell Streamer) for up to 3 seconds.
3. Follow the on-screen remote control pairing instructions.