

**Code List - Lista de Códigos**

TV	
ABEX.....	0401
ADC.....	1431,1661
ADMIRAL.....	0371,0681
.....	1441,1661,4991
ADVENT.....	3261,0631
.....	0871,2891,4931,0581
AFFINITY.....	2361,2381
AIKO.....	1011,4321
AIWA.....	0411,0931,4731,4801
AKAI.....	0191,5891,5901,5911
.....	5921,6041,3215,0331
.....	4151,4461,5141,5171
ALLERON.....	1711
AMTRON.....	2191
AMW.....	0645,0825
ANAM NATIONAL.....	0271,1941
.....	2151,3451,2191,2331,3431
AOC.....	4261,1961
APEX.....	6081,6101,0045,4841
.....	2521,0191,1891,0425,0431
.....	0671,1025,1105,5111,0245
ARIA.....	4101
ARIO.....	1891
ATVIO.....	2371
AUDIOVOX.....	2191
.....	2451,4031,4051,4521
AURIA.....	1221,1171,1411
AVENTURA.....	0141
AXION.....	0881
BANG&OLUFSEN.....	1591
BELL&HOWELL.....	1261
.....	1661,1691,3421
BENO.....	1741,1761,2221,3871
BLUESKY.....	3511,3921
BROKSONIC.....	0371
.....	0211,0851,1631,4951
CAPEHART.....	0391,4221
CCE.....	3721
CELERA.....	0191
CENTRIOS.....	1361
CETOMER.....	0001,1631,2901,2961
CETRONIC.....	1941
CHANGHONG.....	4841
CHIMEI.....	3071
CINERAL.....	3511,4321
CITIZEN.....	0001,0961
.....	1221,1661,1941,2191,4321
CLASSIC.....	1941,4841
CLP.....	0061
CLP CLASSIC.....	0001,0041,0161
COBY.....	2521,3351,2511
.....	2531,5091,5191,2541,2551
COLORTYME.....	0001,1221,1431
CONTEC.....	0011,1911,1941,2191
CONTEX.....	5411
CORNEA.....	1471
CRAIG.....	1941,2191
CROWN.....	1941,2191
CURTIS.....	2121,2141
.....	2361,2371,5411,1881,1891
CURTIS MATHES.....	0351
.....	1551,5351,5371,0001
.....	0261,1221,1661,4011,4941
CYBERVISION.....	3511
DAEWOO.....	1561,0001
.....	0591,0721,0831,0971,1221
.....	1231,1251,1431,1501,1521
.....	1551,1941,2181,4321,4681
DAYTRON.....	0001,1221
DELL.....	0981
.....	1401,3441,2041,3601,3811
DÉVANT.....	6211

DIGIMATE.....	4301
DIGISTAR.....	0381,0581
.....	0871,1061,2451,2471,3901
DISH NETWORK.....	5491
DISNEY.....	0371,1101
DISTAR.....	3231
DUKANE.....	1271,1981
DURABRAND.....	0371,0141,0861
.....	0921,1381,2271,2291,5121
DYNASTY.....	1941
DYNEC.....	3141
.....	5311,3161,0371,2891
ELECTROHOME.....	0001
.....	1221,1921,2151,3431
ELECTRON.....	2121
ELEKTRA.....	1661
ELEMENT.....	5421,2401
.....	5471,1091,1651,5831
.....	5841,5341,6021,5361
ELITE VIDEO.....	0901
EMERSON.....	2761,5761
.....	5221,5231,5561,5831,4731
.....	5421,5741,0001,0141,1651
.....	0201,0231,0951,1551,5551
ENVISION.....	1411,5401
.....	0001,0071,1221,3751,4261
EQD.....	1171,1411
ESA.....	0141,1381
FAVI.....	2141
FISHER.....	5001
.....	1261,1531,1581,1911,3481
FLUID.....	2401,2421,2431
FUJITSU.....	0901,1711,4241,4341
FUNAI.....	0445,0141,0931
.....	1711,1941,2191,4731,4761
FUTURETEC.....	1941,2191
GATEWAY.....	0501
GE (GENERAL ELECTRIC).....	4921
.....	0141,0191,1001,0001,0401
.....	0051,0261,3451,0361,0791
.....	1221,1921,1951,2151,3431,4011
GFM.....	0141,5831
GIBRALTR.....	0001,1771,1781
GOLDSTAR.....	0001
.....	0611,0761,0931
.....	1181,1221,1501,1911,4731
GPX.....	4701
GRADIENTE.....	0001
.....	2291,3661,3951,3961
GUESTVISION.....	1861
GVISION.....	4871
HAIER.....	6151,6141,0921
.....	2141,0671,1061,3831,4851
HALLMARK.....	0001,1221
HANNSPREE.....	5451,5461,5291
HAUPPAUGE.....	3791
HELLO KITTY.....	5391
HEWLETTPACKARD.....	3491,4881
HISENSE.....	6161
.....	1651,6171,2081,5331,2211
.....	2141,5341,0001,0671,4391
HITACHI.....	1041,4331,0925
HKC.....	5721
HP.....	3491
HYUNDAI.....	4651
ILO.....	5171
.....	1381,3215,1141,2391
.....	3691,4231,5031,5141
INFINITY.....	4791
INFOCUS.....	3421
INITIAL.....	4231
.....	4821,5031,5041
INSIGNIA.....	2891,6171,0371

.....	2271,0141,0581,0871,0921
.....	2241,6181,2921,3761,4371
.....	4721,4761,5051,5061,5181
INTEO.....	1771,1781
ISYMPHONY.....	2141,3401
JC PENNEY.....	0001
DUKANE.....	0051,0261,0791,0961,1221
.....	1451,1911,1921,1951,4011
JENSEN.....	2271,0001,1221
JVC.....	5071
.....	1481,0311,0481,0771
.....	0901,1281,1801,1911,5281
KAWASAKI.....	4741
KAWASHO.....	0001,1221,1901
KAYPANI.....	0391,4221
KDS.....	5541
KEC.....	2191,1941
KENWOOD.....	0001,1221
KLH.....	0191
KLOSS NOVABEAM.....	0151,1021
KOGI.....	4871
KONKA.....	6181
.....	4971,0471,0521,5891
.....	1671,2191,2241,4621
KTV.....	0011,1491,1681,1941,2191
KURAZAI.....	1661
KWORLD.....	2931
LASONIC.....	1211,1611,4811
LEGEND.....	1891,0581
LG.....	6021,0001
.....	5511,3001,1911,1181,1221
LIQUIDVIDEO.....	0881,1111
LOGENET.....	1661
.....	1691,2091,3421,4091
LOEWE.....	1871
LOGIK.....	1661,1691,3421
LUCE.....	0301
LUXMAN.....	0001,1221
LXI.....	0001,0261
.....	0931,1221,1691,4011,4731
MAG.....	5541
MAGNASONIC.....	1711
MAGNAVOX.....	5741,4761
.....	0975,4191,4641,4261,0141
MAJESTIC.....	1661,1691,3421
MANHATTAN.....	5381
MARANTZ.....	0001,1221,1841
MAXENT.....	0501,3361
MEDION.....	1101,1141,2351
MEGATRON.....	0001,1221,1271
MEI.....	0011
MEMOREX.....	1711,0001,0211,1221
.....	1631,1661,2401,4251,5001
MGA.....	0001,1221
.....	1581,1711,1801,1911,1921
MIDLAND.....	0051
.....	0261,0811,1691,1781,4011
MINTEK.....	4231
MINUTZ.....	1951
MISAKAI.....	1381
MITSUBISHI.....	3271
.....	1811,0251,0001,1221
.....	1581,1711,1801,1921,2701
MONIVISION.....	0491
MONTGOMERY WARD.....	1661
.....	1691,3421
MOTIVA.....	1261,3661
MOTOROLA.....	1441,2151,3431
MTC.....	0001
.....	0011,0251,0351,1221,1311
MYRON & DAVIS.....	2101
NAD.....	0001
.....	0401,1221,1311,4021

NAXA.....	1421,2141
NEC.....	0001
.....	0341,1221,1431,3451
.....	1801,1841,2151,3431,4401
NET TV.....	0121,0501
NEXUS ELECTRONICS.....	1651,6021
NEXXTECH.....	0871,1201
NIKEI.....	1941
NIKKO.....	0001,1011,1221,4321
NIKO.....	3581
NORCENT.....	0511,0671,2181
NTC.....	1011,4321
OLEVIA.....	3081
.....	2771,2791,5151,5161
ONCOMMAND.....	1861,3991
ONKYO.....	3101
ONWA.....	1941,2191
OPTIMUS.....	0401
.....	1571,3551,4021,5201
OPTOMA.....	3121,2441
OPTONICA.....	0341,1441
ORION.....	0371,0281,1771,1781
PANASONIC.....	6231,5821
.....	5201,5531,1571,5561,5201
PHILCO.....	2321,0141,0001,0321
.....	0961,1021,3451,1221,1671
.....	1801,2151,2941,3431,3931
PHILIPS.....	6221,0181,5741
.....	6051,0201,0911,3981,4261
PHILIPS-MAGNAVOX.....	0681
.....	0911,2321,4791,4991
PIONEER.....	0401,1221,1981,0001
.....	1371,1511,1841,4021,4661
PIVA.....	2411,5021
PLANAR.....	4251
POLAROID.....	5541,2401
.....	4631,0191,5411,1961,0581
.....	6101,2271,2311,2451,5131
PORTLAND.....	0001
.....	0251,1011,1081,1221,1551
PRECISION.....	0621
PRIMA.....	0381
.....	0581,0631,0871,2451
PRINCETON GRAPHICS.....	1301,1441
PROSCAN.....	5421
.....	5781,4191,0221,1651
.....	1731,2131,2141,2361,2371
.....	2381,0261,2061,2301,4011
PROTON.....	0001,0391,0641,1221
.....	1911,2231,4211,4221,4271
PROTRON.....	3731,4301
PROVIEW.....	2401,2421,2431
PULSAR.....	0001,1771,1781
PVLE.....	3331
QUASAR.....	3551,1091,0051,1491
.....	1571,3451,2151,3431,5201
RADIO SHACK.....	0001,0341
.....	0931,1001,1221,1571,1701
.....	1911,1941,2191,4731,4921
RCA.....	2361
.....	1001,0131,4921,2481,1731
.....	0001,3431,2121,2371,2131
.....	2381,2141,1521,3571,2011
REALISTIC.....	0001
.....	0341,0931,1001,1221,1571
.....	1701,1911,1941,2191,4731
ROKU TV.....	6171,6001
RUNCO.....	1771,1781,1841
SAMPO.....	0001,0121
.....	0391,0501,1221,1911,4221
SAMSUNG.....	5791,5801,3301
SAMTRON.....	0351
SANSUI.....	5411,0211,1381

.....	2891,5241,5851,5861,5871
.....	6051,6061,6071,1631,5551
SANYO.....	1161,5261,2891,5251
SCEPTRE.....	3521,4071,5111
SCOTCH.....	0001,1221
SCOTT.....	3215,0001,0021,0281
.....	1221,1711,1941,2191,5141
SEARS.....	0001,0211,0261,1221
.....	1581,1711,1911,4011,4761
SEIKI.....	1263,5751,6091
SELECTRON.....	2471,2491,2501
SEMP.....	3611
SHARP.....	6001,6011
.....	5341,6171,3191,5941,0001
SHARP (ROKU TV).....	6001
SHARP TRINITRON.....	4105
SIGNATURE.....	1661
.....	1691,2171,3421
SIGNET.....	2811,2821,2861
SILO DIGITAL.....	5881
SKYWORTH.....	0701,0691,6191
SONIC.....	0011
SONY.....	1071
.....	5811,5321,4981,1901,2741
SOUNDESIGN.....	0001
.....	0961,1221,1711,1941,2191
SOVA.....	3631,4431
SOYO.....	4611,5101
SPECTRA.....	1611
SPECTRAVISION.....	2341
SQUAREVIEW.....	0141,1381
STARLITE.....	2191
SUNBRITETV.....	3081,3521
SUPERSCAN.....	4761,1291,2021
SUPERSONIC.....	1421,0241,4701
SUPRA.....	0001,1991
SV2000.....	4761
SVA.....	0671,2101
SYLVANIA.....	1381,2761,0371,4761
.....	3701,0141,0201,0231,0941
.....	0951,0001,0321,0931,0961
.....	1021,1221,1801,1821,4731
SYMPHONIC.....	1381,4761
.....	0141,0021,0931,2191,4731
SYNTAX.....	2431,5151,5161
TATUNG.....	1141,1741,2151,3431
TCL.....	6171
.....	5961,6031,5771,6201
TCL/ROKU TV.....	6171
TECHNICS.....	0051
TECHWOOD.....	0001,0051,1221
TEKNIKA.....	0001
.....	0151,0961,1221,1571
.....	1661,1711,1911,1941,2191
TELERENT.....	1661,1691,3421
TERA.....	0001,0641
TEVION.....	1141
TMK.....	0001,1221
TOSHIBA.....	1311,5531,2691
.....	0211,0341,0821,1571,1801
.....	1841,1911,4891,4941,5081
TRUTECH.....	0141,2461,3821,4551
TVS.....	5241
UNIVERSAL.....	0791,1951
VENTURER.....	3781
VICTOR.....	1481,4121
VIDEOCON.....	4061
VIDTECH.....	0001,0251,1221
VISIONSONIC.....	3751,1171,1411
.....	5301,0501,1981,3801,4281
VIORE.....	5431,1421
.....	1881,2141,2831,2841,3681
VISTEON.....	3411

VIZIO.....	5631,5611,5561,6121
.....	6131,6111,5651,5621,5711
WARDS.....	0001,0021
.....	0321,0341,0791,0961,1021
.....	1221,1321,1661,1711,1951
WESTINGHOUSE.....	5781
.....	5971,5981,3241
.....	1891,2141,0111,2281
WHITE-WESTINGHOUSE.....	5241
.....	0601,0931,1501
.....	1521,1551,4731
YAMAHA.....	0001
.....	0251,1221,1571,3551
ZENITH.....	6021
.....	5281,1181,0001,1781,0061
.....	0931,1031,1221,1251,1631
.....	1661,2171,2291,3501,4321
.....	4731,4751,4791,4941,5211

DVD	
ALPSONIC.....	3135
AIWA.....	0235,3285,3565
AKAI.....	4255
ALLEGRO.....	3725,3885
AMES.....	1275
AMW.....	0645,0825
ANABA.....	1375
APEX.....	1025,1405
.....	0245,0045,0425,0615,0845
.....	0945,0965,1065,1105,1235
.....	1245,1675,38

GEMINI.....	0123,0204,0344	.....0703,0783,1633,1753,0094
GENERAL INSTRUMENT (GI).....	1034	.....0344,0424,0474,0494,0554
.....	1864	.....1064,1084,1094,1104,0092
.....	0013,0093,0163,0193,0323	.....0252,1052,1492,1502,1542
.....	0453,0633,0833,0893,0953	PHILIPS-MAGNAVOX..... 0203
.....	0963,1583,1603,0004,0044	.....0533,0783,0064,0104
.....	0074,0314,0374,0514,0594	PINNACLE..... 1493,1823,1833
.....	0634,0794,0814,0884,0894	PIONEER..... 0024,1404,1853,0274
GEOSATPRO.....	2003	.....0614,0924,0532,0985,2855
GLOBECAST.....	0003,1004	POLAROID..... 4561
GO VIDEO.....	1883	PRIMESTAR..... 1253,0323,0633,1563
GOL.....	0173	PROSAT..... 0813,1333
GOLDSTAR.....	0924	PROSCAN..... 0333
HAMLIN.....	0414,0484,0544	.....0643,0723,0803,1383
HITACHI.....	0303	PULSAR..... 0154
.....	1153,0443,0623,1103,0594	QUASAR..... 0154
HNS.....	1153	RADIO SHACK..... 0064
HTB.....	0416	.....0104,0114,0964
HTS.....	0173	
HUGHES.....	0593,1343	
HUGHES NETWORK SYSTEMS.....	0303	
.....	0443,0563,0593,0703,1343	
HUMAX.....	1505	
ILLICO.....	1354,1404,1523	
ILO.....	1035	
INSIGHT.....	1284,1314	
JASCO.....	0474	
JERROLD.....	0004	
.....	0074,0194,0314,0324,0444	
JVC.....	0514,0594,0794,0814,1034	
.....	0433,0783,1145	
KENWOOD.....	0413	
KNOWLOGY.....	1424,1344,1284,1564	
LG.....	0303,1103,1153,2925	
LITEON.....	1035	
LUXOR.....	0503,1653	
MACOM.....	0613	
MAGNAVOX.....	0203	
.....	0533,0783,0094,1064	
MEDIACOM.....	1284,1584	
MEDIA ONE.....	1784,1794	
MEDION.....	1035	
MEMOREX.....	0154	
MICROYAL.....	1423	
MITSUBISHI.....	1534	
.....	0303,0443,0623,1153	
MOTOROLA.....	2093,0374,1283	
.....	0453,1593,1603,1863,0004	
.....	0074,0194,0314,0514,0594	
.....	0634,0684,0794,0814,0824	
.....	0844,0884,0894,0914,1034	
MOVIE TIME.....	0224,1074	
MOXI.....	1274	
MYRIO.....	1884	
NEOSAT.....	1413	
NET.....	1543,1713	
NEW WAVE.....	1274	
NORSTAT.....	0683	
NOVAPLEX.....	0834,0854	
NOWTV.....	1473	
NSC.....	0224,1074	
OAK.....	0144,0354,1054	
OMEGASAT.....	1983	
ONKYO.....	1243	
ORASAT.....	1973	
ORION.....	1523	
PACE.....	0053,0133,1363,1593,1673	
PANASONIC.....	0213,0223,0304	
.....	0394,0954,1014,0545,1272	
PANSAT.....	1993,0033,0883,1403	
PARAGON.....	0154,0284	
PHILIPS.....	0203	
.....	0303,0443,0533,0623	

**CBL SAT DVR  
Cable\_Satélite\_DVR**

RCA.....	0416,0333,0363,0543,0643	
.....	0723,0803,1373,1383,1873	
.....	0244,0394,0474,1014,0915	
RCN.....	0824,0514	
REALISTIC.....	0273,0843,1643,0334	
REGAL.....	0544	
REGENCY.....	0214	
REMBRANDT.....	0594	
REPLAYTV.....	1272	
ROGERS.....	1344,1404,1523	
RUNCO.....	0154	
SAMSONIC.....	1433	
SAMSUNG.....	1213	
.....	0043,0233,1113,1123,1763	
.....	2671,0014,0024,0924,4451	
SCIENTIFIC ATLANTA.....	0498	
.....	1203,0124,1324,1364,1404	
.....	1523,1444,1454,1464,1474	
.....	1484,1494,1414,0134,0164	
.....	0234,0574,0714,0834,0864	
SEIKI.....	1263	
SHARP.....	1853	
SHAW.....	1524,0514	
SHAW DIRECT.....	2734	
SIERRA I II III.....	0653	
SIGNAL.....	0014	
SIGNATURE.....	0594	
SKY NETWORK.....	0053	
.....	0133,1363,1593	
.....	1673,1743,1753,1783,1793	
SL MARX.....	0014	
SONIC BLUE.....	1272	
SONY.....	0113,0353,0773	
.....	1162,1302,2865,2985,3055	
SPRUCER.....	0394,1014	
STANDARD.....	0364	
STAR SIGHT.....	0863,0244	
STAR TRAK.....	0423,0184	
STAR CHOICE.....	2734	
.....	0163,0323,0633,1563,1583	
STARCOM.....	0314	
STARGATE.....	0014	
STS.....	0383,0583,0663	
SUDDENLINK.....	1774	
SUPER GUIDE.....	0513	
SUREWEST.....	1854,1954	
SYLVANIA.....	1903	
TANDY.....	0974	
TELEVIEW.....	0014	
TELSAT.....	1723	
TELUS.....	1943	

TEXSCAN.....	0364	
THOMSON.....	1834,0803,1753	
TIME WARNER.....	1254,0824	
.....	1424,1404,0514,0694,1523	
TIVAX.....	1293	
TIVO.....	1223,0704,0754,0764,0092	
.....	0252,0353,0985,1052,1162	
.....	1492,1502,1505,1542,1745	
TOCOM.....	0004	
.....	0444,0504,0634,0934,1034	
TOSHIBA.....	0063,0143,0303,0443	
.....	0623,0713,0743,0973,1133	
.....	0154,1735,1745,2145,3325	
TV86.....	0224,1074	
TVA.....	1703	
ULTIMATE TV.....	0333,0553,0873	
UNIDEN.....	0693,0823,0863	
UNIKA.....	0264,0334,0474	
UNITED.....	1663	
UNIVERSAL.....	0054,0264	
.....	0334,0474,0564,0944,1044	
VERIZON.....	1283,2033	
.....	1404,0684,0824,1523,0514	
VIDEO CIPHER II.....	0023	
VIDEO TECH.....	0454	
VIDEOTRON.....	1404,1523,1574	
VIDEOWAY.....	0034	
VIEWSAT.....	1803	
VIEWSTAR.....	0084	
.....	0094,0224,0974,1064,1074	
VISIONETICS.....	1483	
VISIONTEC.....	1693	
VOOM.....	2734,2971	
V-TECH.....	1813	
WEB TV.....	0113,0783	
WIDOPENWEST.....	1153	
WOW.....	1964	
X-FINITY.....	1544	
ZENITH.....	0023	
.....	0123,0153,0253,0293	
.....	0313,0733,1593,0114,0154	
.....	0474,0524,0584,0624,0644	
ZENITH NETWORK.....	0254	
ZINWELL.....	2013	

**Digital Converter Box  
Decodificadores Digitales**

ACCESS HD.....	2184,1234	
ADB.....	2194,2614,2624,2644,2664	
AIRLINK 101.....	2344,1174	
ALPHA DIGITAL.....	2184,1234	
AMINO.....	2294,2574,2634	
AMTC.....	2184,1234	
APEX.....	1114	
ARRIS.....	2514	
ARTEC.....	2334	
AT&T.....	2594	
CASIO.....	2244	
CASTI.....	2224	
CHANNEL MASTER.....	2264	
.....	2464,1204	
CINCINNATI BELL.....	2534	
CISCO.....	2424,2434,2454,2594,2674	
COBY.....	2384	
COMCAST.....	2424	
CONFLUENT.....	2554	
COSHIP.....	2314	
DAEWOO.....	2234	
DIGITAL STREAM.....	2214,2704,1194	
DISH NETWORK.....	0073	
ECHOSTAR.....	0073	
EVOLUTION.....	2504,2724	

GE (GENERAL ELECTRIC).....	2284,0874	
GOODMIND.....	2284,0874	
GRIDLINK.....	1144,2254	
HOMECAST.....	2444	
iNet ACCESS.....	1234	
INSIGNIA.....	2174,1184	
KOOLCONNECT.....	2714	
LASONIC.....	1144	
LG.....	2174	
MAGNAVOX.....	2941	
MEMOREX.....	2304	
MICROGEM.....	2324,1154	
MINERVA.....	2484	
MOTOROLA.....	2604	
MOXI.....	2474	
MYRIO.....	2614,2624	
NBOX.....	2494	
NEGRAVISION.....	2564	
NOW TV.....	2654	
PACE.....	2424,2434	
PHILCO.....	2941	
RCA.....	2834,2404,2414	
ROKU.....	2274	
SAMSUNG.....	2434	
SANSONIC.....	1144	
SCIENTIFIC ATLANTA.....	2244	
.....	2434,2594	
SKARDIN.....	1174	
Sling Media.....	2364	
SUDDEN LINK.....	2694	
SUNKEY.....	2394	
TECHNICOLOR.....	2424,2684	
THOMPSON.....	2424,2684	
TIVAX.....	2184,1234	
TRANSPARENT VIDEO SYSTEM.....	2524	
VENTURER.....	1164	
VUDU.....	2204	
WEGENER.....	2584	
WESTERN DIGITAL.....	2354	
WINEGARD.....	1164	
XFINITY.....	2544	
ZENITH.....	2174,1184	
ZENTECH.....	2344,1174	
ZINWELL.....	1124	

**HDTV Set Top Boxes  
Aparatos decodificadores para HDTV**

APEX.....	2911	
DIRECTV.....	1443,1513,1533	
GE (GENERAL ELECTRIC).....	0874	
GO VIDEO.....	2631	
HITACHI.....	1103,2661	
HUGHES.....	0303	
.....	1103,1153,2591,2651,2661	
INSIGNIA.....	2921	
KWORLD.....	2931	
LG.....	0303	
.....	1103,1153,2591,2651,2661	
MITSUBISHI.....	1103,2661	
MOTOROLA.....	2601	
PHILCO.....	2941	
PHILIPS.....	1103,2661	
PIONEER.....	2561	
PROSCAN.....	0803,2581	
RCA.....	2951,0803,2581,0803,2611	
SAMSUNG.....	2671,1143,1123,2621	
SONY.....	2681	
SYLVANIA.....	2641,2941	
TOSHIBA.....	0303	

.....	1153,2591,2651,0303	
VENTURER.....	1164	
ZENITH.....	1173,2571	

**TV/DVD COMBO  
Combinación TV/DVD**

ADVENT.....	1515	
AKAI.....	[3215 & 3285]4461	
AUDIOVOX.....	[4031 & 4481]	
.....	[4051 & 1135]4521	
AXION.....	[0881 & 1335]	
BROKSONIC.....	0015,0211	
COBY.....	3475	
DAEWOO.....	[1561 & 0065]	
DIAMOND VISION.....	[1611 & 0855]	
.....	0455	
DURABRAND.....	[2291 & 3885]0205	
EMERSON.....	0412,0445	
FUNAI.....	0412,0445	
GPX.....	0135	
HAIER.....	0315,1257	
ILO.....	[3215 & 3285]1945	
INITIAL.....	0994,1945,2735	
INSIGNIA.....	[1241 & 0285]	
.....	[2891 & 3335]	
.....	0412,0445,2805,2815,3305	
JVC.....	1685,3015	
KAWASAKI.....	0325	
KONKA.....	1425,1605	
LASONIC.....	[1611 & 0855]	
LIQUIDVIDEO.....	[0881 & 1335]	
MAGNAVOX.....	0445,0552,0412	
MAXENT.....	3361	
MEMOREX.....	0015,0211	
NEXTECH.....	1201,2005	
PANASONIC.....	0412	
.....	0552,0595,1195,1346,3401	
PHILIPS.....	0181,2615,3371	
.....	[1381 & 0702]0412,0445	
PIVA.....	1805	
SANSUI.....	0555,1535	
SAMSUNG.....	0015,0211	
SEARS.....	0015,0211	
SHARP.....	[1291 & 3115]	
SOVA.....	[3631 & 4431]	
SUPERSONIC.....	0135	
SYLVANIA.....	0412	
.....	[1381 & 0702]0445	
SYMPHONIC.....	0412,0445	
TOSHIBA.....	0015,0115,0211,3075	
TRUTECH.....	4551	
WESTINGHOUSE.....	[3711 & 2865]	

**TV/VCR COMBO  
Combinación TV/VCR**

ADMIRAL.....	0302,1682	
AIWA.....	0432,0752	
AKAI.....	0032,1592	
BROKSONIC.....	[0851 & 0462]	
.....	[0851 & 0892]0642,1631	
CURTIS MATHES.....	0652,1522	
DAEWOO.....	1092	
DURABRAND.....	[2291 & 0182]	
ELECTROHOME.....	0032,1592	
EMERSON.....	[0851 & 0462]	
.....	[0851 & 0892]0032	
RCA.....	0192,0232,0332,0432,0942	
.....	1092,1172,1432,1592,1631	
FISHER.....	0602,1712	
FUNAI.....	0432	
GE (GENERAL ELECTRIC).....	1482	

GOLDSTAR.....	0432,1181	
GRADIENTE.....	[2291 & 0182]	
HITACHI.....	0432	
INFINITY.....	0622	
JVC.....	0452,4201	
LG.....	0432,1181	
LXI.....	0432	
MAGNAVOX.....	0302,0412,0622,1682	
MEMOREX.....	0602,0942,1631,1712	
MITSUBISHI.....	0032,1592	
OPTIMUS.....	0122,1062	
PANASONIC.....	0122,1062	
PHILIPS.....	0412,0622	
PHILIPS-MAGNAVOX.....	0302	
.....	0622,1682	
QUASAR.....	0122,1062	
RADIO SHACK.....	0432,1482	
RCA.....	[1691 & 0242]1482	
REALISTIC.....	0432	
SAMSUNG.....	0652,1522,1535	
SANSUI.....	0942,1631	
SANYO.....	0602,1712	
SHARP.....	0302,0332,1682	
SONY.....	0972,1292,1652	
SYLVANIA.....	0312,0432	
SYMPHONIC.....	0432	
TOSHIBA.....	1402,0652,0902,1522	
WHITE-WESTINGHOUSE.....	0432	
ZENITH.....	[2291 & 0182]0302,0332	
.....	0432,0452,0622,0652,0	