

Part code	Part description
-----------	------------------

No longer available from 1st August 2020

MxPro 4 Fire Control Panels

MxPro 4 Fire Control Panels (Apollo / Hochiki Protocol)

MxPro 4 - 1 Loop panels

MX-4100	1 Loop Fire Panel (No loop driver required)
MX-4100/L	1 Loop Fire Panel with lockable hinged door
MX-4100/LG	1 Loop Fire Panel c/w lockable hinged door & Lexan (perspex) kit

MxPro 4 - 2 Loop panels

MX-4200	1-2 Loop Fire Panel (no loop cards)
MX-4200/D	1-2 Loop Fire Panel in deep enclosure suitable for up to 2 x 38Ah batteries
MX-4200/R	1-2 Loop Fire Panel with 19" mounting bezel (no loop cards)
MX-4200/LE	1-2 Loop Fire Panel in Large Enclosure (950 mm High)
MX-4201	1-2 Loop Fire Panel c/w 1 loop card
MX-4202	1-2 Loop Fire Panel c/w 2 loop cards
MX-4201/D	1-2 Loop Fire Panel c/w 1 loop card in deep enc.
MX-4202/D	1-2 Loop Fire Panel c/w 2 loop cards in deep enc

MxPro 4 - 4 Loop panels

MX-4400	1-4 Loop Fire Panel (no loop cards)
MX-4400/D	1-4 Loop Fire Panel in deep back box for up to 2 x 38Ah batteries
MX-4400/R	1-4 Loop Fire Panel with 19" mounting bezel (no loop cards)
MX-4400/LE	1-4 Loop Fire Panel in Large Enclosure (950 mm High)
MX-4401	1-4 Loop Fire Panel c/w 1 loop card
MX-4402	1-4 Loop Fire Panel c/w 2 loop cards
MX-4403	1-4 Loop Fire Panel c/w 3 loop cards
MX-4404	1-4 Loop Fire Panel c/w 4 loop cards
MX-4401/D	1-4 Loop Fire Panel c/w 1 loop card in deep enc.
MX-4402/D	1-4 Loop Fire Panel c/w 2 loop cards in deep enc.
MX-4403/D	1-4 Loop Fire Panel c/w 3 loop cards in deep enc.
MX-4404/D	1-4 Loop Fire Panel c/w 4 loop cards in deep enc.

MxPro 4 - 8 Loop panels

MX-4800	2-8 Loop Fire Panel with standard network card (No loop cards)
MX-4802	2-8 Loop Fire Panel c/w standard network card & 2 loop cards
MX-4803	2-8 Loop Fire Panel c/w standard network card & 3 loop cards
MX-4804	2-8 Loop Fire Panel c/w standard network card & 4 loop cards
MX-4805	2-8 Loop Fire Panel c/w standard network card & 5 loop cards
MX-4806	2-8 Loop Fire Panel c/w standard network card & 6 loop cards
MX-4807	2-8 Loop Fire Panel c/w standard network card & 7 loop cards
MX-4808	2-8 Loop Fire Panel c/w standard network card & 8 loop cards
MX-4800/FT	2-8 Loop Fire Panel with fault-tolerant network card (No loop cards)
MX-4802/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 2 loop cards

MX-4803/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 3 loop cards
MX-4804/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 4 loop cards
MX-4805/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 5 loop cards
MX-4806/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 6 loop cards
MX-4807/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 7 loop cards
MX-4808/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 8 loop cards

MxPro 4 Series Fire Control Panels (AV or Nittan Evolution Protocol)

MxPro 4 - 2 Loop V and N Series panels

MX-4201V	1-2 Loop Fire Panel c/w 1 loop card
MX-4202V	1-2 Loop Fire Panel c/w 2 loop cards
MX-4201V/D	1-2 Loop Fire Panel c/w 1 loop card in deep enc.
MX-4202V/D	1-2 Loop Fire Panel c/w 2 loop cards in deep enc.
MX-4201V/R	1-2 Loop Fire Panel c/w 1 Loop card with 19" mounting bezel
MX-4202V/R	1-2 Loop Fire Panel c/w 2 Loop cards with 19" mounting bezel
MX-4201V/LE	1-2 Loop Fire Panel c/w 1 loop card in Large enc.
MX-4202V/LE	1-2 Loop Fire Panel c/w 2 loop cards in Large enc.

MxPro 4 - 4 Loop V and N Series panels

MX-4401V	1-4 Loop Fire Panel c/w 1 loop card
MX-4402V	1-4 Loop Fire Panel c/w 2 loop cards
MX-4403V	1-4 Loop Fire Panel c/w 3 loop cards
MX-4404V	1-4 Loop Fire Panel c/w 4 loop cards
MX-4401V/D	1-4 Loop Fire Panel c/w 1 loop card in deep enc.
MX-4402V/D	1-4 Loop Fire Panel c/w 2 loop cards in deep enc.
MX-4403V/D	1-4 Loop Fire Panel c/w 3 loop card in deep enc.
MX-4404V/D	1-4 Loop Fire Panel c/w 4 loop cards in deep enc.
MX-4401V/R	1-4 Loop Fire Panel c/w 1 Loop card with 19" mounting bezel
MX-4402V/R	1-4 Loop Fire Panel c/w 2 Loop cards with 19" mounting bezel
MX-4403V/R	1-4 Loop Fire Panel c/w 3 Loop cards with 19" mounting bezel
MX-4404V/R	1-4 Loop Fire Panel c/w 4 Loop cards with 19" mounting bezel
MX-4401V/LE	1-4 Loop Fire Panel c/w 1 loop card in Large enc.
MX-4402V/LE	1-4 Loop Fire Panel c/w 2 loop cards in Large enc.
MX-4403V/LE	1-4 Loop Fire Panel c/w 3 loop cards in Large enc.
MX-4404V/LE	1-4 Loop Fire Panel c/w 4 loop cards in Large enc.

MxPro 4 - 8 loop V and N Series panels

MX-4802V	2-8 Loop Fire Panel c/w standard network card & 2 loop cards
MX-4803V	2-8 Loop Fire Panel c/w standard network card & 3 loop cards
MX-4804V	2-8 Loop Fire Panel c/w standard network card & 4 loop cards
MX-4805V	2-8 Loop Fire Panel c/w standard network card & 5 loop cards
MX-4806V	2-8 Loop Fire Panel c/w standard network card & 6 loop cards
MX-4807V	2-8 Loop Fire Panel c/w standard network card & 7 loop cards
MX-4808V	2-8 Loop Fire Panel c/w standard network card & 8 loop cards
MX-4802V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 2 loop cards
MX-4803V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 3 loop cards
MX-4804V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 4 loop cards
MX-4805V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 5 loop cards
MX-4806V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 6 loop cards
MX-4807V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 7 loop cards
MX-4808V/FT	2-8 Loop Fire Panel c/w fault-tolerant network card & 8 loop cards

MxPro 4 Loop Drivers

MXP-002	Loop driver for MX-4400 /4200 (Apollo or Hochiki protocol)
MXP-067	Loop driver for MX-4400 /4200 (Nittan Evolution protocol)
MXP-069	Loop driver for MX-4400 /4200 (AV protocol)

MxPro 4 Series Remote Terminals

MX-4010	Remote Display Terminal with standard network interface, 24V DC
MX-4020	Remote Control Terminal with standard network interface, 24V DC
MX-4010/FT	Remote Display Terminal with fault-tolerant network interface, 24V DC
MX-4020/FT	Remote Control Terminal with fault-tolerant network interface, 24V DC

MxPro 4 Network Cards

MXP-003F	Standard Network Card / Fitted **
MXP-003	Standard Network Card
MXP-009F	Fault Tolerant Network Card / Fitted **
MXP-009	Fault Tolerant Network Card

* Fitted to a Mx-4100, Mx-4200 or Mx-4400

MxPro 4 Zonal LED Indication

MXP-024F	20 Zone LED card for Mx-4100 / Fitted **
MXP-024	20 Zone LED card for Mx-4100
MXP-025	20 Zone LED card for Mx-4200 /4400 /4800
MXP-025F	20 Zone LED card for Mx-4200 /4400 /4800 / Fitted **
MXP-013-050F	50 zone LED card for Mx-4200 /4400 /4800 / Fitted
MXP-013-050	50 zone LED card for Mx-4200 /4400 with door & label (Retro-fit)
MXP-013-100F	100 zone LED card for Mx-4200 /4400 /4800 / Fitted
MXP-013-100	100 zone LED card for Mx-4200 /4400 with door & label (Retro-fit)
MXP-013-200F	200 zone LED card for Mx-4200 /4400 /4800 / Fitted
MXP-013-200	200 zone LED card for Mx-4200 /4400 with door & label (Retro-fit)
MXP-055F	36 Zone Slide-in label and LED card for Mx-4200D/ 4400D (Requires Mimic interface and network card)

** 20 Zone card cannot be fitted with an onboard printer.

MxPro 4 Series Printers

MXP-012F	On-board printer for Mx-4200 /4400 /4800 / Fitted *
MXP-012	On-board printer for Mx-4200 /4400 /4800 (Retro-fit)
MXP-012-BX	External boxed panel printer for Mx-4100 /4200 /4400 /4800
MXS-014	Spare shrink wrap battery pack for Mxp-012 printer
MXS-008	Spare paper roll for Mxp-012 printer (pack of 10)
MXP-056	Mimic/network printer Interface card
MXP-056F	Mimic/network printer Interface card **
MXP-056/FT	Fault-tolerant mimic/network printer interface card
MXP-056F/FT	Fault-tolerant mimic/network printer interface card / Fitted **

* Onboard printer cannot be fitted with a 20 Zone LED card. ** to a Mx-4200D or Mx-4400D only

MxPro 4 Input & Output Cards

MXP-007F	2-way programmable relay output card for Mx-4100L / Fitted
MXP-007	2-way programmable relay output card for Mx-4100L
MXP-008	8-way programmable relay output card for Mx-4200 /4400 /4800
MXP-008F	8-way programmable relay output card for Mx-4200 /4400 /4800 / Fitted
MXP-014F	8-way programmable input card for Mx-4100L/ 4200/ 4400/ 4800 / Fitted
MXP-014	8-way programmable input card for Mx-4100L/ 4200/ 4400/ 4800
MXP-029	Shop Interface Unit (input/output card) for Mx-4100L /4200/ 4400/ 4800
MXP-029F	Shop Interface Unit (input/output card) for Mx-4100L /4200/ 4400/ 4800 / Fitted

MxPro 4 P-Bus Expansion cards

MXP-031	Peripheral Bus Interface Adaptor
MXP-031F	Peripheral Bus Interface Adaptor / Fitted
MXP-032	Peripheral Bus - Fire alarm routing interface card (monitored output card)
MXP-032F	Peripheral Bus - Fire alarm routing interface card (monitored output card) / Fitted

* Add F - for fitted to a Mx-4200, Mx-4400 or Mx-4800.

MxPro 4 Modem & Pager Interface

MXP-047	ESPA Pager interface
MXP-047F	ESPA Pager interface / Fitted *
MXP-028-BX	Modem card (24V) boxed
MXP-028F	Modem card (24V) / Fitted
MXP-028	Modem card (24V)

* Add F - for fitted to Mx-4200 /4400 /4800

MxPro 4 Key Switches

MXP-011	Access enable key switch assembly
MXP-011F	Access enable Key switch assembly - Fitted
MXP-018	Access enable key switch assembly for RDT / RCT
MXP-018F	Access enable key switch assembly for RDT / RCT - Fitted
MXP-015	8-way key switch input card & cable **
MXP-016	2-Position key switch assembly - trapped
MXP-016F	2-Position key switch assembly - trapped. Fitted
MXP-017	2-Position key switch assembly - untrapped
MXP-017F	2-Position key switch assembly - untrapped. Fitted
MXS-015	3-Position key switch assembly c/w 2 flying leads
MXS-015F	3-Position key switch assembly c/w 2 flying leads - Fitted

* Add F - for fitted ** Accepts up to 8 key switches Mxp-016 / Mxp-017 or 4 x Mxs-015

MxPro 4 Mounting Bezels

MXM-001	Semi-flushing bezel for Mx-4100
MXM-002	Semi-flushing bezel for Mx-4200 / Mx-4400
MXM-008	Semi-flushing bezel for Mx-4010 / Mx-4020
MXM-032	Semi-flushing bezel for Mx-4800
MXM-037	Semi-flushing bezel for Mx-4100/L

MXM-048	Semi-flushing double bezel for 2 multi-loop panels side-by-side
MXM-054	19" rack mounting bezel (6U high) for a 50, 100 or 200 zone LED card
MXM-054F	19" rack mounting bezel (6U high) for a 50, 100 or 200 zone LED card / Fitted
MXM-054-001	19" rack mounting bezel (300mm) for a 50,100, 200 zone LED card
MXM-054-001F	19" rack mounting bezel (300mm) for a 50,100, 200 zone LED card / Fitted
MXM-057	Spare 19" Rack mounted adaptor plate for Mx-4400 chassis

MxPro 4 Lexan (Plexi glass) Door Kits

MXM-007	Lexan Door kit for Mx-4200 / Mx-4400
MXM-007F	Lexan Door kit for Mx-4200/Mx-4400
MXM-007F	Lexan Door kit for Mx-4200/Mx-4400 - Fitted
MXM-041	Lexan Door kit for Mx-4800
MXM-041F	Lexan Door kit for Mx-4800 / Fitted
MXM-059	Full Lexan deep over door kit for Mx-4200 / Mx-4400
MXM-059F	Full Lexan deep over door kit for Mx-4200 / Mx-4400 - Fitted
MXM-059-001	Full Lexan deep over door kit with alternate key for Mx-4200 / Mx-4400
MXM-059-001F	Full Lexan deep over door kit with alternate key for Mx-4200 / Mx-4400 - Fitted

** Add F - for fitted For MXM-041F*, replace * with 001 for c/w Printer cut-out with 002 for c/w Printer cut-out and Key switch or 003 for c/w Key switch cut-out*

MxPro 4 Enclosures, blanking plates and spare doors

MXM-018	Spare back-box for Mx-4100
MXM-018-002	Spare back-box for Mx-4100 without transformer
MXM-038	Spare back-box for Mx-4100/L without transformer
MXM-017	Spare back-box for Mx-4200 / Mx-4400
MXM-020	Spare deep back box for Mx-4200 / Mx-4400
MXM-042	Spare back-box for Mx-4800
MXM-030	Spare back-box for Mx-4010 / Mx-4020
MXM-058	Spare deep back box for Mx-4010 / Mx-4020
MXM-019	Utility enclosure matching Mx-4200 / Mx-4400
MXM-019-D	Deep Utility enclosure matching Mx-4200 / Mx-4400 /d
MXM-052	Utility enclosure matching Mx4100/L
MXM-028	Termination Enclosure - 1-4 Loop Panel
MXM-029	Termination Enclosure - 1-8 Loop Panel
MXM-043	Document Enclosure
MXM-061	Large Document Enclosure
MXM-046	Spare Mx-4100/L enclosure and door
MXM-040	Spare enclosure c/w door for Mx-4200 / Mx-4400
MXM-044	Spare enclosure for Modem or BMS Interface
MXM-049	Spare Lid for Mx-4100
MXM-039	Spare door for Mx-4100/L
MXM-047	Spare door for Mx-4200 / Mx-4400
MXM-047-001	Spare door (double aperture) for Mx-4200 / Mx-4400
MXM-031	Blanking Plate for lower aperture on Mx-4200 / Mx-4400 door
MXM-053	Spare blank deep panel door c/w lock for Mx-4400
MXM-053F	Blank deep panel door for Mx-4200 /4400 - fitted
MXM-045	Spare Lid for Mx-4010 / 4020
MXM-050	Spare door for Mx-4800

MXM-051

Spare upper aperture blanking plate for Mx-4800 enclosure

MXM-060

Spare Mx-4800 Enclosure assembled

MxPro 4 Special Finishes

MXM-009F

Stainless Steel door for Mx-4400 / Mx-4200 - Fitted

MXM-009-001F

Stainless Steel door (double aperture) for Mx-4400 / Mx-4200 - Fitted

MXM-010

Stainless Steel bezel for Mx-4400 / Mx-4200

MXM-011F

Chrome door for Mx-4200 / Mx-4400 - Fitted

MXM-011-001F

Chrome door (double aperture) for Mx-4200 / Mx-4400 - Fitted

MXM-012

Chrome bezel for Mx-4200 / Mx-4400

MXM-013F

Chrome door for Mx-4100 - Fitted

MXM-014

Chrome bezel for Mx-4100

MXM-015F

Stainless Steel door for Mx-4100 - Fitted

MXM-016

Stainless Steel bezel for Mx-4100

MXM-021F

Chrome Door for Mx-4010 / Mx-4020 - Fitted

MXM-022

Chrome bezel for Mx-4010 / Mx-4020

MXM-023F

Stainless Steel Door for Mx-4010 / Mx-4020 - Fitted

MXM-024

Stainless Steel bezel for Mx-4010 / Mx-4020

MXM-055F

Stainless Steel door for Mx-4100/L - Fitted

MXM-056

Stainless Steel bezel for Mx-4100/L

MxPro 4 Spares

MXS-050

Spare 24V 3A EN54-4 Psu & Battery Charger card

MXS-008

Spare paper roll for Mxp-012 printer (pack of 10)

MXS-001

Spare Mx-4100 Single loop base card

MXS-002

Spare Mx-4200 1 - 2 loop base card

MXS-002V

Spare Mx-4200 1 - 2 loop base card / AV Protocol

MXS-002N

Spare Mx-4200 1 - 2 loop base card / Nittan Evolution Protocol

MXS-003N

Spare Mx-4400 1 - 4 loop base card / Nittan Evolution Protocol

MXS-003

Spare Mx-4400 1 - 4 loop base card

MXS-003V

Spare Mx-4400 1 - 4 loop base card / AV Protocol

MXS-004

Spare Mx-4000 Graphic Display Card

MXS-005

Spare power supply unit for Mx-4400

MXS-006

Spare power Supply Unit for Mx-4200

MXS-009-050

Spare 50 zone LED card

MXS-009-100

Spare 100 zone LED card

MXS-010

BMS/Graphics Network Interface Card

MXS-011

Spare panel door key

MXS-012

Spare access enable key

MXS-013

Spare panel lock and key

MXS-021

4-way Sounder Splitter card

MXS-024

20 Zone LED Card (Pcb only)

MXS-025

5A Sounder booster card

MXS-027

Local 100 Zone mimic driver card

MXS-028

Spare peripheral fault tolerant Network Interface

MXS-029

Spare 10-way earthing block for Mx-4200 /Mx-4400 /Mx-4800

MXS-034

2-way pluggable lead for key switch input card

MXS-030

Non-illuminated push button + 450mm long 2-way cable

MXS-030-R	Illuminated (red) push button + 450mm long 2-way cable
MXS-030-G	Illuminated (green) push button + 450mm long 2-way cable
MXS-038-550	20-way ribbon cable 550mm
MXS-038-650	20-way ribbon cable 650 mm
MXS-038-320	20-way ribbon cable 320mm
MXS-039-550	Cable, 2-way plug to plug 550mm
MXS-039-320	Cable, 2-way plug to plug 320mm
MXS-039-650	Cable, 2-way plug to plug 650mm
MXS-049	Spare 24V 1.5A EN54-4 Psu & Battery Charger card
MXS-051	Spare 24V 5A EN54-4 Psu & Battery Charger card
MXS-055	Spare key for Mxm-059-001 Lexan door kit (alternate key)
MXS-056	Spare lock & key for Mxm-059-001 Lexan door kit (alternate key)
MXS-057	Spares kit for MX-4200 / MX-4400
MXS-058	Spare Transformer Assembly for Mx-4100