

TEKTRONIX®

This insert is provided as a supplement to the instruction manual furnished with this modified instrument. The information given in this insert supersedes that given in the manual.

This insert material Copyright © 1985 by Tektronix, Inc., Beaverton, Oregon. Printed in the United States of America. All rights reserved. Contents of this insert may not be reproduced in any form without permission of the copyright owner.

**PS 503A
MOD FF**

MODIFICATION INSERT

DESCRIPTION

This manual insert describes MOD FF as it applies to the Tektronix PS 503A Dual Power Supply plug-in unit. MOD FF provides a front-panel control for adjustment of the +5 V supply by + or -0.5 V. The front-panel control allows fixed or variable operation of the +5 V supply by means of a push-in/pull-out switch integral to the control knob.

CHARACTERISTICS

Regulator

MOD FF removes three-terminal regulator U1 from Main circuit board assembly A1 and replaces it with an adjustable regulator circuit on a new circuit board assembly, A2 Adjust. Regulator output voltage is determined by the ratio of R251, plus either R253 or R255 (depending on the position of S255 PULL-TO-ADJUST), to R250.

The regulator output voltage can be calculated with the following equation:

$$V_{OUT} = 1.25 \text{ volts} (1 + ((R251 + R_{VAR})/R250))$$

The values chosen for R250 and R251 assure a minimum adjustment range of $\pm 10\%$ under all conditions. Different adjustment limits may be set by selecting other values for R250 and R251.

Front Panel Control

The front-panel control provided by MOD FF is located to the left of the +5 V supply ground connector. The control has dual functions; a push-in/pull-out switch to select FIXED or VARIABLE +5 V supply operation and a variable control for the +5 V supply when VARIABLE mode has been selected.

FIXED Mode

With S255 of the front-panel +5 V ADJ control pushed in, the +5 V supply output is fixed as in a standard instrument. MOD FF does, however, provide internal adjustment R253 on the A2 Adjust circuit board assembly for adjustment of the +5 V supply.

VARIABLE Mode

With S255 of the front-panel +5 V ADJ control pulled out, the +5 V supply output is adjustable from $\leq +4.5 \text{ V}$ (control full counterclockwise) to $\geq +5.5 \text{ V}$ (full clockwise).

PERFORMANCE CHECK

Perform the Performance Check Procedure as given in Section 2 of the Instruction Manual with the following changes:

7. Check +5 Volt Output Voltage

The front-panel +5 V ADJ control must be pushed in for FIXED operation.

9. Check Variable Current Limiting

Do not perform steps n and o.

10. Check +5 Volt Adjustment Range

Add the following new procedure:

- a. Connect the digital voltmeter between the +5 V @ 1A red and white binding posts.
- b. Push in the OUTPUT button and pull out the +5 V ADJ knob.
- c. Rotate the +5 V ADJ knob to full counterclockwise.
- d. CHECK—for a meter reading less than +4.50 volts.
- e. Rotate the +5 V ADJ knob to full clockwise.
- f. CHECK—for a meter reading greater than +5.50 volts.

g. Connect a 5 Ω load resistor between the +5 V @ 1A binding posts.

ADJUSTMENT

Add the following step to the Instruction Manual Adjustment Procedure:

h. Repeat steps c through f.

i. Turn the power off to the TM 500-Series Power Module. Disconnect the 5 Ω load resistor and the digital voltmeter. Push and release the OUTPUT button, push in the +5 V ADJ and the VOLTS DUAL TRACKING knobs, and set all front-panel controls full counterclockwise.

j. This completes the Performance Check Procedure for PS 503A MOD FF.

2. Adjust +5 Volt FIXED Voltage

- CHECK—that the +5 V ADJ knob is pushed in.
- Connect the digital voltmeter between the 5 V @ 1A binding posts.
- Set the voltmeter to the 20 volts dc range.
- Adjust R253 (on Adjust circuit board assembly A2) for a reading between +4.75 and +5.25 volts.

REPLACEABLE ELECTRICAL PARTS LIST CHANGES

ADD:

A2 037-6369-00 CKT BOARD ASSY:ADJUST

Assembly A2 consists of the following components:

C250	290-0974-00	CAP.,FXD,ELCTLT:10 UF,20%,50 VDC
C251	285-1189-00	CAP.,FXD,MTLZD:0.1 UF,5%,100 V
R250	321-0079-00	RES.,FXD,FILM:64.9 OHM,1%,0.125 W
R251	321-0112-00	RES.,FXD,FILM:143 OHM,1%,0.125 W
R253	311-1858-00	RES.,VAR,NONWW:TRMR,100 OHM,0.5 W,LINEAR

Front-panel +5 V ADJ control consists of the following components:

R255	037-0084-00	RES. VARIABLE:100 OHM,10%,LINEAR
S255	_____	(PART OF R255)

CHANGE TO:

U1 156-1161-00 MICROCKT,LINEAR:VOLTAGE REGULATOR,POS,ADJ,LM317T

REPLACEABLE MECHANICAL PARTS LIST CHANGES

ADD:

<u>TEK</u> <u>P/N</u>	<u>QTY.</u>	<u>DESCRIPTION</u>
		Part of A2 Assembly
131-0589-00	4	TERMINAL,PIN:0.46 L X 0.025 SQ,PH,BRZ GLD PL
166-0024-00	1	SPACER,SLEEVE:0.125 L X 0.125 ID,AL
210-0586-00	2	NUT,PL,ASSEM WA:4-40 X 0.25,STL CD PL
210-1171-00	1	WASHER,SHLDR:0.12 ID X 0.143 OD X 0.07 D,NYL
211-0038-00	1	SCREW,MACHINE:4-40 X 0.312,FLH,100 DEG,STL CD PL
211-0114-00	1	SCREW,MACHINE:4-40 X 0.438,FLH,100 DEG,STL CD PL
333-2925-01	1	PANEL,FRONT:PS 503A,MOD FF
337-3036-01	1	SHIELD,ELEC:FRONT SUBPANEL,PS 503A,MOD FF
342-0355-00	1	INSULATOR,PLATE:TRANSISTOR,SILICONE RUBBER
386-4864-01	1	SUBPANEL,FRONT:MOD FF

WIRE KIT CHANGES

	TEK P/N	QTY.	DESCRIPTION
ADD:			
	034-3244-00	1	CA ASSY,SP,RIBBON:4 COND,7.5 L,W/CONNECTORS ONE END
	175-0826-00	2	CABLE,SP,ELEC:3,26AWG,STRD,PVC,JKT,RBN

ACCESSORIES CHANGES

	TEK P/N	QTY.	DESCRIPTION
ADD:			
	061-3171-00	1	INSERT,MANUAL:PS 503A MOD FF

