

# BINNUNE

## BINNUNE WIRELESS GAMING HEADSET



# CONTENTS

<b>BINNUNE Gaming Device</b>	<b>Home</b>
a. Info and Table of contents	3
b. Product overview	4
c. Setup	5-7
Specifications	7
d. Power ON/OFF	8
e. MIC ON/OFF	8
f. Headset Charging	9
g. Trouble shooting	10-11
h. Support	12
<b>Translations</b>	
Deutsch	13-18
Français	19-24
日本語	25-30
Español	31-36
Italiano	37-42
Português	43-48
한국어	49-54

## a. Info and Table of contents

### PACKAGE CONTENTS

BINNUNE BW02 Wireless Gaming Headset

2.4G Wireless Transmitter

User Manual

3.5mm Audio Cable

USB Type-c Charging Cable

### ENGINE REQUIREMENTS

Platforms:

Windows 7 - Windows 10


Mac OS X 10.8 - 10.11

[See page 12 for details](#)


## b. Product overview




- Retractable Headband 08
- Soft Memory Protein Ear Cushions 09
- Unidirectional Microphone 10
- Mic Mute Button 11
- 2.4G Wireless Transmitter
- 3.5mm Audio Cable
- USB Type-c Charging Cable
- Master Volume Wheel
- Power Button
- 3.5mm Audio Port
- USB Type-c Charging port



## c. Setup




## ① Using with PC/Mac in Wireless Mode




1. Open Sound settings
2. Choose your output device BW02
3. Choose your input device 'BW02'
4. BW02 wireless headset can be used.

## ② Using with PS4/PS5 Controller in Wired Mode




## Using with PS4/PS5 Console in Wireless Mode



Route: Settings → Devices → Audio Devices  
Set 'BW02' as Input Device & Output Device

### ③ Using with Xbox Controller in Wired Mode




• Note: Wireless mode is not available for Xbox.

#### Specifications

Model .....	BW02
Headset battery capacity .....	lithium battery 3.7V/1500mA
Working time .....	about 17 hours(70%volume)
Charging time .....	about 4 hours
Standby time .....	about 200 hours
Input charging standard .....	USB Type-C,DC5V/1A
Frequency response .....	20Hz - 20KHz
Sensitivity .....	100±3dB@1KHz
MIC sensitivity .....	-38±3dB@1KHz(Unidirectional)
Wireless Range .....	Up to 32 feet


## d. Power ON/OFF



## e. MIC ON/OFF


On: Microphone On

Off: Microphone Off



Note: On the wired mode, the microphone mute function does not work.

## f. Headset Charging



### Note

- 1.If your headset is disconnected from your devices and no operation is performed for five minutes, your headset wil turn off automatically.
- 2.Insert the 3.5mm audio cable, then the headset turns off and enters the wired mode.
- 3.Low Battery Reminder: When you hear the low battery tone 'battery low' and the red light flashes, please charge the headset in time.

## g. Trouble shooting



### 2.4GHz wireless

The 2.4GHz connection is available on Windows / Mac / PS4 / PS5.



### Charging and Working Time

1. Please charge the headset with 5V/1A standard adapter or via the USB port of PC;
2. Generally, it takes 4 hours to fully charge the headset, but, actual the charging time may vary according to different charging devices;
3. Up to 17 hours working time (at 70% volume) after fully charged.



### The Microphone can not Work

#### **Wireless mode:**

1. Check whether you've set the headset as the default recording device;
2. Check if the microphone has been turned off.

#### **Wired mode:**

1. Make sure the line-in cable has been connected tightly;
2. Please use a converter cable while connecting with PC.



## No Sound or Intermittent Sound from the Headset

1. Check if there are other obstacles which affect the transmitter;
2. If intermittent sound occurs when you are communicating, check whether the network of your device works smoothly;
3. Check whether you've set the headset as the default recording device;
4. Check whether the headset is in lowest volume setting.



## Can't Connect to Devices









1. Check whether you used a USB Extension Cable or USB Hub. It is not recommended.
2. Plug directly into the USB jack of the device's host.
3. Try to replace a USB jack. (Some USB jacks may have power shortage)
4. For PC, it is recommended to plug into the USB jack at the back of the host.

We can't meet all our customers' expectations, but we try to meet it.

[www.binnunetech.com](http://www.binnunetech.com)

[support@binnune.com](mailto:support@binnune.com)

# h.Support

Device		Wireless			Wired		
		Sound	Mic	Mic Mute	Sound	Mic	Mic Mute
PC		✓	✓	✓	✓	✗ (requires splitter adapter not included)	✗
PS5/PS4 Console		✓	✓	✓	✗	✗	✗
Xbox Series X Console		✗	✗	✗	✗	✗	✗
PS5/PS4 Controller		✗	✗	✗	✓	✓	✓
Xbox Series X Controller		✗	✗	✗	✓ (old version requires adapter)	✓	✓
Switch		✗	✗	✗	✓	✓	✗
Cell phone (3.5mm)		✗	✗	✗	✓	✓	✗
Tablet (3.5mm)		✗	✗	✗	✓	✓	✗