

Karaoke Treasure Instructions

I. Buttons Operation

1. "  "

Hold: ON/OFF Press: Mode switching

2. " ^ "

Press: the previous song under MP3 mode.

3. " v "

Press: the previous song under MP3 mode.

4. "  "

Press: Play/Pause. Under FM state, hold it for automatic search

5.  MIC/Replay

Press: Mike ON/OFF

6. " + " Increase volume

7. " - " Decrease volume

II. Wireless Karaoke

1. Supply power: Hold "  " button to start the product.

2. Wireless connection: enable the wireless of mobile phone, click to connect, successful connection if prompt tone is produced.

3. Adjust sound: adjust the sound volume of mike and the reverberation to suitable level.

4. Start Karaoke

III. Recording with mobile phone

1. Connect the recording wire: insert the MICRO plug of the recording wire into the MICRO interface of Karaoke Treasure, and the 3.5mm interface into the earphone jack of the mobile phone.
2. Open the Karaoke software in the mobile phone, such as: USING, Kugou Music or other recording APPS, select your favorable song, record the song according to the above mentioned singing method.
3. Test and save the song: operate according to the instructions of Karaoke software.

Technical Parameters

- Output Power: 3W
- Frequency Range: 100HZ-10KHZ
- Max Sound Pressure Level: >115DB 1KHZ TDH < 1%
- Reverberation Mode: sound effect reverberation
- Power Supply: Built-in 18650 Li-battery
- Battery Capacity: 1200mAh
- Charging Power: DC5V

