



en-GB

At a glance

Let's get started. We'll guide you through start-up and tell you about your phone.

Note: software updates happen frequently, so your phone may look a little different.

SIM & microSD card slots

(under back cover)

Remove the back cover

To insert SIM and memory cards, remove the back cover.

Caution: don't use tools to remove the cover - doing so may damage your phone.

Put in the cards

Your phone might support using two SIM cards.

Caution: make sure you use the correct size SIM cards and don't cut the SIM cards.



Nano SIM

Finish up

to get started.

For phones that use two SIM cards, follow the prompts to set them up.

Put on the back cover. Connect your charger to

charge your phone fully, then turn on the power.

Select your language and follow the screen prompts



read me







One SIM card If your phone uses one SIM card, insert the SIM card first, then insert the optional microSD card. 1. SIM 2. microSD Micro



* Note: To remove SIM 1, slide the lever on the slot.







https://motorola.com/sar. To view additional SAR information on your phone, swipe up A> Settings > Legal information > RF information. www.motorola.com/rfhealth.

motorola.com

70119119-B



Printed in China

To remove SIM 2, push it from the other side of the









Control with one touch

Lock, unlock and navigate your phone and make mobile purchases with just one touch.

- To find lock/unlock settings, swipe up ^> Settings > Security > Fingerprint.
- To find navigation settings, swipe up ^> Moto > Moto Actions > One button nav.

Note: authorising in-store purchases is not available in all areas (NFC and a mobile payment app are both required).

Home screen & settings

From the Home screen, you can explore apps, check notifications, speak commands and more.

- Add a shortcut: swipe up ^, tap and hold an app, then drag it to your home screen.
- Settings: to change your Wi-Fi, display brightness and more, swipe the status bar down with two fingers. To open more settings, tap .
- Share your phone: to add a guest user, swipe the status bar down with two fingers and tap (A).

Discover your Moto app

Find it: O Moto



Explore special features designed to save you time and make your day easier.

- Moto Actions: use gestures as phone shortcuts.
- Moto Display: see your notifications at a glance.

Note: your phone may not have all features.



• Get apps: swipe up ∧ > ▶ Play Store to buy and download apps.

• Everything Moto E4 Plus Edition: get software,

user guides and more at www.motorola.com/

• Help is here: swipe up \wedge > 3 Device Help to get

walk-through tutorials, how-tos or FAQs, right on

News: here's how to find us:

Get answers, updates and info:

Help & more

your phone.

mvmotoe.

- YouTube™ www.youtube.com/motorola
- Facebook™ www.facebook.com/motorola
- Twitter www.twitter.com/moto.
- Soogle+™ www.google.com/+moto

Where is my legal, safety and regulatory information?

In order to provide you with better access to this important information, we've made the materials accessible from the phone's settings menu and on the web. Review these materials prior to using your device. To access the materials from a connected phone, go to Settings > Legal information and select a topic. To access the materials on the web, visit www.motorola.com/device-legal.

Battery safety

Before assembling, charging or using your mobile device for the first time, please read the important product safety and legal information provided with your product.

If your mobile device becomes unresponsive, try a reboot - press and hold the Power button until the screen goes dark and your device restarts.

For your safety, the battery in your mobile device should only be removed by a Motorola-approved service centre or independent qualified professional Don't try to remove or replace the battery yourself - doing so may damage the battery and could cause burning and injury. Don't crush, bend or expose your mobile device to heat or liquid. This may damage the battery and could cause burning and injury. Don't try to dry your mobile device using a microwave oven, conventional oven or dryer.

Warning about high volume usage

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Disposal & recycling

Help do your part! Please don't dispose of mobile devices or electrical accessories (such as chargers, headsets or batteries) with your household waste. Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. For details on approved national recycling schemes and Motorola recycling activities, go to: www.motorola.com/recycling.

Usage

This phone supports apps and services that could use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details. Certain apps and features may not be available in all countries.

Regulatory information

To view the Regulatory ID (such as FCC ID) for this device, on the phone, go to Settings > Legal information > Regulatory information or visit www.motorola.com/device-legal.

Warranty

This product is covered by Motorola's limited warranty. To review the warranty on your phone, go to Settings > Legal information > Warranty or visit www.motorola.com/device-legal. You may also obtain a copy of the warranty by contacting Motorola at: Motorola Mobility LLC, Attention Customer Service - Warranty Request, 222 West Merchandise Mart Plaza, Suite 1800, Chicago, IL 60654.

Arbitration & opt-out

Except where prohibited by law, any controversy or claim arising out of or relating to any Motorola product will be resolved by binding arbitration, instead of in court, unless you opt out. To opt out, send a written rejection notice within 30 days of purchase that includes your name, address, phone number, device and device serial number, and tells Motorola that you are rejecting this arbitration provision to: Motorola Mobility LLC, 222 West Merchandise Mart Plaza, Suite 1800, Attn: Arbitration Provision Opt-Out, Chicago, IL 60654 or arbitrat@motorola.com. For more information on this arbitration provision, on your phone, go to Settings > Legal information > Arbitration and Opt-out or visit www.motorola.com/device-legal.

Legal disclaimers

Certain features, services and applications are network-dependent and might not be available in all areas; additional terms, conditions and/or charges might apply. Contact your service provider for details. All features. functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to correct, change or modify any information or specifications without notice or obligation.

Copyright & trademarks

MOTOROLA, the stylised M logo, MOTO and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. LENOVO is a trademark of Lenovo. Google, Android, Google Play and other marks are trademarks of Google Inc. microSD Logo is a trademark of SD-3C. LLC. All other product or service names are the property of their respective

© 2017 Motorola Mobility LLC. All rights reserved.

Product ID: Moto E4 Plus Edition (Model XT1771) Manual number: 70119119-R

Motorola Mobility LLC 222 W. Merchandise Mart Plaza Chicago, IL 60654 www.motorola.com





or with two fingers for profiles and settings. Touch and hold an empty spot to change widgets, wallpaper and more. Search by typing or say "OK, Google" ■ Swipe up 🔨 to see all vour apps.

▲ 11:35 — Swipe down with one

finger for notifications

4/4/2017 2:30:15 PM Moto E4 Plus GSG en-GB 70119119B.indd 7-12