

reMarkable

reMarkable 2 paper tablet RM110

Designed by reMarkable in Norway - Made in China

www.remarkable.com
Biermannsgate 6 - 0473 Oslo - Norway

TM and © 2017 reMarkable AS - all rights reserved

IC: 22859-RM100
FCC ID: 2AMK2-RM100

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Licensed Open Source Software:

The software included in this product contains copyrighted software that is licensed under the GPL. You may obtain the complete Corresponding Source code from us for a period of three years after our last shipment of this product, which will be no earlier than 2017-08-01, by sending a money order or check for \$5 to the address of reMarkable AS.

Important information

To ensure safe and proper use, please review the user guide (support.remarkable.com) and safety precautions (remarkable.com/legal) before using the device. The reMarkable paper tablet contains a lithium ion battery, active RF transmitters and other electronic components. Do not disassemble the device or try to modify, remove or replace any of the parts, you can permanently damage the device and cause harm to yourself or others. The reMarkable should never be charged with incorrect voltage, or current, the battery may start to burn. Never cover the device with anything when it's charging. Never charge the device at night or when it is out of visible reach. Use only approved batteries / chargers designed for your device. Incompatible batteries / chargers can cause serious injuries or damages to your device. Do not use damaged power cords or plugs. Do not expose your device to high external pressure or temperature. Batteries may explode when overheated.

This product is not designed to be used by small children under five years of age. This product may contain parts small enough that can be inadvertently swallowed and should not be used by children under five years of age.

Keep reMarkable away from prolonged exposure to direct sunlight as it may damage the display and cause cosmetic change to the surface materials. The reMarkable should not be subject to any liquid and is not waterproof. Do not store, operate or charge the device below 5 degrees or above 50 degrees celsius. Contact reMarkable support if you have any questions or concerns.

Do not eat or chew on your reMarkable or any of the accessories. Do not microwave the device. reMarkable is not a rescue flotation device. Do not use your device for anything other than its intended use.



Quick guide

Get started with your reMarkable



reMarkable

Set up

1

Turn on the device by pressing the power button on the top left corner, and follow the instructions on the screen.

2

Create an account at my.remarkable.com on a mobile or desktop device to import and export files to your reMarkable.

3

Download our apps for mobile and desktop to access your files across devices.

Helpfull links

remarkable.com

Find all information about your reMarkable.

my.remarkable.com

See your connected devices and download the supporting apps.

support.remarkable.com

Find all information on using the reMarkable, such as FAQ, user manual, user guides and support information.

remarkable.com/legal

Find safety, warranty and general legal information.