

Quick Start




SAMSUNG
Gear S3 frontier




Preparing for Use

Fully charge before using.



Wireless
charging dock



Get Started

Download App

To connect your Gear S3 and smartphone, install the **Samsung Gear**  app.

Download the **Samsung Gear** app from Galaxy Apps or visit **apps.samsung.com/gear**.

*Compatible with select devices using Android 4.4 and later with at least 1.5 GB RAM. Supported devices may vary by carrier and device. Some features may not be available. For best results, connect with compatible Samsung Galaxy devices. For a list of compatible smartphones, please visit **samsung.com/gearS3**.

Gear S3

① Ensure the Gear S3 is on.

*Smartphone**

② Turn Bluetooth on.

③ Launch Gear app; update app if needed.

④ Tap **CONNECT TO GEAR**.

⑤ Confirm the Bluetooth passkey on both devices, and then tap **OK**.

⑥ Follow the prompts to complete the setup.

Once connected, follow the tutorial to get started.

Customize

From the Smartphone

① Tap **Apps**  > **Samsung Gear**



- Tap **Watch faces** to change the look of the clock.
- Tap **Notifications** to manage your notifications.
- Tap **Apps** to add, remove, and organize apps.
- Tap **Samsung Galaxy Apps** to download and install apps for your Gear S3.

From the Gear S3

① Press and hold the Watch screen, and then rotate the bezel to select a watch face.

② Tap **STYLIZE** to customize the watch face.

Navigate


Moments Bar

View the current status and configure basic settings.

From the Watch screen, swipe down from the top of the screen.




Answer a Call

Rotate the bezel right or swipe right to **Answer** .



Reject a Call

Rotate the bezel left or swipe left to **Reject**  and send the caller to voice mail.



Using the Gear S3 Bezel

Notifications

Rotate the bezel to the left to view notifications.



Apps

Press the **Power/Home** button to open the apps panel.



Widgets

Rotate the bezel to the right to view and add widgets.

Tap + on the last screen to add a widget.



Connection Modes

- **Bluetooth:** Receive notifications and calls from the connected smartphone when in Bluetooth range.
- **Connected remotely:** Connected to the smartphone via the wireless network.

Receive notifications and calls from the smartphone and Gear S3 phone number even when your phone is not near.

- **Standalone:** Not connected to the smartphone.

Send and receive calls and notifications from the Gear S3 phone number only.

AT&T Services

NumberSync

Place and receive calls and texts using your AT&T smartphone number. Tap **Settings > Connections > NumberSync**

Digital Life

The Digital Life app lets you receive alerts and manage your Digital Life home right from your Gear S3.

DIRECTV

Change channels, and schedule recordings using the DIRECTV app.

Data charges apply for Numbersync & app downloads and use. For NumberSync, primary AT&T phone number must be HD Voice-enabled.

Details: att.com/numbersync. DIRECTV DVR and Gear must be on same WiFi network. Digital Life and DIRECTV services sold separately.

Details: att.com/digitallife & att.com/directv.

For More Information

Need More Help?

- On the web:
att.com/DeviceHowTo
att.com/MyATT
- 800.331.0500
- 611 from any AT&T wireless phone

Appearance of devices may vary. Google Play is a trademark of Google Inc. Portions ©2016 Samsung Electronics America, Inc. Samsung and Samsung Gear S are both trademarks of Samsung Electronics Co., Ltd. Portions © 2016 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.