
Waterproof Wireless Speaker



User Manual

1

Quick start Guide

1.What's in the box



BS702 1pc


USB cable 1pc


2.Key functions

- 1. Power: Press and hold 3 seconds to power on/OFF
- 2. Play/Pause:short press to play/pause the music
- Call answer key: When an incoming call, a short press will answer or hang up the call, press and hold to reject the call.
- 3. Mode:Short press to switch TF/Bluetooth Mode, Long press To active Siri(Only for iphones) 4.Speaker phone
- While Max volume, you can hear a prompt tone
- 5. LEDindicator:
- 6. -: Long press: Volume-, Short press, Previous Song
- 7. +:Long press:Volume+,Short press,next song Power on:Blue Flashing, ready for bluetooth paring. Paired, Continous blue Play mode:Light Continuous blue
- Charging:RED light keeps on while charging,off while charging completed.
- 8. Hook
- 9. Micro SD(TF) card solt
- 10. Micro USB charging solt

Charging with DC5V/1A adaptor or USB Cable


When low battery, you can hear the prompt tone then the speaker will power off





3.Bluetooth Connection

Pairing with the devices that with bluetooth function





4

Wireless range is up to 10M(direct line of sight), your enviroment can cause shorter ranges to be experienced.

Bluetooth Pairing

Power on the speaker after the tone sound, a blue light will flicker, allowing pairing with a bluetooth device"BS702".

Notes:

The default password is "0000".

The speaker will auto-connect to te last paired device when it powers on. If you need to connect other devices disconnect with your current device first.

you will hear a prompt voice then the speaker is re-discoverable and ready to pair with a new device.

4.Specifications

Speaker Type	Waterproof Wireless Speaker	
Speaker system	Stereo	7
Active/Passive	Active	
Main Features	IPX66 water proof	
	Class G Digital AMP, Super good sound	_
	Bluetooth 4.1 Music Playing	
	Micro SD music Playing	
	Siri Activation	
Power Supply	Built-in 2000mAh Lithium Battery	
Louder speaker	1.5inch+passive radiators	
Output	4ohm 5W X2	╝
Frequency Response	100-200KHZ	
Bluetooth Version	4.1	
Max Support Micro SD	16GB	1

5.FAQ

Problems	What to do
Paired bluetooth	Restart the speaker
Device will not connect	2. If need password,please input "0000"
Music Cuts out/Stops playing	Check if the Bluetooth connection is valid and in range. check for outside interference from other electronic devices
The speaker indicates a connection,but is not playing music	1.Check the Volume of the speaker 2.Check if the speaker is muted or paused
Speaker will not turn on	Check if the battery is low
System Halted	Restart the speaker

5

6. Warnings

- *Please use and store the product at room temperature *Do not expose this product to rain or wet conditions
- *DO not throw and drop this product to avoid product damage
- *DO not self-dismantling, repair and transform the product
- *DO not use chemical solvent cleaning the product
- *Do not arbitratily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion

RoHS (€ 🗵

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.