Kensington

User Guide

Wireless mouse for life™
M01314-M

Thanks for buying Kensington products,
please read this user guide carefully before use.

Package contents:

- ◆ 1× M01314-M Mouse
- ◆ 1× Nano receiver
- ◆ 1× AA battery
- ◆ 1× User guide

User Guide

+ AA 1.5V

Installation

1 Open the battery cover and insert one AA battery. Switch the ON/OFF button to ON

AA

ON OFF

⚠ please pay attention to the the positive and negative polarity

2 Plug the Nano receiver into an available USB port on your laptop or desktop.

Feature

◆ Super silent keys function

The mouse has silent microswitch, its key stroke noise is lower than other mouse over 90%. The super silent keys brings you good comfort grip. No need to worry about the annoying key stroke noise in the still of night.

◆ 24-month battery life

Two automatic mode change to energy-saving mode which lower the power consumption to 9mW. Under the standard status, 1*AA battery can last for 24 months. Low-carbon environment save time and extend the battery life.

◆ Automatical sleep energy-saving mode

When stop using the mouse, it will automatically switch to two grades of sleep mode, which is super energy-saving.

| Time	Sleep status	Power consumption
After 0.2 seconds	First grade	≤ 0.16mA
After 20 seconds	Second grade	≤ 0.1mA

◆ Nano receiver

The nano receiver can be perfectly stored in the bottom of the mouse. Even when you are using the mouse, it can be perfectly hidden inside the USB port which make you forget about it.

◆ High precision optical sensor

The mouse has high precision optical sensor with high positioning accuracy. It can adapt with surface in different material and brings you high precision of the cursor control.

optical sensor

Technical data

Operation current	8mA	Operation distance	10m
Power supply	1.5V	Resolution	1000dpi
Frequency band	2402~2479MHz	Accelaration	≤10G

Maintenance

In order to keep the mouse for best using, M01314-M only require minimum maintenance. To avoid dust, we suggest using soft cloth or cotton yarn with little warm water to clean the nano receive after pulling it from the USB port. Do the cleaning once in one month. Do not use soap or trong detergent for cleaning. For best use the mouse in controlling and oving, strongly suggest you purchase high grade mouse pad. The mouse foot may be wear out by some mouse pad, which make you use the mouse unfavorably and force you change new mouse.

材质：80g双胶纸
工艺：单色印刷，风琴折
折叠尺寸：55x90mm