1. ASSEMBLE BATTERY

1) Remote control (As picture ① shows),
Open the cover of the battery box, put into a 9V battery as the inside instruction +/-, and then replace the battery cover.

2)Bodywork's battery(As picture ② shows),
Loosen the screw on the bottom of the car with screwdriver, open the cover and join the connection-pegs, put the battery into the box, replace the cover and lock it with the screwdriver. REMARK: The FENDER BRACKET is for avoiding slant and keeping the car in balance while it is playing.

NOTICE:

1).The battery should be putted in the correct pole like +/-.

2).Please turn off the switch and take out the battery while it stop playing.

2. Instruction of Controller

As picture ③ shows,

A. LEFT LEVER: Push it, the motor will go forward. Push it back, the motor will slowdown and stop.

B. RIGHT LEVER: Turn left & Turn right.

3. PREPARATION BEFORE USING

1) Remote Control(As picture ③ shows),
Put into the battery and replace the cover.

2) Bodywork's battery(As picture ② shows),

A. Assemble the battery and lock the cover with a screw.

B. Assemble the ANTENNA PIPE, there is a flexible antenna on the rearward, put it through the white wipe, and stick it in the position.

C. There is a switch under the rearward, (As picture ⑤ shows, Please turn on it before playing).

4. INSTRUCTION OF RECHARGING

As picture ⑥ shows,

1) Join battery's the connection-peg to the charger's.

2) It will recharge when the charger plug in the home socket directly.

3) The charger is not a toy, please get away from children.

4) The charger's indicator will light white it recharging, charge time is 5-6 hours.

5) It is normal that charger and battery become lapidity when they are recharging.

6) For extending the using time of battery, please recharge the battery when it use up the power source.

7) If it's need to check whether the charger's wire, pin, crust and other parts damage or not every month.

CAUTION:

A. The connection-peg couldn't be in short circuit.

B. Only the rechargeable battery could be recharged.

C. Please take out the battery from the car while it is recharging.

D. Not allow to use the old and the new battery at one time, the same as the different batteries.

E. Please take out the battery when it lacks of power.

F. It must be recharged by adult, not by children.

G. Please put into the battery according to the right pole.

5. NOTICE AND MAINTENANCE

1) Please keep all the accessories away from children for avoiding swallow.

2) If there is the same frequency of wave in where you are playing, please choose another place to avoid being interfered.

3) Please don't overstep the telecontrol distance when you are playing.

4) Please replace the remote control's battery or recharge the car's battery when the car is at low speed or uncontrolled. Please turn off the switch while it stop playing.

5) For avoiding accident, Please don't analyze the useless battery or throw it into the fire or water.

6) To avoid polluting the environment, please don't throw the wrapper after taking apart the packaging.

7) Please don't store up the ship near the fire, high temperature and dampness.

8) Please clean and dry the battery adequately when it was soaked.

9) Please keep the instruction for using.

10) Please don't play the car on the road, slope or any dangerous places.

11) Please check the car before playing every times

12) It's need to check whether the bodywork, wheel and any other parts damaged or not every month. If it has any damaged, please don't play it until it was amended.

13) For avoiding any hurts by rip, please don't allow children to touch the wheel and nearby.

14) Please don't wash the car, just clean it with dry cloth.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

6. TROUBLE SHOOTING

Problems	Checking Focus
Can not charge the battery fully	1.Whether the battery or charger were damaged or not. 2.Whether the electrical outlet was demaged or something bung it. 3.Whether the battery encase in the right pole or not.
Poor operation or low speed	1.Whether all batteries poor of power or not. 2.Whether it use the appointed battery or not.
Out of work	1.Whether the power switch of the controller and the car were turn on or not. 2.Whether the battery poor of power or encased in wrong ways. 3.Whether the telecontrol distance out of the limit. 4.Whether there is a same frequency or disturbing waves nearby. 5.Whether the poriee of controller was distorted , and out of contact.

CHOKING HAZARD: Small part. Not suitable for children under 6 years. It should be assembled & guided by adult.

MADE IN CHINA

⚠ WARNING:

CHOKING HAZARD-Small parts. Not for children under 6 years.