FCC Information

This equipment has been tested and found to comply with limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmtul interference in a residential installation.
This equipment can generates, uses, and radiate radio frequency energy and. if not installed and used in accordance with the instructions, may cause harmful inteference to radio Communcations. However there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause unacceptable interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or reocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a clrout different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio/TV technician for help.

DECLARATION OF CONFORMITY

PRODUCT NAME:17" COLOR MONITOR
MODEL NUMBER:1772E
FCC RULES:TESTED TO COMPLY WITH FCC PART 15, CLASS B
OPERATING ENVIRONMENT:FOR HOME OR OFFICE USE
FCC COMPLIANCE STATEMENT:
This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmtul interference, and(2)this device must accept any interference received,including interference that may cause undesired operation.

Introduction

Package 4
Safety Information 4
Features 5
Power management system 6

Installation

Connection to your personal computer 7
Pin assignment table D-sub mini 15 pin connector 7

Controls

OSD Controls 8
OSD Menus 9

Troubleshooting

No picture 12
Image is scrolling or unstable 12
Picture is fuzzy 12
Picture bounces or a waving pattern is present in the picture 12
Edges of the display image are not square 12
Display image is not centered, too small, or too large 12

Specifications

Electrical specifications 13
Mechanical specifications 13
Environmental specifications 13

Appendix

Preset Timings 14

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canadian Natice

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations

Avis Canadien

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Notice

The information contained in this document is subject to change without notice.

Introduction

Package

Congratulations on your purchase of this top quality color monitor!

The items illustrated below are contained in the carton.
First, be sure that your carton includes all of them.
It any items are mssng or damaged, please contact your local dealer or supplier.



Display Monitor

Tilt&Swivel Base



AC Power Input Cable

Safety information

- Provided with this monitor is a detachable power supply cord with IEC320 style terminations. It may be suitable for connection to any UL listed personal computer with similar configuration Betore making the connection ensure that the voltage rating of the computer convenience outlet is the same as the monitor and that the ampere rating of the computer convenence outlet is equal to or exceeds the monitor current rating.
  For 120Volt applications use only UL listed detachable power cord with NFMA configuration 5-15P type(parallel blades) plug cap.
  For 240Volt applications use only UL listed detachable power cord with NEMA configuration 6-15P type(tandem blades)plug cap.
- Use only a power source and connection appropriate for the monitor as indicated on the marking label.
- Slots and openings in the cabinet are provided for ventilation;
  these openings must not be blocked or covered. Never push objects of any kind into cabinet slots or other openings.
- Never insert anything metallic into the monitor openings.
  Doing so may create a danger of electric shock.
- To avoid electric shock, never touch the inside of the monitor.
  Only a qualified technican should open the monitor's case.
- Unplug the monitor from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp, lint-free cloth tor cleaning.
- Install the monitor near an outlet that you Can reach easily Disconnect the product by grasping the plug firmly and pulling in from the outlet.
  Never disconnect it by pulling the cord.

Introduction

Features

Superior image

- On Screen menu fingertip control system to visually select and adjust screen using buttons on front panel and on screen menus.
- The exclusive double dynamic focus system with a hyperbolic focus compensation circuit controls the electron bearms resulting in a fine image display over the entire area of the screen.
- Super contrast screen tor superior contrast and richer color.
- Advanced INVAR Shadow mask for superior focus, brightness and color.
- 17" , 0.24dot pitch high resolution, non-interaced technology provides sharp, flicker-free images.
- On screen menu color control system easily allows the white of the image to be adjusted as well as R.G.B signals, resulting in true-to-life colors.

Ergonomic Design

- Flat, square screen to reduce image distortion and glare, thus relieving eye strain.
- Tilt base allowing 90° rotation in the horizontal and 17° in the vertical for greater user comfort.
- Low-leak radiation prevention meeting MPR II and the very stringent TCO magnetic field as emissions standards for increased user safety .

Environmentally Friendly

- Power management circuit conforming to VESA DPMS standards controls energy consumption when monitor is not in use, you save energy.
- All plastic parts are recycable. All materials are strictly selected to ensure ease of maintenance, inspection and disposal.

Timing

- Automatic tracking of horizontal frequencies of 30 to 72 kHz,and vertical frequencise of 50 to 160 Hz.
- Eight timings are factory preset for image size and position
- Eight additional timings are user definable.
- Synchronizing input signals (separate, composite)can be automatically selected.

Introduction

System Flexibility

- Equipped with DDC1 DDC2B and DDC2BI for Plug & Play compatibility.
- Monitor is compatible with VGA, SVGA XGA and high resolution video modes up to 1280(H)×1024(V)60Hz
- Monitor may be used with IBM or compatible PC, Mac.
- Automatic universal power supply is buit in permitting AC power input of 100-240VAC, 50 or 60Hz.
- Self-test menu allows the display unit to be checked on screen without connecting to a Computer.
- Compact case minmizes desktop space giving you a large screen image without loss of workspace.
- Power cable included easily plugs into a standard outlet.

Power management system

This monitor complies with VESA, Nutek, and Energy Star power saving requirements. The power saving system works only when used with VESA DPMS compliant PC's and/or graphic controllers.

State	LED	Power	Recovery Time
On	Green	Normal(70 Watts)	N/A
Stand by	Green	< 60 Watts	2Sec
Suspend	Green/Blink	< 3 Watts	15Sec
off	Green/Blink	< 3 Watts	15Sec

The monitor goes into various power saving stages depending on the incoming video signal as shown in the follwing table

State	Horizontal Sync	Vertical Sync
On	On	On
Stand by	Off	On
Suspend	On	Off
off	off	off

Note

The monitor automatically goes through the DPMS steps when it is idle.

To release the monitor from the DPMS condition, press any key on the keyboard or mouse.

Installation

Connection to your computer

⚠ CAUTION

Ensure that both the PC and the display monitor are switched off.



To attach the monitor to your system, as shown in the following illustrations.

1.Insert the AC power cord ② into monitor and then into an AC power outlet.

2.Connect the signal cable ① to the 15pin graphics connector of the system and tighten the fastening screws.

3.To turn on the monitor, push the power switch.

Note: To attach the monitor to the Macintosh system, please contact an authorized deaer.(Need to use a special adaptor)

Pin assignment table D-Sub Mini 15pin connector

Pin No.	Assignment
1	Red Video
2	Green Video
3	Blue Video
4	Frame Ground
5	Ground
6	Red Video Ground
7	Green Video Ground
8	Blue Video Ground
9	N.C
10	Sync. Ground
11	Ground
12	SDA
13	H-Sync.
14	V-Sync.
15	SCL

The 15-pin D-Sub connector (male) of the signal cable (IBM Systems):



(15 Pin D-Sub)

Controls

OSD controls

"ON SCREEN MENU" controls include the following extended controls such as Size, Position, Geometry, Color Adjust, Brightness and Contrast Utilities. Adjustments are saved instantly. The currently addressed control can be reset to factory settings by pressing the Reset button.



Function of OSD buttons on the front of the monitor

- ↵ : In the main menu, exits the OSD controls. In a submenu, exits to the OSD main menu.
- -/+
  1) When no OSD on the Screen,
  -: Direct access to Brightness controls.
  +: Direct access to Contrast controls.
  2) When Main menu is displayed.: Moves to function what you want to adjust.
  3) When the Sub menu is displayed.: Controls the amount what you want to adjust.
- MENU: Displays OSD main Menu.
  1) When Main menu is displayed.: Selects function with RED ICON.
  2) When Sub menu is displayed.: Seects function with RED ICON.

Additional front controls

- Power Switch: Turns the monitor power on or off. When the power is on, the LED is on.
- LED Power indicator Light: Located left side of the power switch and indicates the monitor's power mode. Each mode reduces the amount of power used by the monitor.

Accessing on screen menu

Press MENU Button.

Turning off on screen menu

When in the main menu, press ↵ button.
When in submenus, press the ↵ button twice.

Controls

OSD Menu

OSD MENU	MENU	−	+	↵
1. NO OSD	Proceeds to NO.2	Proceeds to NO.3	Proceeds to NO.4	No meaning
2. MAIN MENU 	The function with RED ICON is -Performed: Recall, Degauss -Selected and blinked :Color Adjust, Zoom -Proceeded: Others	Moves to function you want.		Exit to No.1
3. BRIGHTNESS	Moves to No.2	Decreases the brightness	Increases the brightness	Exit to No.1
4. CONTRAST	Moves to No.2	Decreases the contrast	Increases the contrast	Exit to No.1
5. H/V-POSITION 	Toggles horizontal or vertical position	Moves the image down or left in the selected function.	Moves the image up or right in the selected function.	Exit to No.2
6. H/V-SIZE 	Toggles horizontal or vertical size	Shinks the image in the selected function.	Expands the image in the selected function.	Exit to No.2
7. GEOMETRY 	Odd press :Selects and blinks the function with RED ICON	Controls the amount of the Selected funcion. (Refer to Geometry controls menun detail)		Exit to No.2
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.2

Controls

OSD MENU	MENU	—	+	↵
8. MOIRE	Odd press :Selects and blinks the function with RED ICON	Controls the amount of the selected function. Please control these key in order the image not to shiver.		Exit to No.2
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.2
9. LANGUAGES	Selects the languages with RED ICON and Exit to No.2	Moves to language you want.		Exit to No.2
10. OSD POSITION 	Toggles OSD position horizontally or vertically.	Moves the OSD menu left or down in the selected function.	Moves the OSD menu right or up in the selected function.	Exit to No.2
11. COLOR MODE 	Odd press :Blinks the RED ICON -color menu ICON.	Moves to color mode you want and the selected "color mode" will blink.		Exit to No.1
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.1
	When the color mode ICON is blinking in user mode, press, then go to color adjust mode No.12.	—	—	—
12. COLOR ADJUST MODE  RB-Red background raster GB-Green background raster BB-Blue background raster RG-Red level gain GG-Green level gain BG-Blue level gain	Odd press :Selects and blinks the function you want.	Controls the amount of function you want.		Exit to No.1
	Even press :Stops blinking and ready to move function you want.	Moves to the function you want.		Exit to No.1

Controls

OSD MENU	MENU	—	+	↵
13.ZOOM 	Odd press :Selects zoom and blinks the zoom ICDN.	Shinks the image horizontally and vertically.	Expands the image horizontally and vertically.	Exit to No.1
	Even press :Stops blinking and ready to move another function.	Moves to the function you want.		Exit to No.1

■ Recall( ) : Recall control to the factory setting resets all the controls within the all menu. If you want to return to the factory mode setting, press menu key on Recall ICON.

■ Degauss( ): Eliminates the build-up of stray magnetic fleds which alter the correct scan of the electron beams and affect the purity of the screen colors, focus and convergence. When pressed, you screen image will jump and waver a bit as the screen is demagnetized.

⚠Caution :Please allow aminimum of 20 minutes to elapse between uses of the Degauss button. Do no hold the button down continuously to avoid decreasing the life the Deguass circuitry.

※ Geometry Controls Menu



The Geometry controls allow you to adjust the curvature or angle of the sides of you display.

■ Pincushion :Increases or decreases the curvature of the sides either inward or outward.
■ Parallelogram :Increases or decreases the tilt of the sides either to the left or right.
■ Trapezoid :Increases or decreases the bottom of the screen to be the same as the top.
■ Pin Balance :Increases or decreases the curvature of the sides either to the left or right.
■ Rotation :Increases or decreases the tilt of the screen image relative to a horizontal line.

Troubleshooting

No picture

- Check that the AC cord is correctly connected.
- Check that the AC socket is live by plugging in another piece of equipment.
- Power switch and computer power switch should be in position.
- Ensure that the signal cable is properly connected to the video card or PC.
- Ensure that the video card is securely seated in the PC.
- Check the connector for bent or pushed-in pins.
- Press a key on the keyboard or move the mouse, in case the screen power-saver mode has banked the screen.

Image is scrolling or unstable

- Signal cable should be securely attached to the computer.
- Check the pin assignments and signal timings of the monitor and your video card with respect to recommended timings and pin assignments.
- Ensure that the video card is securely seated in the PC.

Picture is fuzzy

- Adjust the Contrast and Brightness Controls.
- Push the Degauss Button once.

⚠ Caution :A minimum interval of 20 minutes should exist before the Degauss Button is used a second time. Do not hold the button down continuously.

Picture bounces or a waving pattern is present in the picture

- Move electrical devices that may be causing electrical interference away from the monitor.
- See the inside front cover of this manual for FCC information.
- Unshieded audio speakers placed next to the monitor can cause picture distortion. Move the speakers away.

Edges of the display image are not square

- Adjust the distortion using the Side Pincushion or Trapezoid Pincushion Balance, Parallel adjustment controls under the on screen menu.

Display image is not centered, too small, or too large

- Adjust the horizontal and vertical image sizes using the Horizontal and Vertical Size adjustment controls under the on screen menu.

Specifications

Electrical Specifications

ITEM		SPEC.
CRT Type		17",90° deflection FST
CRT Horizontal Dot pitch		0.24mm
CRT Surface		Anti-reflection
Input Signal	Sync	5V Separate TTL positive/negative H/V Composite TTL positive/negative
	Video	RGB Analog(0.7Vp-p), positive 75Ω Terminated
Scanning frequency	Horizontal	30Hz~72kHz Automatically
	Vertical	50Hz~160Hz(Automatically)
Maximum Resolution		1280Dots × 1024Lines(Non-interlace)
Pixel Clock(Max.)		110MHz
Display Size(Standard)		Horizontal 310mm, Vertical 230mm
Power Consumption(Max.)		74 Watts
Power Supply		AC 100~240V(at 50/60Hz ±3Hz)
Iuput Connector		D-Sub, 15Pin Connectors
Display Colors		Unlimited

Mechanical Specifications

ITEM		SPEC.
Dimension	Unit	15.6" (W)×16.4" (D)×14.4/14.9/16.1(H) 397mm(W)×417mm(D)×366/378/410.2mm(H)
	Carton	17.8" (W)×18.9" (D)×17.3" (H) 453mm(W)×479mm(D)×440mm(H)
Weight	Net	32.1lbs(14.6Kg)
	Gross	45.2lbs(20.5Kg)

Environmental Specifications

ITEM		SPEC.
Temperature	Operating	32°F to 104°F(0°C to 40°C)
	Storage	-4°F to 140°F(-20°C to 60°C)
Humidity		10% to 85% R.H. Non-condensing

Troubleshooting

Preset Timings

This Monitor 1772E has preset modes for the 8 most popular industry standards for "Plug and Play" capability.



Resolution / Timing	IBM		VESA	
	VGA/70Hz	VGA/60Hz	640/75Hz	640/85Hz
	720×400	640×480	640×480	640×480
H-Freq(KHz)	31.469	31.469	37.5	43.269
A μ sec	31.777	31.777	26.667	23.111
B μ sec	3.813	3.813	2.032	1.556
C μ sec	1.907	1.907	3.81	2.222
D μ sec	25.422	25.422	20.317	17.778
E μ sec	0.636	0.636	0.508	1.556
V-Freq(Hz)	70.09	59.94	75	85.008
Omsec	14.268	16.684	13.333	11.764
Pmsec	0.064	0.064	0.08	0.069
Qmsec	1.08	1.048	0.427	0.578
Rmsec	12.711	15.253	12.8	11.093
Smsec	0.413	0.318	0.027	0.023
Pixel rate(MHz)	28.322	25.175	31.500	36
H-Polarity	Negative	Negative	Negative	Negative
V-Polarity	Positive	Negative	Negative	Negative

Resolution / Timing	VESA			
	800/75Hz	800/85Hz	1024/75Hz	1024/85Hz
	800×600	800×600	1024×768	1024×768
H-Freq(KHz)	46.875	53.674	60.023	68.677
A μ sec	21.333	18.631	16.660	14.561
B μ sec	1.616	1.138	1.219	1.016
C μ sec	3.232	2.702	2.235	2.201
D μ sec	16.162	14.222	13.003	10.836
E μ sec	0.323	0.569	0.203	0.508
V-Freq(Hz)	75	85.061	75.029	84.997
Omsec	13.333	11.756	13.328	11.765
Pmsec	0.064	0.056	0.050	0.044
Qmsec	0.448	0.503	0.466	0.524
Rmsec	12.8	11.179	12.795	11.183
Smsec	0.021	0.019	0.017	0.015
Pixel rate(MHz)	49.5	56.25	78.750	94.5
H-Polarity	Positive	Positive	Positive	Positive
V-Polarity	Positive	Positive	Positive	Positive

FCC Information

This equipment has been tested and found to comply with limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmtul interference in a residential installation.
This equipment can generates, uses, and radiate radio frequency energy and. if not installed and used in accordance with the instructions, may cause harmful inteference to radio Commuincations. However there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause unacceptable interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or reocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a cirout different from that to which the receiver is connected.
- Consult the dealer or an experienced Radio/TV technician for help.

DECLARATION OF CONFORMITY

PRODUCT NAME:17" COLOR MONITOR
MODEL NUMBER:1772ED
FCC RULES:TESTED TO COMPLY WITH FCC PART 15, CLASS B
OPERATING ENVIRONMENT:FOR HOME OR OFFICE USE
FCC COMPLIANCE STATEMENT:
This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmtul interference, and(2)this device must accept any interference received,including interference that may cause undesired operation.

Introduction

Package 4
Safety information 4
Features 5
Power management system 6

Installation

Connection to your personal computer 7
Pin assignment table D-sub mini 15 pin connector 7

Controls

OSD Controls 8
OSD Menus 9

Troubleshooting

No picture 12
Image is scrolling or unstable 12
Picture is fuzzy 12
Picture bounces or a waving pattern is present in the picture 12
Edges of the display image are not square 12
Display image is not centered, too small, or too large 12

Specifications

Electrical specifications 13
Mechanical specifications 13
Environmental specifications 13

Appendix

Preset Timings 14

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canadian Natice

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations

Avis Canadien

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Notice

The information contained in this document is subject to change without notice.

Introduction

Package

Congratulations on your purchase of this top quality color monitor!

The items illustrated below are contained in the carton.
First, be sure that your carton includes all of them.
It any items are mssng or damaged, please contact your local dealer or supplier.



Display Monitor

Tilt&Swivel Base



AC Power Input Cable

Safety information

- Provided with this monitor is a detachable power supply cord with IEC320 style terminations. It may be suitable for connection to any UL listed personal computer with similar configuration Betore making the connection ensure that the voltage rating of the computer convenience outlet is the same as the monitor and that the ampere rating of the computer convenence outlet is equal to or exceeds the monitor current rating.
  For 120Volt applications use only UL listed detachable power cord with NFMA configuration 5-15P type(parallel blades) plug cap.
  For 240Volt applications use only UL listed detachable power cord with NEMA configuration 6-15P type(tandem blades)plug cap.
- Use only a power source and connection appropriate for the monitor as indicated on the marking label.
- Slots and openings in the cabinet are provided for ventilation;
  these openings must not be blocked or covered. Never push objects of any kind into cabinet slots or other openings.
- Never insert anything metallic into the monitor openings.
  Doing so may create a danger of electric shock.
- To avoid electric shock, never touch the inside of the monitor.
  Only a qualified technican should open the monitor's case.
- Unplug the monitor from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp, lint-free cloth tor cleaning.
- Install the monitor near an outlet that you Can reach easily Disconnect the product by grasping the plug firmly and pulling in from the outlet.
  Never disconnect it by pulling the cord.

Features

Superior Image

- On Screen menu fingertip control system to visually select and adjust screen using buttons on front panel and on screen menus.
- The exclusive double dynamic focus system with a hyperbolic focus compensation circuit controls the electron bearms resulting in a fine image display over the entire area of the screen.
- Super contrast screen tor superior contrast and richer color.
- Advanced INVAR Shadow mask for superior focus, brightness and color.
- 17″ , 0.20dot pitch high resolution, non-interaced technology provides sharp, flicker-free images.
- On screen menu color control system easily allows the white of the image to be adjusted as well as R.G.B signals, resulting in true-to-life colors.

Ergonomic Design

- Flat, square screen to reduce image distortion and glare, thus relieving eye strain.
- Tilt base allowing 90° rotation in the horizontal and 17° in the vertical for greater user comfort.
- Low-leak radiation prevention meeting MPR II and the very stringent TCO magnetic field as emissions standards for increased user safety .

Environmentally Friendly

- Power management circuit conforming to VESA DPMS standards controls energy consumption when monitor is not in use, you save energy.
- All plastic parts are recycable. All materials are strictly selected to ensure ease of maintenance, inspection and disposal.

Timing

- Automatic tracking of horizontal frequencies of 30 to 72 kHz,and vertical frequencise of 50 to 160 Hz.
- Eight timings are factory preset for image size and position
- Eight additional timings are user definable.
- Synchronizing input signals (separate, composite)can be automatically selected.

Introduction

System Flexibility

- Equipped with DDC1 DDC2B and DDC2Bi for Plug & Play compatibility.
- Monitor is compatible with VGA, SVGA XGA and high resolution video modes up to 1280(H)×1024(V)60Hz
- Monitor may be used with IBM or compatible PC, Mac.
- Automatic universal power supply is built in permitting AC power input of 100-240VAC, 50 or 60Hz.
- Self-test menu allows the display unit to be checked on screen without connecting to a Computer.
- Compact case minmizes desktop space giving you a large screen image without loss of workspace.
- Power cable included easily plugs into a standard outlet.

Power management system

This monitor complies with VESA, Nutek, and Energy Star power saving requirements. The power saying system works only when used with VESA DPMS compliant PC's and/or graphic controllers.

State	LED	Power	Recovery Time
On	Green	Normal(70 Watts)	N/A
Stand by	Green	< 60 Watts	2Sec
Suspend	Green/Blink	< 3 Watts	15Sec
off	Green/Blink	< 3 Watts	15Sec

The monitor goes into various power saving stages depending on the incoming video signal as shown in the follwing table

State	Horizontal Sync	Vertical Sync
On	On	On
Stand by	Off	On
Suspend	Off	Off
off	off	off

Note

The monitor automatically goes through the DPMS steps when it is idle.

To release the monitor from the DPMS condition, press any key on the keyboard or mouse.

Installation

▩ Connection to your computer

⚠ CAUTION

Ensure that both the PC and the display monitor are switched off.



To attach the monitor to your system, as shown in the following illustrations.

1.Insert the AC power cord ② into monitor and then into an AC power outlet.

2.Connect the signal cable ① to the 15pin graphics connector of the system and tighten the fastening screws.

3.To turn on the monitor, push the power switch.

Note: To attach the monitor to the Macintosh system, please contact an authorized deaer.(Need to use a special adaptor)

▩ Pin assignment table D-Sub Mini 15pin connector

Pin No.	Assignment
1	Red Video
2	Green Video
3	Blue Video
4	Frame Ground
5	Ground
6	Red Video Ground
7	Green Video Ground
8	Blue Video Ground
9	N.C.
10	Sync. Ground
11	Ground
12	SDA
13	H-Sync.
14	V-Sync.
15	SCL

The 15-pin D-Sub connector (male) of the signal cable (IBM Systems):



(15 Pin D-Sub)

Controls

OSD controls

"ON SCREEN MENU" controls include the following extended controls such as Size, Position, Geometry, Color Adjust, Brightness and Contrast Utilities. Adjustments are saved instantly. The currently addressed control can be reset to factory settings by pressing the Reset button.



Function of OSD buttons on the front of the monitor

- ↵ : In the main menu, exits the OSD controls. In a submenu, exits to the OSD main menu.
- -/+
  1) When no OSD on the Screen,
     -: Direct access to Brightness controls.
     +: Direct access to Contrast controls.
  2) When Main menu is displayed.: Moves to function what you want to adjust.
  3) When the Sub menu is displayed.: Controls the amount what you want to adjust.
- MENU: Displays OSD main Menu.
  1) When Main menu is displayed.: Selects function with RED ICON.
  2) When Sub menu is displayed.: Seects function with RED ICON.

Additional front controls

- Power Switch: Turns the monitor power on or off. When the power is on, the LED is on.
- LED Power indicator Light: Located left side of the power switch and indicates the monitor's power mode. Each mode reduces the amount of power used by the monitor.

Accessing on screen menu

Press MENU Button.

Turning off on screen menu

When in the main menu, press ↵ button.
When in submenus, press the ↵ button twice.

Controls

OSD Menu

OSD MENU	MENU	—	+	↵
1. NO OSD	Proceeds to NO.2	Proceeds to NO.3	Proceeds to NO.4	No meaning
2. MAIN MENU 	The function with RED ICON is -Performed: Recall, Degauss -Selected and blinked :Color Adjust, Zoom -Proceeded: Others	Moves to function you want.		Exit to No.1
3. BRIGHTNESS	Moves to No.2	Decreases the brightness	Increases the brightness	Exit to No.1
4. CONTRAST	Moves to No.2	Decreases the contrast	Increases the contrast	Exit to No.1
5. H/V-POSITION 	Toggles horizontal or vertical position	Moves the image down or left in the selected function.	Moves the image up or right in the selected function.	Exit to No.2
6. H/V-SIZE 	Toggles horizontal or vertical size	Shinks the image in the selected function.	Expands the image in the selected function.	Exit to No.2
7. GEOMETRY 	Odd press :Selects and blinks the function with RED ICON	Controls the amount of the Selected funcion. (Refer to Geometry controls menun detail)		Exit to No.2
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.2

Controls

OSD MENU	MENU	—	+	↵
8. MOIRE 	Odd press :Selects and blinks the function with RED ICON	Controls the amount of the selected function. Please control these key in order the image not to shiver.		Exit to No.2
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.2
9. LANGUAGES	Selects the languages with RED ICON and Exit to No.2	Moves to language you want.		Exit to No.2
10. OSD POSITION 	Toggles OSD position horizontally or vertically.	Moves the OSD menu left or down in the selected function.	Moves the OSD menu right or up in the selected function.	Exit to No.2
11. COLOR MODE 	Odd press :Blinks the RED ICON -color menu ICON.	Moves to color mode you want and the selected "color mode" will blink.		Exit to No.1
	Even press :Stops blinking and ready to move function you want.	Moves to function you want.		Exit to No.1
	When the color mode ICON is blinking in user mode, press, then go to color adjust mode No.12.	—	—	—
12. COLOR ADJUST MODE  RB-Red background raster GB-Green background raster BB-Blue background raster RG-Red level gain GG-Green level gain BG-Blue level gain	Odd press :Selects and blinks the function you want.	Controls the amount of function you want.		Exit to No.1
	Even press :Stops blinking and ready to move function you want.	Moves to the function you want.		Exit to No.1

Controls

OSD MENU	MENU	—	+	↵
13.ZOOM 	Odd press :Selects zoom and blinks the zoom ICDN.	Shinks the image horizontally and vertically.	Expands the image horizontally and vertically.	Exit to No.1
	Even press :Stops blinking and ready to move another function.	Moves to the function you want.		Exit to No.1

■ Recall( ) : Recall control to the factory setting resets all the controls within the all menu. if you want to return to the factory mode setting, press menu key on Recall ICON.

■ Degauss( ): Eliminates the buid-up of stray magnetic fieds which alter the correct scan of the electron beams and affect the purity of the screen colors, focus and convergence. When pressed, you screen image will jump and waver a bit as the screen is demagnetized.

⚠Caution :Please allow aminimum of 20 minutes to elapse between uses of the Degauss button. Do no hold the button down continuously to avoid decreasing the life the Deguass circuitry.

※ Geometry Controls Menu



The Geometry controls allow you to adjust the curvature or angle of the sides of you display.

■ Pincushion :Increases or decreases the curvature of the sides either inward or outward.
■ Parallelogram :Increases or decreases the tilt of the sides either to the left or right.
■ Trapezoid :Increases or decreases the bottom of the screen to be the same as the top.
■ Pin Balance :Increases or decreases the curvature of the sides either to the left or right.
■ Rotation :Increases or decreases the tilt of the screen image relative to a horizontal line.

Troubleshooting

No picture

- Check that the AC cord is correctly connected.
- Check that the AC socket is live by plugging in another piece of equipment.
- Power switch and computer power switch should be in position.
- Ensure that the signal cable is properly connected to the video card or PC.
- Ensure that the video card is securely seated in the PC.
- Check the connector for bent or pushed-in pins.
- Press a key on the keyboard or move the mouse, in case the screen power-saver mode has banked the screen.

Image is scrolling or unstable

- Signal cable should be securely attached to the computer.
- Check the pin assignments and signal timings of the monitor and your video card with respect to recommended timings and pin assignments.
- Ensure that the video card is securely seated in the PC.

Picture is fuzzy

- Adjust the Contrast and Brightness Controls.
- Push the Degauss Button once.

⚠Caution :A minimum interval of 20 minutes should exist before the Degauss Button is used a second time. Do not hold the button down continuously.

Picture bounces or a waving pattern is present in the picture

- Move electrical devices that may be causing electrical interference away from the monitor.
- See the inside front cover of this manual for FCC information.
- Unshieded audio speakers placed next to the monitor can cause picture distortion. Move the speakers away.

Edges of the display image are not square

- Adjust the distortion using the Side Pincushion or Trapezoid Pincushion Balance, Parallel adjustment controls under the on screen menu.

Display image is not centered, too small, or too large

- Adjust the horizontal and vertical image sizes using the Horizontal and Vertical Size adjustment controls under the on screen menu.

Specifications

Electrical Specifications

ITEM		SPEC.
CRT Type		17",90° deflection FAT
CRT Horizontal Dot pitch		0.25mm
CRT Surface		Anti-reflection
Input Signal	Sync	H/V Separate TTL positive/negative H/V Composite TTL positive/negative
	Video	RGB Analog(0.7Vp-p), positive 75Ω Terminated
Scanning frequency	Horizontal	30KHz~71KHz(Automatically)
	Vertical	50Hz~160Hz(Automatically)
Maximum Resolution		1280Dots×1024Lines(Non-interlace)
Pixel Clock(Max.)		110MHz
Display Size(Standard)		Horizontal 316mm, Vertical 236mm
Power Consumption(Max.)		74 Watts
Power Supply		AC 100~240Volt 50/60Hz ± 2Hz
Iuput Connector		D-Sub, 15Pin Connectors
Display Colors		Unlimited

Mechanical Specifications

ITEM		SPEC.
Dimension	Unit	15.6" (W)×16.4" (D)×14.9/16.1(H) 397mm(W)×413mm(D)×378/410mm(H)
	Carton	19.1" (W)×20.3" (D)×16.1" (H) 485mm(W)×515mm(D)×409mm(H)
Weight	Net	34.8lbs(15.8Kg)
	Gross	38.1lbs(17.3Kg)

▷ It is different according to option.

Environmental Specifications

ITEM		SPEC.
Temperature	Operating	32°F to 104°F(0°C to 40°C)
	Storage	-4°F to 140°F(-20°C to 60°C)
Humidity		10% to 85% R.H. Non-condensing

Troubleshooting

Preset Timings

This Monitor 1772ED has preset modes for the 8 most popular industry standards for "Plug and Play" capability.



Resolution / Timing	IBM		VESA	
	VGA/70Hz	VGA/60Hz	640/75Hz	640/85Hz
	720×400	640×480	640×480	640×480
H-Freq(KHz)	31.469	31.469	37.5	43.269
A μ sec	31.777	31.777	26.667	23.111
B μ sec	3.813	3.813	2.032	1.556
C μ sec	1.907	1.907	3.81	2.222
D μ sec	25.422	25.422	20.317	17.778
E μ sec	0.636	0.636	0.508	1.556
V-Freq(Hz)	70.09	59.94	75	85.008
Omsec	14.268	16.684	13.333	11.764
Pmsec	0.064	0.064	0.08	0.069
Qmsec	1.08	1.048	0.427	0.578
Rmsec	12.711	15.253	12.8	11.093
Smsec	0.413	0.318	0.027	0.023
Pix.rate(MHz)	28.322	25.175	31.500	36
H-Polarity	Negative	Negative	Negative	Negative
V-Polarity	Positive	Negative	Negative	Negative

Resolution / Timing	VESA			
	800/75Hz	800/85Hz	1024/75Hz	1024/85Hz
	800×600	800×600	1024×768	1024×768
H-Freq(KHz)	46.875	53.674	60.023	68.677
A μ sec	21.333	18.631	16.660	14.561
B μ sec	1.616	1.138	1.219	1.016
C μ sec	3.232	2.702	2.235	2.201
D μ sec	16.162	14.222	13.003	10.836
E μ sec	0.323	0.569	0.203	0.508
V-Freq(Hz)	75	85.061	75.029	84.997
Omsec	13.333	11.756	13.328	11.765
Pmsec	0.064	0.056	0.050	0.044
Qmsec	0.448	0.503	0.466	0.524
Rmsec	12.8	11.179	12.795	11.183
Smsec	0.021	0.019	0.017	0.015
Pix.rate(MHz)	49.5	56.25	78.750	94.5
H-Polarity	Positive	Positive	Positive	Positive
V-Polarity	Positive	Positive	Positive	Positive