MOBITALK™
M O B I L E   M E S S E N G E R

Getting Started Guide
for CNI-900KM

cni Communication Network Interface, Inc.

Document title: Getting Started Guide for CNI-900KM

Edition	Date	Version	Remarks
1	September 17, 2002	Version 0.1	Preliminary Release

Table Of Contents

Getting to know Your MOBITALK

Front

LED   LCD

Power

Home
Key

Trackwheel

ESC

Del/Backspace

Enter

ALT

L-arrow   Space   R-arrow   CAP(sym)

Back

Strap Hole

Speaker

Reset Button

Connect the Serial Port to the serial cable provided.
(For information about connecting the serial port, see "Fully Charge Before Use," page 2.)

◄ Serial Port

In case of difficulty
Press the Reset Button with a sharp-end tool (such as a sharp pencil) to restart the system.

Fully Charge Before Use

Please follow the instructions below to fully charge your MOBITALK:

Serial Port

- Connect the serial cable both to the serial port of the MOBITALK and to the power adapter cable.
- It takes 3 hours to fully charge your MOBITALK.

- Red LED: Charging
- Green LED: Fully charged

Your MOBITALK is now ready for use. The following sections will help you understand the functions of your MOBITALK.

Starting your MOBTALK

Turning Your MOBITALK ON/Off

To turn your MOBITALK on, press and hold the **Power** button for 4 seconds. To turn it off, press and hold the **Power** button for 3 seconds.

> **Power Save Mode**
>
> Power Save Mode is set to one minute. To get out of the Power Save Mode, press the ESC or Power button once. To change the Power Save Mode setting, go to General Settings in Functions.

MOBITALK Home Screen

Status Icon

Program Icon

Status Icons

📶	Coverage strength indicator
⚡	Communication services are disabled because the battery is low.
⚡	Modem is off
🔋	Battery power indicator
🕐	Alarm is set
✉	Unread message waiting
🎵	Red LED + melody
🎵	Red LED + melody + vibration
📳	Red LED + vibration
A	Numeric/Symbolic Mode
N	Num(Sym) Lock Mode
c	Capitalization Mode
C	Caps Lock Mode

Message Delivery Status Icon

You can check delivery status of your sent messages in Outbox by the following icons.

😊 Successfully delivered

😟 Couldn't establish connection to the server.

🔄 Still waiting for response from the server.

Program Icon

To start a program, scroll to the program icon and click the trackwheel. You can also press the corresponding hotkey in the Home screen to start the program.

Program	Messenger	SMS	Chat	Mail	Address	Calculator	Game	Functions
Program Icon								
Hotkey	I	S	C	M	A	N	G	F

Navigating Using Trackwheel

	You can scroll up the trackwheel to see more menus.
	Shortcut keys
	You can scroll down the trackwheel to see more menus.

- Roll the trackwheel with your thumb to scroll up and down through screen lines, fields, and menu items
- Click the trackwheel with your thumb to open menus and select options, similar to the function of a mouse used with your PC.

Entering E-Mail Address

In the E-Mail input field, hit Space key to enter @ and hit Space key again to enter a period.

Entering Symbolic Characters

1. Display the Symbol Key Pad by pressing ALT + CAP (holding ALT while pressing CAP)
2. Click the trackwheel and select the symbol key pad you want (Greek, Basic..etc.)
3. To select a symbol, scroll to a symbol and press ENTER or click the trackwheel to select **Insert**.
4. To select more than one symbol at once, select each symbol and press the SPACE key. The selected symbols are shown on top. press ENTER or click the trackwheel to select **Insert**.

Keys and Key Combinations

| Key	Function
Power	■ Turning power on: Press and hold the Power button for 3 seconds. ■ Turing power off: Press and hold the Power button for 4 Seconds. ■ Activating backlighting: Press once
Trackwheel	Scrolling and selecting ■ Roll the trackwheel to scroll through screen lines, fields and menus items. ■ Click the trackwheel to open menus and select options.
Home Key	Returning to Home screen: Press the Home Key once. Setting manner mode: Press and hold the Home Key for 3 seconds.
ESC	Escaping from screens/menus
Enter	Inserting carriage returns and selecting
Space	Inserting a space
sym CAP	■ Capitalizing an alphabetic characters: Press the CAP key once ■ Activating CAPs lock: Press the CAP key twice consecutively
Alt	■ Typing numeric and symbol characters: Press the ALT key once to affect the next character you type ■ Activating Num(Sym) lock: Press the ALT key twice to affect all characters
del	Deleting previous characters
Alt + del	Deleting characters ahead of cursor
← →	Moving cursor left or right Increasing (right arrow) or decreasing (left arrow) values
Alt + sym CAP	Opening symbol library for extra characters
Home + ESC	Locking the keyboard: Hold Home Key while pressing ESC for two seconds
ESC + reset button	Switching to boot mode: Pres ESC + reset button in case your MOBITALK doesn't switch to boot mode when upgrading.

Customizing your MOBITALK

Customize your MOBITALK by adjusting settings in the **Functions**.

How to set values

■ To increase a value, use the right arrow; use the left arrow key to decrease a value.

■ To set data type, use the right or left arrow key to display the data type you want.

MOBITALK Programs

Messenger

Messenger Main Screen

Enjoy MSN, ICQ and Yahoo Messenger on the go.

> **Before using MOBITALK Messenger**
>
> You need to install each messenger program on your computer and sign up before using MOBITALK Messenger.

Registering Messenger

Manage Messenger → Choose a messenger → **Set** → Enter ID/password → **Register**

Setting View Properties

■ In the **View As** field, choose display type of your buddies (Display name, Name, ID) → **View As**

■ In the **Default Messenger** field → Choose which messenger you want to display at login → **Default Messenger**

My Messenger

My messenger is a favorite contact list made from MSN, ICQ and Yahoo messengers' contact lists.

1. **Manage Messenger** → **My Messenger** → **Set**

2. Choose contacts from the messenger on the right → **Add to My Messenger** → **Save & Exit**

3. To choose contacts from the other messengers → **Select Messenger** → Select a messenger → **Select** → Choose contacts from the messenger on the right → **Add to My Messenger** → **Save & Exit**

SMS

SMS Main Screen

Setting User Info

SMS Main Screen → **User Information** → Enter a name and contact number (MOBITALK, MICESS or Cell Phone) → **Save**

Sending New Message

SMS Main Screen → **Create New Message** → In **To** field, select **Import from Addr.Book** (or enter a recipient's number) → Select an address → **Select/Deselect** or press SPACE → **OK** → Enter a message in **Body** → **Send Message**

- You can enter up to 5 numbers in **To** field,
- When entering numbers directly in **To** field, use semi colon (;) between numbers.
- If the number of received messages exceeds 50, no more message will be received.

Chat

Chat Main Screen (Lobby)

You can enjoy MOBITALK Chat with MOBITALK and MICESS users.

Entering a Room/Starting a Chat

Chat Main Screen → **Create a Room** → Enter a **Name**, **Numbe**r (maximum number of people: 7) → Set **Password** (4-digit numbers) if you set the room as **Private** → **OK** → Enter a message and press ENTER.

P-to-P Chat (Peer to Peer Chat)

Chat Main Screen → **Request P-to-P Chat** → Enter a **Recipient's number** or Select **Address Book** or **Find Friend** → **Request**

Whisper

Chat Main Screen or Chat Room → **Whisper** → Enter a **Recipient's number** or Select **Address Book** or

Find Friend → Request

Mail

Mail Main Screen

Setting User Accounts

Mail Main Screen → **Set Account** → In **POP3 Ser.** field, enter a mail server or **Select Mail Sever** →
Enter **ID** (the part before @) and **password** → **Request Account**

User Settings

Mail Main Screen → **User Settings** → Enter a Name and E-Mail address which you want to use sending out
emails → Enter your signature in **Sig.** → **Save**

Sending New Mail

Mail Main Screen → **Create New Mail** → In **To** and **CC** field, select **Import from Addr.Book** (or enter a
recipient's number) → Select a address → **Select/Deselect** or press SPACE key → **OK** → Enter a **Title** and
a message in **Body** → **Send Mail**

- You can enter up to 5 mail addresses in **To** and **CC** field.
- When entering mail addresses directly in **To** field, use semi colon (;) between mail addresses.
- If numbers of received mails exceed 50, no more mail will be received.

Address Book

Address Book Main Screen

Creating New Address

Address Book Main Screen → **Create** → **Set Category Name** → Select a category → **Set Category
Name** → **Save**

Searching Address

- Address Book Main Screen → Enter a character in the field on top → **Search**
- Address Book Main Screen → **Search** → Enter a character in the field on top → **Search**

Viewing Address by Category

Address Book Main Screen → **Categories** → Select a category → **View Item**

Calculator

How to use Calculator

1. Enter a number using ALT key
2. Use arrow keys to navigate through operators and select one by pressing ENTER key.
3. Enter the next number and press ENTER.

Calculating percentage

To calculate 20% of 1000, enter the following: 1000 + 20%

Desktop Software

Using the MOBITALK desktop software, **MOBITALK XSync**, you can perform the following tasks.

- Synchronize your MOBITALK address book with MS Outlook contacts or MOBITALK Manager contacts.
- Backup any important information from MOBITALK to PC and restore MOBITALK from a backup file.
- Download melodies and icons onto your MOBITALK.
- Upgrade your MOBITALK with the latest software.

Safety Information

1 . SAFETY INFORMATION FOR FIXED WIRELESS TERMINALS

POTE NTIALLY EXPLOSIVE ATMOSPHERES

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cauls e an explosion or fire resulting in bodily injury or even death.

INTERFERENCE TO MEDICAL DIVICES

Certain electronic equipment may be shielded against RF signal from you wireless phone. (pacemakers, Hearing Aids, and so on) Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so.

RF signals may affect improperly installed or inadequately shielded electronic system in motor vehicles.

EXPOSURE TO RF ENERGY

Use only the supplied or an approved replacement antenna.

Do not touch the antenna unnecessarily when the phone is in use.

Do not move the antenna close to, or touching any exposed part of the body when making a call.

SAFETY INFORMATION FOR RF EXPOSURE

This equipment has been approved for mobile operation, and requires a minimum

of 20 cm. spacing between antenna(s) and all person's body (excluding extremities

of hands, wrist and feet) during wireless modes of operaton.