8055T

USER MANUAL

DBTEL is a registered trademark of DBTEL Incorporated.
Copyright © 2001 DBTEL Incorporated. All rights reserved.
No part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior written permission of the publisher.
DBTEL Incorporated reserves the right to make changes in technical and product specifications without provisional notification.
Address: No.29, Tzu Chiang St, Tu-Cheng, Taipei, Taiwan.
Website: http://www.dbtel.com.tw

Warning: Use only approved accessories and battery. Do not connect to any incompatible products; otherwise, it will invalidate the recognition or warranty applying to your mobile phone.

The font type of the legend, graphics and icons in the user manual may differ from that shown on the hand.

Notice

To reduce exposure to electromagnetic radiation, use it with properly.
SAR Radiation Limit: 1.6 W/Kg
Tested SAR Rating: 0.485 W/Kg

Safety Guarantee

DBTEL handset is the first Specific Absorption Rate(SAR) compliance in Taiwan.

Safety Is The First

Product safety is always the first priority of DBTEL Incorporated. With the SAR Safety Certificate, the persistence we insist on has been proved that to be right, again. Customer's safety is of paramount importance to us, there is no exception.

A declaration of conformity to the essential requirements.

Identification of the North America in which the equipment is intended to be used.

Identification of the public telecommunication network to which the equipment is intended to be connected.

" Hereby, we <DBTEL Inc.>, declares that this **8055T** is in compliance with the essential requirements and other relevant provisions of "FCC Part2(Section2 1093) & FCC OET Bulletin 65".

Quick & Easy

This page provides some of the basic operations for using your phone. For more detailed information, refer to relevant function show.

1. Remove the battery and insert your SIM card, then re-install and charge the battery. For more details, please refer to “Installation”.
2. Press and hold to turn on your phone. Wait until the name of the network operator appears on the screen.

Making calls

In idle mode, key in the area code, the phone number and press to make a call.

Answering calls

Press or (Accept) to answer a call. Alternatively, simply open the phone cover to answer a call if the handset cover is closed (if “Flip answer” is activated).

Terminating calls

Press or (End) to end the active call. Alternatively, simply close the phone cover to end.

Refusing calls

Press or (Reject) or simply close the handset cover to refuse an incoming call.

Emergency calls

In idle mode, key in 112 and press to contact the emergency services center.

Clear screen

Press and hold to clear an editing entry.

Adjusting the earpiece volume

You can adjust the earpiece volume when calling using (louder) or (lower) to increase or decrease the earpiece volume.

Add new phone number

The easy operating steps of new added telephone numbers.

1. In idle mode, key in the phone number and press (Save).
2. Select ”name” or ”number”，edit and press (save).
3. If ” Save To SIM ”is selected. Press (save). If “Save To Handset” is selected. Press (enter) to the group setting. Select the desired group and press (save).

- Scroll to the required fields with .
- Switch between the input methods by pressing .
- ***For information on how to enter the characters, please refer to “Input text” in “Call Functions”.***

Menu Map

1. CAMERA

- Photo Album
- photo Size
  - Large
  - Medium
- Photo Quality
  - High
  - Normal
  - Low
- Photo Effect
  - Normal
  - Brown
- Self Timer
  - Disabled
  - 10 Seconds
  - 15 Seconds
  - 30 Seconds
- Night Mode
  - Disable
  - Enabled
- Profiles
  - mode(60Hz)
  - mode(50Hz)
- Settings
  - Photo Flash
  - Capture Sound
  - Auto Off

Menu Map

2. Phone book

- Search
  - View
  - Copy
  - Delete
  - Group setting
  - Send
  - Send MMS
- Add new
  - To SIM
  - To Handset
- Group setting
  - Family
  - Friend
  - Workmate
  - VIP
  - Others
- Copy
  - Manual select
    - Erase original
    - Keep original
  - Auto select
    - SIM all
    - Handset all
- Delete
  - One entry
  - Entries
  - SIM all
  - Handset all
- Fixed dial
  - Off
  - On
- Speed dials
  - View
  - Change
  - Delete
- Phone status

3. Messages

- **SMS**
  - Inbox
    - Delete
    - Extract number
    - Text reply
    - Voice reply
    - Text forward
  - Outbox
    - Delete
    - Extract number
    - Change
    - Text forward
  - Write message
    - Send
    - Save
    - Send & save
    - Send to many
  - Draftbox
    - Send
    - Send to many
    - Change
    - Delete
  - Delete message
    - Select Delete
    - Inbox
    - Outbox
    - Draftbox
    - Delete all message
  - Voice box
    - Listen to voice Number
  - Cell broadcast
    - Broadcast
    - Channel
  - Message settings
    - SMS validity
    - SMS center
    - SMS Report
    - AudSMS Frequency

Menu Map


MMS
Compose
Edit Slide
Add Text
Input text
From File
Add Image
pictures
Camera
Add Audio
Preview Slide
Next Slide
Add Text
Input text
From File
Add Image
pictures
Camera
Add Audio
Previous Slide
Duration
Delete Slide
End Compose
To
Cc
Subject
Preview
Send
Save
Configure
Priority
Sender Visibility
Delivery Report
Read Reply Request

Menu Map


Inbox
Outbox
Pending
Drafts
Sent
Configure
Priority
Sender Visibility
Delivery Report
Reply Request
Read Reply
Auto Download
Reject Ads
Append Signature
Validity Period
MMS URL
Report
User Folder

4. Call meters

- Missed
  - Save
  - Delete
  - Delete all
- Received
  - Save
  - Delete
  - Delete all
- Dialled
  - Save
  - Delete
  - Delete all
- Last call time
  - Off
  - On
- Call alert
  - Off
  - 1 minute
  - 3 minutes
  - 6 minutes
  - 10 minutes
- Show call duration
  - Outgoing
  - Incoming
  - Lifetime
- During call
  - Off
  - Time
  - Cost
  - Time & cost
- Charge rate
- Total cost

Menu Map

5. Profiles

- General
  - Activate
  - Settings
    - Incoming call alert
    - Incoming ringer
    - Alarm, ringer
    - SMS ringer
    - Volume level
    - Keytone
    - Keypad Volume
- Silent
- Outdoor
- Economic
- Restore

Menu Map

6. Date & Time

- Alarm
  - Off
  - Once
  - Everyday
- Calendar
- Date & Time
- Display mode
  - No display
  - Date only
  - Time only
  - Date & Time
- Power off
  - Off
  - Once
  - Everyday
- Format
  - Date format
    - YYYY/MM/DD
    - DD/MM/YYYY
    - MM/DD/YYYY
  - Time format
    - 12 hour
    - 24 hour
- Stop watch
- Time Different
- Count down
- Alarm at hour

Menu Map

7.Settings

- Screen
  - Wallpapers
    - Wallpaper Everyday
    - Wallpaper
  - Colour
  - Brightness
  - Backlight
  - WelcomeNote
- Phone setting
  - Language
  - Input style
  - Own number
  - Auto redial
  - Anykey answer
  - Auto answer
  - Flip answer
  - Headset
  - Volume
  - GPRS incoming call
  - Battery State
  - Start-Up Tone
  - Factory set
- Call setting
  - Call barring
    - Change code
    - Outgoing
    - Incoming
    - Cancel all
  - Call waiting
    - Status
    - Activate
    - Deactivate
  - Call divert
    - All calls
    - When busy
    - No reply
    - Not reachable
    - Cancel all
  - Own number
    - Sending off
    - Sending on

Menu Map


Network
Security
Phone lock
On
Off
PIN lock
On
Off
Password
Change code
Change PIN
Change PIN2
Set short cut
Up key short
Down key short
Left key short
Right key short