RANGER
说明书1

正面



Product Parameters

Model	D402	Screen type	0.95-inch screen
Battery capacity	0.285Wh	Battery life	over 10 days
Charging time	about 2.5 hours	Bluetooth version	BLE 4.2
Waterproof level	5ATM	Operating temperature	10°C～45°C
Product frequency	2450-2480MHz	Max. transmission power consumption	< 12dBm (for EU compliance)

Range of charging temperature:10 ~ 45 ℃
Battery life: Actual battery life and charging time will vary depending on usage and environment, etc.
Waterproof: Not suitable for diving, swimming in the sea, or sauna. But suitable for swimming in swimming pool or in shower (cold water) and shallow beach.

Safety and Product Information Notes

Warning

Battery warning
Do not disassemble, bore or damage the battery. Do not disassemble the built-in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

Health Warning
If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitoring strap.
The watch's optical heart rate sensor glows green and flashes. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician if you can wear this product.
The device tracks your daily activities through sensors. These data are intended to tell you about your daily activities, such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
The device, accessories, heart rate sensors and other relevant data are designed for entertainment and fitness, not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We are not responsible for any consequences caused by any data deviation.

Cycling Warning
Please maintain good judgment at all times and ride in a safe manner. Make sure your bike and hardware are properly maintained, and all components are properly installed.

Matters Needing Attention
- Watch data needs to be kept once every 7 days to avoid data loss.
- The watch has no waterproof effect on seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports mode supports up to 6 hours of exercise at a time.
- The watch has a waterproof level of 5ATM and supports cold water shower, swimming, but not diving.
- Avoid wearing the watch too tight in daily use. Please keep the parts of the watch touching the skin dry.
- When your heart rate is measured, keep your arm still during the test.

RoHS

The device meets the EU ROHS criterion.
Please refer to IEC 62321, EU ROHS Directive 2011/65/EU and revised directive.

背面



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.