dokiWatch S

QUICK START GUIDE

Contents

Doki APP ---------- 1
Features ---------- 2
SIM card Installation ---------- 4
Warning ---------- 6
Caution ---------- 7
FCC Caution ---------- 8

Doki APP

Download APP
Search "dokiWatch"

Available on App Store
GET IT ON Google Play

Or download from: www.doki.com

Features



1. SOS button
2. Microphone
3. Touch panel
4. Speaker
5. Camera
6. On/Off button
7. Charging port
8. Home/Back button
9. SIM card cover

Features



SIM Card Installation

1. Power off the device before inserting SIM card
2. Pick and pull to open SIM card cover



SIM Card Installation

1. Slide right to open the metal sleeve
2. Place the SIM card into the sleeve
3. Slide left to lock the metal sleeve
4. Snap the SIM card cover back to secure
5. Start the device by pressing on/ off button for 3 seconds



Please visit Doki Help Center online (https://doki.zendesk.com/hc/en-us) for more detailed user manual.

Warning

- CAUTION - ELECTRICAL OPERATED PRODUCT
- All packing materials such as internal bags, plastic collars, plastic films are not part of this product and should be discarded for your child's safety.
- Do not try to disassemble the unit.
- To charge device, only use the USB cable supplied.
- Keep the device out of direct sunlight and away from any direct heat source.
- Do not attempt to clean device with water.
- If there is any discomfort or irritation during use, please remove device immediately.
- The product and the USB cable should be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to persons and that, in such an event, the USB cable should not be used until properly repaired.
- Precautions should be observed during handling and use to prevent electrical shock. Adult supervision is recommended.
- Please do not wear device during thunderstorm to avoid any danger caused by lightning.
- Do not bathe, shower, or swim with device. Do not submerge device in water. Avoid direct contact with rain or running water when washing hands.
- If the screen is broken, please stop using it. Do not touch or attempt to remove the broken parts, and contact customer service immediately.
- For all warning and disclaimer, please visit www.doki.com

Caution

1. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
2. Device shall only be connected to a USB interface of version USB2.0.

3. Adapter shall be installed near the equipment and shall be easily accessible.
4. USB port to charge device only
5. The max operation of the EUT is 50C and should not be lower then -10C.
6. The plug considered as disconnect device of adapter.
7. Device complies with RF specifications when it is used at 5mm from body.
8. Declaration of Conformity

Hereby, Umeox Innovations Co., Ltd. (The Manufacturer) declares that this device is in compliance with essential requirements and other relevant provisions of Directive 2014/53/EU

FCC Caution

5.15.21 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
5.15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
5.105(b) Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference in a residential installation, This equipment generates uses

and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Specific Absorption Rate (SAR) information:
This device meets the government's requirements for exposure to radio waves.The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 5mm for body worn and 10mm for hotspot.The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Contenidos

Doki APP ---------- 8
Características ---------- 9
Instalación de la SIM ---------- 10
Advertencia ---------- 11
Precaución ---------- 12

Doki APP

Descarga la APP
Busca "dokiWatch"

Available on App Store
GET IT ON Google Play

O descárgala aquí: www.doki.com

Características



1. Botón de ayuda
2. Micrófono
3. Pantalla táctil
4. Bocina
5. Cámara
6. Botón encendido / apagado
7. Puerto de carga
8. Botón de casa / atrás
9. Cubierta de la SIM

Características



Instalación de tarjeta SIM

1. Apaga el dispositivo antes de insertar la tarjeta SIM
2. Retira la tapa de la tarjeta SIM



Instalación de tarjeta SIM

1. Desliza a la derecha para abrir la placa de metal
2. Posiciona la tarjeta SIM en la placa
3. Desliza a la izquierda para cerrar la placa de metal
4. Vuelva a colocar la tapa de la tarjeta SIM
5. Enciende el dispositivo presionando el botón de encendido por 3 segundos



Advertencia

- PRECAUCIÓN: PRODUCTO CON OPERACIÓN ELÉCTRICA
- Todo el material de empaque incluyendo bolsas internas, sujetadores y cubiertas de plástico no son parte del producto y deben ser removidas por la seguridad de tu niño(a).
- No intentes desarmar el dispositivo.
- Para cargar el dispositivo utiliza únicamente el cable USB provisto.

- Mantén el dispositivo fuera de la luz directa del Sol y de cualquier fuente de calor.
- No limpies el dispositivo con agua.
- Si hay molestias o irritación con el uso, remueva inmediatamente el dispositivo del niño(a).
- El dispositivo y el cable USB debe ser examinado periódicamente por condiciones que puedan resultar en riesgo de fuego, choque eléctrico o daños a personas. En dicho caso el cable USB debe de cambiarse inmediatamente y no utilizarse más.
- Precauciones deben ser observadas durante la manipulación del dispositivo, para evitar choque eléctrico. Supervisión de un adulto es recomendado.
- No utilicos el dispositivo durante tormentas para evitar daños por rayos.
- No sumerjas el dispositivo en el agua. No permita que el niño(a) se bañe o nade con el reloj.
- Si la pantalla se rompe, deja de utilizar el reloj. No intentes remover las partes rotas y contacta servicio al cliente inmediatamente.
- Para soporte comunicate a www.doki.com

Precaución

1. Existe riesgo de explosión si la batería es reemplazada por otro.
2. El dispositivo sólo debe utilizarse con una interfaz USB2.0
3. El adaptador debe encontrarse cerca del equipo.
4. Cargar únicamente con el puerto USB
5. No exponga el reloj a temperaturas mayores a 50 grados centigrados ni menores a -10 grados centigrados.
6. El dispositivo cumple con las especificaciones RF cuando se utiliza a 5mm del cuerpo.
7. Declaración de conformidad: Umeox Innovations Co., Ltd (El fabricantel declara que este dispositivo cumple con los requerimientos esenciales de la Directiva 2014/53/EU.

Specific Absorption Rate (SAR) information: This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: dokiWatch S (FCC ID: 2AIGUDOKIWATCHS) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at Back-of-Wristbands is 1.280W/kg. This device was tested for typical limb-worn operations with the Back-of-Wristbands kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's limb and the Back-of-Wristbands. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. Use only the supplied or an approved antenna.

目录

Doki APP ---------- 13
功能 ---------- 14
SIM卡安裝方式 ---------- 15
警告 ---------- 17

Doki APP

下載 APP
搜索 dokiWatch

Available on App Store
GET IT ON Google Play

或到 www.doki.com 下載

功能



1. SOS 按鍵
2. 麥克風
3. 觸控螢幕
4. 喇叭
5. 相機
6. 電源按鍵
7. 充電接觸點
8. 首頁/返回鍵
9. SIM card 蓋

功能



SIM Card 安裝方式

1. 放入SIM卡前按壓鎖扣開機
2. 開啟SIM卡蓋



SIM Card 安裝方式

1. 向右滑開金屬卡槽
2. 放入SIM卡到卡槽內
3. 向左滑扣上金屬卡槽固定SIM卡
4. 將SIM卡蓋蓋上
5. 按下電源鍵3秒鐘開啟



警告

- 遵守所有與兒童安全相關的預防措施。請勿讓小朋友吸食或誤吸本裝置或包裝盒下之配件，可能會有窒息風險的危險。
- 請勿試圖拆開裝置本體。
- 請使用裝置專屬的USB充電線充電。
- 請勿長時間置於陽光照射處(例如車內儀表板上)，這會任何直接熱源或火源。
- 如果在使用過程中有任何不適或過敏現象，請立即關閉裝置。
- 請勿反覆或重重電击，會試將高壓電人電过，將電池進入或暴露於水或其他液體中否則將會導致火災，爆炸或其他危險。
- 如果本裝置過熱，請立即停用裝置或應用程式片刻。
- 禁止使用本裝置時，請勿使用。若使用本裝置會造成危險或干擾電子裝置，請勿使用裝置。
- 遵守所有兒童安全有關的安全措施。讓小朋友使用此裝置時需要在大人監督下使用。
- 有雷雨期間，請勿使用本裝置，以防止因閃電導致的任何危險。
- 洗澡或游泳時請勿佩戴。請勿將裝置置於水中。洗手或下雨時避免與水直接接觸。
- 如果裝置螢幕因碰撞而破裂，應立即停用裝置。切勿碰觸或嘗試取出
- 裝配的零件，並立即聯絡服務中心。

更多警告和免責聲明，請前往www.doki.com

www.doki.com

support@doki.com