part.6 **Settings**

06

Settings

Settings

The Setup screen is used to control the system settings of the Multimedia System. To enter the screen, press the `SETUP` key of the device or the `Settings` button in All Menus.

Navigation Settings

For more details, refer to part 4. Navigation Settings.

Sound Settings

Adjusts the sound effects for the whole system.

Features	Description
1 Position	Select the Up/Down/Left/Right button to control sound positioning. Press ⊕ to concentrate the sound in the centre of the vehicle.
2 Equaliser	Drag the slide bar to control bass/middle/treble settings. Press `Centre` to initialise the settings.

Features	Description
3 Loudness	Sets the volume ratio when reversing the car, answering a call, using Navigation Guidance, turning on the car's ignition, etc.
4 Advanced	You can select additional audio options such as "Speed Dependent Volume Control" that automatically controls Audio volume according to vehicle speed.
5 Default	Resets the sound to factory default settings.
6 Beep	Select to activate a beep when pressing buttons.

i **Information**

• Advanced sound settings may differ according to selected AMP option.
• The seat shape may differ according to vehicle model.

Display Settings

Controls the display brightness and image rate for the whole system.

Features	Description
1 Dimming	Provides the Auto-illumination feature that automatically adjusts the brightness of the screen according to the brightness levels of the car's surroundings. If you do not use the Auto-illumination feature, you can select either Daylight or Night illumination and maintain the brightness accordingly.

Features	Description
2 Illumination	Adjusts the level of brightness in Daylight or Night illumination. (If you use the Auto-illumination feature, you can set the brightness for both Daylight and Night illumination.)
3 Default	Resets the display to factory default settings
4 Display off	Shows the Display Off (touch activation) function.
5 Ratio	Aspect ratio can be switched between Normal, Full and Wide. This option is available only when in video mode.

Bluetooth Settings

Changes Bluetooth phone settings.
• Select the head unit SETUP key ▶
  Select Bluetooth .
• Home screen ▶ Select All menu ▶
  Select Settings ▶ Select Bluetooth .

Bluetooth Connections

Select the SETUP key in the head unit ▶
Select Bluetooth ▶ Select Bluetooth connection

Features	Description
1 Paired device list	Displays the paired Bluetooth device list. When selecting from the list, the device is connected or disconnected.
2 Bluetooth audio connection status	An icon appears when you make a Bluetooth Audio connection.
3 Bluetooth Hands-free connection status	An icon appears when you make a Bluetooth Hands-free connection.
4 Add new	Register a new Bluetooth device.
5 Delete devices	Select and delete a paired device.

ⓘ Information

• Up to 5 Bluetooth devices can be paired.

• Only one Bluetooth device can be connected at a time.

• During Bluetooth device connection, another device cannot be paired.

• When you delete a paired device, the Call History and Contacts stored in the head unit are also completely deleted.

• Bluetooth Hands-free and Bluetooth Audio functions are supported.

• Hands-free and audio-supported devices, such as a Bluetooth smartphone or audio, will function normally.

• When a Bluetooth device is connected, if the Bluetooth connection is unexpectedly disconnected due to being out of communication range, the device powering off or a Bluetooth communication error, the Bluetooth device automatically searches for and connects to other nearby Bluetooth devices.

• If the system is not stable due to a vehicle Bluetooth device communication error, restore the Default Factory Settings.

• In Default Factory Settings, the Bluetooth settings are reset to factory settings

• Select the SETUP key in the head unit ▶ Select Bluetooth ▶ Select Factory settings .

Auto connection priority

Select the SETUP key in the head unit ▶ Select Bluetooth ▶ Select Auto connection priority .

When the engine is running, the selected Bluetooth device is automatically connected. If you fail to connect the selected device, the previously connected device is automatically connected. If this also fails, it tries to connect all paired devices sequentially.

Depending on auto-connection priority, connection to a device may take some time.

System Bluetooth Info

Select the SETUP key in the head unit ▶ Select Bluetooth ▶ Select System Bluetooth Info .

Features	Description
1 Device name	You can change the Bluetooth device name of the vehicle.
2 Passkey	You can change the passkey used for Bluetooth device authentication. The default passkey is 0000.

ⓘ Information

• The device name above is an example. Check the actual information on the product.

Phone projection

For more details, refer to Phone projection guide.

Custom Button Settings

You can configure the feature to be accessed when the [☆] key is pressed.

Setting it to a feature that you frequently use will allow you to access the feature quickly and conveniently anytime.

For example, setting it to My Menu will enable you to access the My Menu screen by pressing the [☆] key.

Date/Time Settings

Configure the settings for time and date. Using the arrow buttons, you can change the values. Date/Time settings do not automatically change when crossing into different time zones. The time must be changed manually on this screen.

Features	Description
1 GPS	The time display is set in GPS Time.
2 Direct entry	If you tap any value, you can directly enter the number in the following screen.
3 Daylight Saving Time	The daylight saving time (DST) is applied.
4 24 Hours	The time display is set in 24-hour format.

Language Settings

You can configure the displayed system language.

When the language is changed, the system language is automatically changed. Unique data including MP3 file name is not changed and some languages don't support voice recognition.

Keyboard Settings

You can configure the keyboard layout for each language.

Features	Description
1 Keyboard type - Arabic	You can configure Arabic keyboard layout type for the system.
2 Keyboard type - English	You can configure ABCD or QWERTY keyboards for the system.
3 Default keyboard	You can select the system default keyboard.

i **Information**

• Configured keyboard layouts are applied to all input modes.

Screensaver Settings

You can select any of the following screen formats to be displayed when the screen or power is turned off.

• Digital clock and date
• Analogue clock and date
• None

Advance Settings

You can configure notifications per feature, etc.

Features	Description
1 Media notification	Sets whether to display media information at the top of the screen as the next item is played when not on the media screen.
2 Mode button steering wheel	You can configure the media to be accessed when the steering wheel's MODE button is pressed.

System Info

System version information and update details are available.

Select the Update button to update the system. After an update is complete, the system will reboot automatically.

System Update

On the System Info screen, insert the updated memory (USB or SD card) with the latest file downloaded, then select the Update button to begin updating. The system will then reboot automatically.

i **Information**

• This product needs supplementary software updates, additional new functions and updated maps, which collectively may take some time to complete, depending on the amount of data.

⚠ **CAUTION**

• If the power is disconnected or the USB device or SD card is removed during an update, data might be damaged. Please wait until the update is complete with the engine on.

MEMO

part.7 **Appendix**

07

Appendix

Product Specifications

TFT-LCD

Screen Size	7 inch(152.4 × 91.44 mm)
Resolution	384000 pixels (Resolution: 800 x 480)
Operating Method	TFT (Thin Film Transistor) Active Matrix
Viewing Angle	Left/Right, Top/Bottom: ALL 89°
Internal Lighting	LED

Radio

Channels	FM: 87.5 MHz ~ 108.0 MHz (Step : 100 kHz)
	AM: 531 kHz ~ 1602 kHz (Step : 9 kHz)
Sensitivity	FM : Under 10 dBu/AM : Under 35 dBu
Distortion Factor	Within 2 %

Common

Name	Car TFT LCD Display Navigation Unit		
Power Supply	DC 14.4 V	Operating Power	DC 9 V ~ DC 16 V
Current Consumption	2.5 A	Sleep Current	1 mA (Head Unit only)
Operating Temperature	-20 ~ +70 ℃ (-4 ~ +158 ℉)	Storage Temperature	-30 ~ +80 ℃ (-22 ~ +176 ℉)
Dimensions	178 × 140.2 × 60 mm (MAIN BOX)		
Weight	1.8 kg		

Bluetooth® Wireless Technology

Frequency Range	2402 ~ 2480 MHz	Supported Bluetooth® Specifications	3.0
Supported Profile	Hands-free(1.6), A2DP(1.2), AVRCP(1.4), PBAP(1.0)		
Output	-6 ~ 4dBm(Power Class2, Conducted)		
Number of Channels	79 channels		

⚠ CAUTION

• The manufacturer and installer cannot provide services relating to life safety as the radio equipment is liable to radio interference.

ℹ Information

• Further information including the manufacturer's declaration of conformity is available on Kia web site as follows; http://www.kia-hotline.com

Common Issues

1. Errors which occur during the operation or installation of the device may be mistaken as a device malfunction.
2. If you are having problems with the device, try the suggestions listed below.
3. If the problems persist, contact your Kia dealer.

Problem	Possible Cause
There are small red, blue or green dots on the screen	• Because the LCD is manufactured with technology requiring high point density, a pixel or lighting deficiency may occur within 0.01 % of total pixels
The sound or image is not working	• Has the Switch been turned to [ACC] or [ON]? • Has the SYSTEM been turned OFF?
The screen is being displayed but sound is not working	• Has the volume been set to a low level? • Has the volume been muted?
When the power is turned on, the corners of the screen are dark	• It is normal with LCD panels for the display to appear somewhat dark after prolonged periods of use. It is not a malfunction • If the screen is very dark, contact your nearest Kia dealer for assistance
Sound is only coming from one speaker	• Are the positions of Fader or Balance sound controls adjusted to only one side?

Problem	Possible Cause
Sound does not work in AUX mode	• Are the audio connector jacks fully inserted into the AUX terminal?
The external device is not working	• Is the external device connected with a standard connector cable?
When turning the power on, the most recent mode screen is not displayed	Within modes that play files by reading external sources, such as USB, iPod or Bluetooth® streaming mode, the most recently played mode screen prior to turning off power may not properly load • If there is no disc or the corresponding device is not connected, the mode operated prior to the most recent mode will operate • If the previous mode still cannot be properly played, the mode operated prior to that will operate

Troubleshooting

Problem	Possible Cause	Solution
The power does not turn on	The fuse is discon-nected	• Replace with a suitable fuse • If the fuse disconnects again, please contact your point of purchase or service centre
	Device is not properly connected	• Check that the device has been properly connected
The system does not play	The vehicle battery is low	• Charge the battery. If the problem persists, contact your point of purchase or service centre

Problem	Possible Cause	Solution
The image colour/tone quality is low	• The brightness, satura-tion, hue and contrast levels are not set prop-erly	• Adjust the brightness, satu-ration, hue and contrast lev-els in Display Setup
Sound is not working	• The volume level is set to the lowest level • The connection is not correct • The device is cur-rently fast-forward-ing, rewinding, scan-ning or playing in slow motion	• Adjust the volume level • Check that the device has been properly connected • The sound will not work when the device is fast-forwarding, rewinding, scanning or playing in slow motion
The sound or image quality is low	• Vibration is coming from where the con-version switch has been installed • Image colour/tone quality is low	• The sound may be short-circuited and the image dis-torted if the device vibrates • The device will return to normal once vibration stops

Problem	Possible Cause	Solution
USB does not work	• USB memory is damaged	• Please use the USB after formatting it.
	• USB memory has been contaminated	• Remove any foreign substances on the contact surface of the USB memory and multimedia terminal
	• A separately purchased USB HUB is being used • A USB extension cable is being used	• Directly connect the USB memory with the multimedia terminal on the vehicle • Directly connect the USB memory with the multimedia terminal on the vehicle
	• A USB which is not a Metal Cover Type USB Memory is being used	• Use standard USB memory
	• HDD type, CF, SD Memory is being used	• Use standard USB memory
	• There are no music files which can be played	• Only MP3, WMA file formats are supported. Please use only the supported music file formats

Problem	Possible Cause	Solution
The iPod is not recognised even though it has been connected	• There are no titles that can be played • The iPod firmware version has not been properly updated • The iPod device does not recognise downloads	• Use iTunes to download and save MP3 files onto the iPod • Use iTunes to update the firmware version and reconnect the iPod to the device • Reset the iPod and reconnect to the device

🛈 **Information**

• While operating the device, if an abnormality occurs that cannot be corrected using the above described measures, press the RESET key to reset the system.

• Press and hold the RESET key (for more than 1 second). The device power will turn off and the system will reset.

FAQ

Pairing Mobile Phones

Q I cannot pair my mobile phone. What is the cause?

A Check that the mobile phone supports Bluetooth® function. Check whether Bluetooth on the mobile phone is set to OFF. If so, set it to ON. If the mobile phone still can't be paired, try again after turning Bluetooth off and on, or delete the device registration on the Multimedia System and mobile phone and then register the mobile phone again.

Q What is the difference between pairing a mobile phone and connecting a mobile phone?

A Pairing takes place after authentication of the head unit and mobile phone. Mobile phones paired to the head unit can be connected and disconnected until the paired mobile phone is deleted from the system. Bluetooth® Hands-free features, such as making/answering calls or managing contacts, are supported only on mobile phones connected to the head unit.

Q What is a passkey?

A A passkey is the password used to authenticate the connection between the head unit and mobile phone. The passkey only needs to be entered once when pairing the mobile phone for the first time.
The initial passkey is 0000. You can change it in
`SETUP` ▶ `Bluetooth` ▶ `System Bluetooth info` ▶ `Passkey` using the menu options.

Making/Answering Phone Calls

Q How can I answer a call?

A When there is an incoming call, a notification pop-up will be displayed. To answer the incoming call, press the Accept button on the screen or the 📞 key on the steering remote controller.

To reject the call, press the Reject button on the screen or press the ☎ key on the steering remote controller.

Q What should I do if I am talking on the Hands-free but want to switch the call to my mobile phone?

A While on a call, press and hold (more than 0.8 seconds) the 📞 key on the steering remote controller or press the Use private button at the bottom of the Phone screen to switch the call to your mobile phone.

Bluetooth® Wireless Technology/Head Unit Use

Q What is the range of my wireless connection?

A The wireless connection can be used within 10m.

Q How many mobile phones can be paired?

A It is possible to pair up to five mobile phones.

Q Why is call quality sometimes poor?

A Check the reception sensitivity of the mobile phone when call quality deteriorates. Call quality may deteriorate when the signal strength is low. Call quality may also deteriorate if metal objects such as drink cans are placed near the mobile phone. Check if there are any metal objects in the vicinity of the mobile phone. The call sound and quality may differ depending on the type of mobile phone.

Important Safety Information

Before using your Multimedia System, read and follow all instructions and safety information provided in this end user manual ("User Guide"). Not following precautions found in this User Guide can lead to an accident or other serious consequences.

Keep User Guide in Vehicle

When kept in the vehicle, the User Guide will be a handy reference for you and other users unfamiliar with the Multimedia System. Please ensure that, before using the system for the first time, all users have access to the User Guide and read the instructions and safety information carefully.

Warning:

Operating certain parts of this system while driving can distract your attention away from the road and potentially cause an accident or other serious consequences. Do not change system settings or enter data non-verbally (using your hands) while driving. Stop the vehicle in a safe and legal manner before attempting these operations. This is important since, when setting up or changing some functions, you might be required to distract your attention away from the road and remove your hands from the wheel.

General Operation

Prolonged Viewing of Screen

Do not access any functions requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system that requires prolonged attention. Even occasional short scans to the screen may be hazardous if your attention has been diverted away from your driving task at a critical time.

Volume Settings

Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.

Navigation Features

Any navigation features included in the system are intended to provide turn-by-turn instructions to get you to a desired destination. Please make certain all system users carefully read and follow instructions and safety information fully.

Distraction Hazards

Some navigation features may require manual (non-verbal) setup. Attempting to perform such setup or insert data while driving can seriously distract your attention and could cause an accident or other serious consequences. Stop the vehicle in a safe and legal manner before attempting these operations.

Let Your Judgement Prevail

Any navigation features are provided only as an aid. Make your own driving decisions based on your observation of local conditions and existing traffic regulations. Any such feature is not a substitute for your personal judgement. Any route suggestions made by this system should never replace any local traffic regulations or your personal judgement or knowledge of safe driving practices.

Route Safety

Do not follow the route suggestions if doing so would result in an unsafe or illegal manoeuvre, if you would be placed in an unsafe situation or if you would be directed into an area that you consider unsafe. The driver is ultimately responsible for the safe operation of the vehicle and must therefore evaluate whether it is safe to follow the suggested directions.

Potential Map Inaccuracy

Maps used by this system may be inaccurate because of changes in roads, traffic controls or driving conditions. Always use good judgement and common sense when following the suggested routes.

Emergency Services

Do not rely on any navigation features included in the system to route you to emergency services. Ask local authorities or an emergency services operator for these locations. Not all emergency services such as police stations, fire stations, hospitals and clinics are contained in the map database.

FCC

FCC Part 15.19 Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21 statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF Exposure Statement (MPE)

The antenna(s) must be installed such that a minimum separation distance of at least 20 cm is maintained between the radiator (antenna) and all persons at all times.

This device must not be co-located or operating in conjunction with any other antenna or transm

FCC Part 15.105 statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.