Bluetooth Keyboard For iPad Pro User Manual

Model:HB180

Package Contents

1.Bluetooth keyboard
2.Micro-USB charging cable
3.User manual

Specifications

Bluetooth Specification	Bluetooth 3.0
Dimensions	304x223x7.7mm
Operating Range	Up to 10 meters
Modulation System	GFSK
Stand-by time	90 days
Charge time	< 4 hours
Uninterrupted Work Time	90 hours
Lithium Battery Capacity	230 mAh
Lithium Battery Life	3 years
Key Life	3 million clicks

Product Overview

① Caps Lock Indicator: Green light is on.
Bluetooth Indicator: Blue light will flash after pressing the "FN+ " keys together. Pair successfully will off.

② Power Indicator: The Green light will flash.
Red light will turn on when the keyboard is charging and turn green once fully charged.
Battery Low Indicator: Red light will flash when it is time to recharge.
Battery power display Indicator: Press "Fn+ ", flashing Green.
（Every blinking represents 25% battery. That is to say, flash once, the remaining battery 25% ; flash twice, the remaining battery 50% .)

Function Keys

	Home		Reduce brightness		Increase brightness
	Search		Keyboard Display		Select Language
	Previous track		Play/pause		Next track
	Mute		Volume down		Volume up
Fn+	Lock	Fn+	Battery power display		ON/OFF

Pairing keyboard method

Pairing with iPad Pro

Step 1. Press ⏻ , the keyboard turns on; Re-press 1.5 seconds to close.
Step 2. Press the "FN+ " keys together to enter pairing mode.
The blue Bluetooth indicator will start to rapidly flash.
Step 3. On the iPad Pro, select: Settings- General- Bluetooth-On.
Step 4. The iPad Pro will display "Bluetooth 3.0 keyboard" as an available device.
Step 5. Select " Bluetooth 3.0 Keyboard " on the iPad Pro, click on it, the keyboard will now be paired to iPad Pro and the Bluetooth indicator will turn off.

SPECIAL NOTE:

1. Only one device can be actively paired at one time.
2. After pairing for the first time, your device will connect to the keyboard automatically when opening the keyboard.
3. In case of connection failure, delete the pairing record from your device, and try the above procedures again.

Power Saving Mode

The keyboard will enter sleep mode when idle for 30 minutes.
To re-active it, press any key and wait for 3 seconds.

Charge it

1. Plug the micro end of the USB charging cable into the keyboard.
2. Plug the USB end of the cable into a computer or charging adapter (not included).

Note: Battery life of keyboard is approximately 90 hours, if the red charge indicator light begins flashing during use, 4-hour recharge is recommended.

Caution

When not in use for a prolonged period of time, it is recommended that you turn off the keyboard to lengthen the battery life.

Warning

1. Keep the keyboard away from sharp objects and liquids.
2. Do not place heavy objects on the keyboard.
3. Avoid extreme hot and cold temperatures.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.