•ΞYUNDAI
HYUNDAI IT CORP.

Type No. L22C0E080

Model. W220D

Multi Function Wide Monitor

User's Guide

U.S.A.

U.S.FEDERAL COMMUNICATIONS COMMISSION
RADIO FREQUENCY INTERFERENCE STATEMENT
INFORMATION TO THE USER

NOTE : This equipment has been tested and found to comply with the limits for a
Class B digital device pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful
interference in a residential installation.
This equipment generates, uses, and can radiate radio frequency energy and, if
not installed and used in accordance with the instructions, may cause harmful
interference to radio communications.
However, there is no guarantee that interference will not occur in a particular
installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is
encouraged to try to correct the interference by one or more of the following
measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet of a circuit different from that to which
  the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for assistance.

Changes or modification not expressly approved by the party responsible for
compliance could void the user's authority to operate the equipment.
Connecting of peripherals requires the use of grounded shielded signal cables.

1. Introduction

This manual contains instructions for installing and operating HYUNDAI IT CORP.

HYUNDAI IT CORP. This **is a highly ergonomic color display unit.**

- **24" viewable WUXGA LCD**
- **High quality screen re-scaling capability**
- **100-240V AC input voltage**
- **VESA DPMS (Display Power Management Signaling)**
- **VESA DDC1/2B compatibility**
- **Advanced digital On-Screen-Display controls**
- **Digital Signal Input by DVI-1.0 Compatability**
- **Fast and accurate auto adjustment**
- **Most advanced image scaling**
- **Supporting VESA Flat Panel Monitor Physical Mounting Interface**

This Monitor has been engineered and manufactured to assure your safety. You can prevent serious electrical shock and other hazards by keeping in mind the following:

2. Safety Information

Do not place anything wet on the monitor or the power cord. Never cover the ventilation openings with any material and never touch them with metallic or inflammable materials.

HYUNDAI
HYUNDAI IT CORP.

Avoid operating the monitor in extreme heat, humidity or areas affected by dust.
Temperature : 5~40°C
Humidity : 30~80RH

Be sure to turn the monitor off before plugging the power cord into the socket. Make sure that the power cord and the other cords are securely and rightly connected.

Overloaded AC outlets and extension cords are dangerous, as are frayed power cords and broken plugs, which may cause electric shock or fire. Call your service technician for replacement.

Do not use sharp tools such as a pin or a pencil near the monitor, as they may scratch the LCD surface.

Do not use a solvent, such as benzene, to clean the monitor, as it will damage the LCD surface.

HYUNDAI
HYUNDAI IT CORP.

Cleaning and Maintenance

- To avoid to risk of electric shock, do not disassemble the Cabinet of display Unit. The Cabinet is not user-serviceable. Remember to unplug the display unit from the power outlet before cleaning.

- Do not use alcohol (methyl, ethyl or isopropyl) or any strong dissolvent. Do not use thinner or benzene, abrasive cleaners or compressed air.

- Do not wipe the screen with a cloth or sponge that could scratch the surface.

- To clean your antistatic screen, use water and a special microfiber screen cleaning tissue used in optical lens cleaning, or lightly dampen a soft, clean cloth with water or a mild detergent.

- If the instructions above do not help in removing stains, contact an authorized service agent.

HYUNDAI
HYUNDAI IT CORP.

3. Installing the monitor

3-1. Packing List

The following items should be found in the packaging.

Power Cord

Signal Cable

DVI Cable

Audio Cable

Compact Disc

UK Japan

America/Canada Europe

South Africa Australia

Korea

! **Above power cord can be changed upon different voltage areas. Please contact your dealer if anything is missing or damaged.**

Other power cord except the cord packed in the product or longer than 3m may affect EMC of the product in operating condition.

HYUNDAI
HYUNDAI IT CORP.

3-2. Selecting a suitable location

3-3. Connecting the PC

• 15 pin D-sub / DVI-D / HDMI

- • Place the monitor at least 30cm from other electrical or heat-emitting equipment and allow at least 10cm on each side for ventilation.
- • Place the monitor in a position where no light shines directly onto or is reflected on the screen.
- • To reduce eye strain, avoid installing the display unit against a bright background such as a window.
- • Position the monitor so that the top of the screen is no higher than eye level.
- • Position the monitor directly in front of you at a comfortable reading distance (around 45 to 90cm)

! Before you start cabling your monitor, check that the power is off on all units. To avoid any possibility of electric shock, always connect your equipment to properly earthed outlets.

1. Insert the other 15-pin/DVI-D/HDMI signal cable connector into the 15-pin VGA/DVI-D connection on your computer and screw it down.
2. Plug the power cord connection to connection on the monitor.
3. Plug the other end of the power cord to your computer's main supply or to a 100V-240V earthed electrical outlet.
4. Turn on the monitor using the power switch and check that the power LED is on. If not, repeat steps 1,2,3 and 4 or refer to the Troubleshooting section of this guide.

HYUNDAI
HYUNDAI IT CORP.

• **Audio system**

This monitor has an audio system including two micro loudspeakers. Each of two micro loudspeakers has an 3W(max.) output power. This system also supports a headphone output jack.

! This system has been tuned to get a best tone quality which an audio input level is under 500mv rms. If the input level is more than 500mv rms, you must tune down the audio input as the audio output tone may be distorted.

Speaker

HYUNDAI
HYUNDAI IT CORP.

3-4. Setting the refresh rate

Follow the instructions below to set your refresh rate in Windows 98/ME/XP/2000.

1. Go to the configuration window(Start-Settings-Configuration window).
2. Double click on the 'Display' icon.
3. Click on the 'Settings' tab.
4. Click on the 'Advanced' button.
5. Click on 'Adapter' and select 60Hz from the list.
6. Click on 'Apply' to accept the selected value.

Preset Timing Table

> **!** If the signal from the system doesn't equal to the preset timing mode, adjust the mode with reference to the user guide of videocard because the screen may not be displayed.

No.	Resolution	H-Freq.(Khz)	V-Freq.(hz)	Supported Mode	
				Analog	DVI
1	640 X 350	31.4	70.0	•	
2	720 X 400	31.4	70.0	•	
3	640 X 480	31.4	59.9	•	•
4	640 X 480	37.5	75.0	•	
5	800 X 600	35.1	56.2	•	
6	800 X 600	37.8	60.3	•	•
7	800 X 600	46.8	75.0	•	
8	832 X 624	49.7	74.5	•	
9	1024 X 768	48.3	60.0	•	•
10	1024 X 768	56.4	70.0	•	
11	1024 X 768	60.0	75.0	•	
12	1152 X 864	67.5	75.0	•	
13	1152 X 870	68.6	75.0	•	
14	1280 X 960	60.0	60.0	•	•
15	1280 X 1024	63.9	60.0	•	•
16	1280 X 1024	79.9	75.0	•	
17	1680 X 1050	64.7	60.0	•	•
18	1600 X 1200	75.0	60.0	•	•
19	1920 X 1200	84.0	59.9	•	•
20	480 i/p		50/60	Video Mode	
21	720 i/p		50/60		
22	1080 i/p		50/60		

3-6. User's Environment

Recommended Ergonomic User's Environment

- Viewing angle of the monitor should be between -3~17 degree.

HYUNDAI IT CORP.

Kensington Security (Locking) Slot

VESA MOUNT'G

- This display unit supports a Kensington-type security device to secure your monitor. Kensington lock is not included.
- To purchase and install the Kensington locking device, please refer to the following contact information.

  > *** Kensington Technology Group**
  > · *Address : 2000 Alameda de las Pulgas 2F san mateo, California 94403-1289*
  > · *Tel : +1 650 572 2700   · Fax : +1 650 572 9675   · Web-site : www.kensington.com*

- This display unit supports VESA FPMPMI standard for 100mmx100mm screw mounting by giving 4 screw holes inside the base stand of the unit.
- For buying VESA Flat Panel Monitor Mounting Devices, please contact following information.

  > *** Ergotron, Inc.**
  > · *Address : Ergotron Europe Kuiperbergweg 50 1101 AG Amsterdam The Netherlands*
  > · *Tel : +3 1 20 696 60 65 · Fax : +3 1 20 609 04 59· E-mail : info.eu@ergotron.com*

Desk Mount

Wall Mount

![HYUNDAI IT CORP.]

4. Adjusting the picture

You can adjust the screen display by using the buttons located below the screen.

PICTURE

BRIGHTNESS		100
CONTRAST		50
H.POSITION		60
V.POSITION		96
CLOCK		50
PHASE		45
AUTO ADJUST		50

RESOULTION : 1920x1200 60Hz   VAG

AUTO ADJUST   SOURCE   VOLUME

MENU   SELECT   ∨   ∧   —   +   ⏻

TOUCH SENSOR

The second Menu from the OSD can't be chosen in digital-mode.

HYUNDAI
HYUNDAI IT CORP.

4-1. Using the On Screen Display

To make adjustments in the On Screen Display, follow these steps:

MENU ➡ ⋀ ⋁ ➡ SELECT ➡ ➖ ➕ ➡ MENU ➡ MENU

1. Push the MENU button to call the OSD to the screen.
2. Push the ⋀ or ⋁ button to choose the item you want to adjust. The selected item is highlighted.
3. Push the SELECT button to adjust the highlighted item.
4. Use the ➖ or ➕ button to adjust the selection.
5. Push the MENU button to return to the previous menu if you are in a submenu.
6. The display unit automatically saves the new settings in 1 second after your last adjustments and the menu disappears. You can also push the MENU button to make the menu disappear.

MENU SELECT ⋁ ⋀ ➖ ➕ ⏻

4-2. Direct access buttons

SELECT   **AUTO ADJUST**
At first display a full screen such as Window's back ground.
Push the button SELECT(AUTO) to adjust the shape of screen automatically.

➖   **VOLUME**
Use the button ➖ to select the Volume adjustment.
Adjust with ➖ or ➕ button.

⋀   **SOURCE**
Use the button ⋀ to switch the other input from current input.
(VGA -> Component -> DVI -> HDMI -> VGA)

HYUNDAI
HYUNDAI IT CORP.

4-3. OSD Adjustments
• Picture

PC

PICTURE

BRIGHTNESS		100
CONTRAST		50
H.POSITION		60
V.POSITION		96
CLOCK		50
PHASE		45
AUTO ADJUST		50

BRIGHTNESS
To adjust the brightness of the screen.

CONTRAST
To adjust the contrast of the screen.

H.POSITION
To move image left and right.

V.POSITION
To move image up and down

CLOCK
To adjust the horizontal size of the entire screen image.

HDMI MODE

PICTURE

BRIGHTNESS		100
CONTRAST		50
SATURATION		60
SHARPNESS		96

BRIGHTNESS
To adjust the brightness of the screen.

CONTRAST
To adjust the contrast of the screen.

SATURATION
To adjust color density.

SHARPNESS
To adjust sharpness of screen.

HYUNDAI
HYUNDAI IT CORP.

• Color

PC ANALOG

COLOR

STANDARD   REDISH   BLUISH

USER

RED   100
GREEN   50
BLUE   60

AUTO COLOR

STANDARD
For general Color tone.

REDISH
For Redish color with warm tone.

BLUISH
For Bluish color with cool tone.

USER
For adjusting degree of RGB as User wants

AUTO COLOR
TO adjust the horizontal size of the entire screen image.

HDMI MODE

COLOR

STANDARD

SHARPEN

BLUR

S**TANDARD**
For general Color tone.

DYNAMIC
To be Sharper image.

MILD
To be Smoother image.

• Sound

• Setting

SOUND

VOLUME	100
BASE	50
TREBLE	60
BALANCE	96
MUTE	15

VOLUME
To adjust the audio volume level.

BASE
To emphasize low frequency audio.

TREBLE
To empahsize high frequency audio.

BALANCE
To use this function to balance sound from the left and right speakers.

MUTE
Audio ON or OFF

SETTING

OSD CONFIGURATION	▶
INPUT SOURCE	VGA
DISPLAY CONTROL	▶
GENERAL RECALL	▶

OSD CONFIGURATION

- OSD TIMER
   To adjust OSD Display time on the screen.
- OSD POS
   To adjust OSD Display position on the screen.
- TRANSPARENT
   To adjust the transparency of OSD window.
- OSD ZOOM
   To adjust the size of OSD window.

INPUT SOURCE
To switch between current source and other input source. (VGA/DVI/COMP/HDMI)

HYUNDAI
HYUNDAI IT CORP.

• Language

DISPLAY CONTROL
If you choose DISP. CONTROL on the OSD menu, you can adjust the following

<PC>
- Full (16:10) : Shows full screen regardless of screen size.
- 4:3 : Displays image at 4:3 ratio.

<HDMI Mode>
- Full (16:10) : Shows full screen regardless of screen size.
- 16 : 9 : Displays image at 16:9 ratio.
- 4:3 : Displays image at 4:3 ratio.
- 1:1 : Displays image according to actual input pixels.
- Zoom1 : Enlarges image by 20%
- Zoom2 : Enlarges image by 25%.

GENERAL RECALL
Recall the saved initial data

LANGUAGE	
ENGLISH	SUOMI
DEUTSCH	DANSK
FRANÇAIS	PORTUGÊS
ITALIANO	Русский
ESPAÑOL	한국
DUTCH	日本語
SVENSKA	语言

LANGUAGE
You can select the language in which adjustment menus are displayed. The following languages are available. English, German, French, Italian, Spanish, Dutch, Swedish, Finnish, Danish, Portuguese, Russian,Korean,Japanese,Chinese.

5. Display power management

Reducing power consumption

If the power management function of your computer is enabled, your monitor turns on and off automatically. You can control power management features from your computer.

Your computer may have power management features which enable the computer or monitor to enter a power saving mode when the system is idle. You can reactivate the system by pressing any key or moving the mouse.

Mode	LED	Power consumption
Normal	Blue	50W(Typ)
off	RED(Orange)	≤ 1 W(Typ)
Unplugged	Not illuminated	0 W

! The power button does not disconnect the monitor from the mains. The only way to isolate the monitor completely from the mains supply is to unplug the mains cable.

HYUNDAI
HYUNDAI IT CORP.

6. Troubleshooting

If your monitor is not functioning properly, you may be able to solve the problem by following the suggestions below :

Problem	Possible solution
Blank screen	If the power LED is not lit, push the Soft power switch or check the AC cord to turn the monitor on. If the display unit is powered through the computer, check that the computer is switched on. The display unit might be in standby mode. Push one of the keyboard keys. Check that the keyboard is properly connected to the computer. Check that the signal cable connector is properly connected and that the connection pins are not bent or damaged. If the connector is loose, tighten the connector's screws. Check that the power cable is correctly connected to the display unit and to the power outlet.
Error message: *Video mode not supported*	Check the resolution and the frequency on the video port of your computer. Compare these values with the data in the Preset Timing Table.
The display does not enter power management mode	The video signal from the computer does not comply with VESA DPMS standard. Either the computer or the graphics adapter is not using the VESA DPMS power management function.

Problem	Possible solution
Color defects	**Check that the signal cable connector is properly connected and that the connection pins are not bent or damaged. Try another color temperature.**
Size, position, shape or quality unsatisfactory	**Adjust the picture characteristics as described in the section *OSD Adjustment(4-3).***
Duplicated images	**A problem with your graphics adapter or display unit. Contact your service representative.**
Image is not stable	**Check that the display resolution and frequency from your PC or graphic adapter is an available mode for your monitor.** **In your PC, you can check through Control panel, Display, Settings.** **If the setting is not correct, use your computer utility program to change the display settings.**
Message : *No signal*	**Check that the signal cabel connector is properly connected and that the connection pins are not bent or damaged.** **If the connector is loose, tighten the connector's screws.** **Check that the computer is switched on.**
The power LED is a orange color	**To enter a power saving mode. You can reactivate the system by pressing any key or moving the mouse.**

HYUNDAI
HYUNDAI IT CORP.

Contacting service

Problem	Possible solution
The power LED is a orange color	LED Indicator can be orange color on changing of video mode or Input Signal.

Check the Resolution and the frequency on the video part of your computer. Compare these values with the data in the Preset Timing Table. |

If the above troubleshooting hints do not help you find a solution to the problem, contact an authorized service agent. If the monitor is sent for service, use the original package if possible.

Unplug the display unit from the power outlet and contact a service agent when:

- The monitor does not operate normally according to the operating instructions.
- The monitor exhibits a distinct change in performance.
- The monitor has been dropped or the cabinet has been damaged.
- The monitor has been exposed to rain, or water or liquid has been spilled onto the monitor.

HYUNDAI
HYUNDAI IT CORP.

7. Specifications

LCD	22" viewable, Diagonal, Pixel pitch 0.270mm, A-si TFT
Display area	473.78(H) X 298.1(V), 22" Diagonal
Number of color	16.7 million colors (true 8-bit color)
Input signals	R.G.B Analog, 15pin D-sub / DVI-D / HDMI
Frequency rate	Horizontal : 30.0 to 80.0Khz, Vertical : 56 to 75hz
Maximum bandwidth	162Mhz
Maximum resolution	1920 X 1200 @ 60hz
Recommanded resolution	1920 X 1200 @ 60hz
Input voltage	100-240V AC, 2.0A
Power consumption	50W(Typ.)
Power management	VESA DPMS
Plug & Play	VESA DDC 1/2B
OSD menu	BRIGHTNESS, CONTRAST, H/W POSITION, CLOCK, PHASE, AUTO ADJUST AUTO COLOR, SOUND, OSD CONFIGRATION, INPUT SOURCE, DISPLAY CONTROL, GENERAL RECALL, LANGUAGE
Audio system	2ch X 3watts / Ear Phone Jack
VESA FPMPMI	75mm X 75mm screw mounting
Ergonomics, Safety and EMC	Energystar cTUVus, TUV-GS, CB, FCC, CE, VCCI, GOST
Operating Temperature	5 ~ 40º C
Weight	9.9Kg unpacked, 13.8Kg packed
Dimensions (W X H X D mm)	200 X 494 X 240 mm

- *Specification is subject to change without notice.*
- *HYUNDAI IT CORP. specification on "dead pixel" of LCD Panel applies to ISO 13406-2 Standard.*