Security

1.Move the Cursor & Select a "Security".

Input Security related information.

Security
1.Certificates
2.Change Auth. Pin
3.Change singText Pin
4.Session info
5.Current Certifi
6.Contracts
Back

Certificates : To view Certificate necessary to setup Connection.
Contracts : To view Contracts necessary to setup Connection.

Browser Options

1.Press ⌒, 2ABC, 1☆, 6MNO, 4GHI to select "Browser Options".

To set up Browser function related Options.

Browser Options
1.Enable CSS
2.Enable Refresh
3.Enable Narrow Rende
4.Show Images
5.Show Movies
6.Play sounds
Back

Enable CSS : To set up using CSS or not (On/Off).
Enable Refresh : To set up Refresh function (On/Off).
Enable Narrow Rend : To set up Narrow Rend function (On/Off).
Show Images : To select/setup printing Images function (Never/Ask/Always).
Play Sound : To select/setup Sound function (Never/Ask/Always).
Load Object With MIME : To select/setup Object Load function (Never/Ask/Always).
History size : Number of link you visited before.

Rename Profile

1.Press ⌒, 2ABC, 1☆, 6MNO, 5JKL to select "Rename Profile".
To change the name of selected/setup Profile.

Rename profile ABC

OK   Cancel

Cache

1.Press ⌒, 2ABC, 1☆, 6MNO, 6MNO to select "Cache".
To select whether load Internet page or not from Cache.

Cache
1.Cache Mode
2.Clear Cache

Back

Cache mode : To set up Cache mode (On/Off).
Clear cache : To clear contents of Cache.

Cookies

1.Press ⌒, 2ABC, 1☆, 6MNO, 7PQRS to select "Cookie".

Cookies
1.Enable Cookies
2.Clear Cookies

Back

Enable Cookies : To select which Cookie may remain.
Clear Cookies : To clear Cookies saved in the browser.

Push Settings

1.Press ⌒, 2ABC, 1✱, 6MNO, 8TUV to select "Push Settings".

Push SL Settings : WAP Push Service Setup Function.
-Never: Set the selected Push message cannot be loaded through the browser.
-If On Same Host: Permit if currently visited page is the same host with it.
-Always: Always permitted.

Push Security : Security related setup function of WAP Push Service.
-Never Accept: Do not accept any push message.
-Accept authentication: Accept if certified host.
-Accept Non Wap: Accept push message from currently visited host.
-Accept Always: Accept all available messages.

Push Settings
1.Push SL Settings
2.Push Security

Back

Clear Recent Pages

1.Press ⌒, 2ABC, 1✱, 6MNO, 9WXYZ to select "Clear Recent Pages".

To delete URL List on History.

OFFLINE PAGES

1.Press ⌒, 2ABC, 1✱, 7PQRS to select "Offline Pages".
 Change current accessing site into Offline.
2.Select Save Page Offline.
3.Enter Title for Save Page Offline.
4.Press ◯ to save it.

Offline Pages
1.Save Page Offline

Menu   Back

PUSH

1.Press ⌒, 2ABC, 2ABC to select "Push".

Press ⌒ to select one of the following options.

Delete all
Sort : Sort by date / sort by type / Sort by sender

Massenger menu
📁 Inbox
📁 Drafts
📁 Sent
📁 Templates
📁 Friends
📁 Fun
Menu   Back

ORGANIZER

The Organizer is a practical tool that will help you to keep track of your appointments and alert you of meetings, celebrations, events etc.

CALENDAR

To set and view appointments.

1.Press ✆ , `3DEF` , `1` **to select "Calendar".**

```
📅 Calendar
1.Day view
2.Month view
3.New
4.Delete
                    Back
```

DAY VIEW

1.Press ✆ , `3DEF` , `1` , `1` **to select "Day View".**

2.Use ◉ **and** ◉ **to select a schedule and press** ○ **to view it.**

In Day view, you can check appointments for the day.
You can scroll through the entries and use [○] to view an appointment.
Press [✆] to add an appointment and edit or delete it.

```
📅 Fri. 2, Jan.
📧 13:29-14:00
   Sales meeting
🎁 15:30-20:23
   Tom's birth
Options          Back
```

Press ✆ **to select "Option".**

Month : To move to 'Month view'.
New : To add an appointment.
        You are to select one of the following categories.
        (Meeting/ Birthday / Memo)
Delete : To delete a selected appointment.
View : To display a selected appointment.

ORGANIZER

MONTH VIEW

1.Press ✆ , `3DEF` , `1` , `2ABC` **to select "Month View".**

```
January 2004
S  M  T  W  T  F  S
            1  2  3
4  5  6  7  8  9  10
11 12 13 14 15 16 17
18 19 20 21 22 23 24
25 26 27 28 29 30 31
Options          Back
```

- A calendar is displayed with appointments. the date with an appointment is shown in green color, while a selected date is in violet.
- The wallpaper for calendar changes as a new season is selected.

2.Use ◉ **to select a date and press** ○ **to view appointments on the particular date.**

Press ✆ **to select "Option".**

Day view : To move to 'Day view'

New : To add a new appointment.

3.Select an appointment and press ✆ **to do the following options.**

Press ✆ **to select "Option".**

New : To add an appointment.

        You are to select one of the following categories. (Meeting/ Birthday / Memo).

Delete : To delete a selected appointment

View : To display a selected appointment.

ORGANIZER

NEW

1.Press 📞 , 3ᵈᵉᶠ , 1ᵃᵇ , 3ᵈᵉᶠ **to select "New".**

In 'New' you can enter a new appointment.
Define it as a Meeting, Birthday or a Memo.
Select one and enter the relevant
information in the text editor.
Use [⊙] to scroll through the entry fields:

①.**Subject**
To enter a title for an appointment.

②.**Start and End date,**
③.**Start and End time.**
To set a date and a time to start or end an appointment

④.**Reminder time**
To set a reminder to give you an alert to appointment.

ORGANIZER

DELETE

1.Press 📞 , 3ᵈᵉᶠ , 1ᵃᵇ , 4ᵍʰⁱ **to select "Delete".**

2.Select one of the following items and press ◯ **.**

1. All : Delete all appointments.
2. Week Old : Delete the appointments that is a week old.
3. Month Old : Delete the appointments that is a month old.

3.Press 📞 **to confirm it.**

ORGANIZER

TASKS

To put down things to remember.

1.Press ⌒, 3def, 2abc **to select "TASKS".**

The Tasks list is an electronic notepad that will help you to remember things to do. The list is accessed in the Organizer folder.

*If no tasks are entered in the list, the screen will display "No entries".*

NEW

1.Press ⌒ **to select "Options".**

2.Select a "New" item and press ⌒ **to create a new task.**

3.Move to each field to enter data.

1. Subject : Enter a title for a task.
2. Due Date : Enter a due date for a task.
3. Reminder : Mark it up and you are prompted to enter its date and time.
4. Reminder Date
5. Reminder Time

If one or more tasks are entered, you can choose among the following options: Delete all, Delete, New

You can enter up to 10 different tasks, each with a maximum 20 characters, and set an alarm to remind you.

ORGANIZER

ALARM

1.Press ⌒, 3def, 3def **to select "Alarm".**

TIME

1.Press ⌒, 3def, 3def, 1 **to select "Time".**

2.Enter a time.

SOUND

1.Press ⌒, 3def, 3def, 2abc **to select "Sound".**

Sound - Alarm1~5.

ALARM ON

1.Press ⌒, 3def, 3def, 3def **to select "Alarm on".**

2.To mark up 'Alarm on' to enable the alarm.

ORGANIZER

CALCULATOR

To use the calculator.

1.Press 📱 , 3ᵈᵉ , 4ᵈᵉ **to select "Calculator".**

Press [📱] to clear a digit or press and hold [📱] to clear all inputs.

Enter a figure and press a +, -, *, / as a assigned in navigation keys.
Enter another figure, then press ◯ .
The result will be show on the bottom line.

Example

Enter 200.
Use 🎛 to moved to a '+' and press ◯ select it.
Enter 25 then press ◯ .
The result 225 will be show in bottom line.

If you want to continue the calculation, do not select =,
To finish the calculation, select 📱.

GAMES

MINI GOLF

1.Press 📱 , 4ᵈᵉ , 1ᵃ **to select "Minigolf".**

Let 's play the simplified golf game using your handset.
This is a miniature golf.
Only putter is used.
Put the ball in the hole by avoiding walls and barriers.
There are holes with pars 3 to 5.A player with the least number of hits,minus even par numbers in each hole,becomes a winner.
Regardless of total score,each hole has its winner for the hole and gains 1 point.
Stroke(1P,2P),Match Play(2P)are available.

GAMES

MIRROR IN ACTION

1.Press 🔘 ,`4₄`,`2₂` **to select "Mirror In Action".**

The objective is to shoot down enemy ships using reflecting mirrors to aim the lasers.
Be careful because when you use a laser you need to recharge it.
During this time your enemy has a chance to regroup and attack you when you are not in a position to defend yourself.
As you move onto subsequent levels the mirrors are positioned at different angles making your task harder.

GAMES

PUSH MAN

1.Press 🔘 ,`4₄`,`3₃` **to select "Parking War".**

The objective is to unlock the traffic grid by carefully maneuvering the cars and trucks around each other towards the exit.
The game is time based so there is no time to lose as you test your wits moving the vehicles back and forth to smooth out the jam as quickly as possible.

MYPHONE The default settings with regard to the sounds and display are easily changed.

1.Press 📞 , 5ᴶᴷ , 1☆ **to select "Audio".**

Audio
1.Incoming Call
2.SMS alert
3.Keypad tone
4.Info Tones
5.Connect Tone
6.Folder tune

Back

INCOMING CALL

1.Press 📞 , 5ᴶᴷ , 1☆ , 1☆ **to select "Incoming Call".**

1☆ **Alert Tune** - Select one among 10bells, 14melodies and some downloaded melodies.

2ᴬᴮᶜ **Alert Type** - Select one of the available options .
(1.Tone only / 2.Tone+Vib / 3.Tone after Vib / 4.Vibration Only)

3ᴰᴱᶠ **Volume** - Volume can be controlled in 7 levels through [🔘] and [🔘]

Icoming Call
1.Alert Tune
2.Alert Type
3.Volume

Back

MYPHONE

SMS ALERT

1.Press 📞 , 5ᴶᴷ , 1☆ , 2ᴬᴮᶜ **to select "SMS Alert".**

1☆ **Alert Tune** - 10 different SMS alert tunes.

2ᴬᴮᶜ **Alert Type** - Select one of the available options. (1.Tone only / 2. Tone +Vib / 3.Vibration)

3ᴰᴱᶠ **Volume** - Volume can be controlled in 7 levels through [🔘] and [🔘].

SMS alert
1.Alert Tune
2.Alert Type
3.Volume

Back

KEYPAD TONE

1.Press 📞 , 5ᴶᴷ , 1☆ , 3ᴰᴱᶠ **to select "Keypad tone".**

2.Select one of the available keypad tone type and press ⬭ **to save it.**

Keypad tone
1.Bolb tone
2.DTMF
3.Mute

Back

MYPHONE

INFO TONES

1.Press ⌒ , 5ᴬᴸ , 1ᴬᴮ , 4ᴳᴴ to select "Info Tones".

2.Select On or Off and press ◯ to save it.

Info Tones
1.On ⊙
2.Off ⊙
Back

CONNECT TONE

1.Press ⌒ , 5ᴬᴸ , 1ᴬᴮ , 5ᴬᴸ to select "Connect Tone".

2.Select On or Off to set call connection tone.
  Press ◯ to save it.

Connect Tones
1.On ⊙
2.Off ⊙
Back

FOLDER TUNE

1.Press ⌒ , 5ᴬᴸ , 1ᴬᴮ , 6ᴹᴺᴼ to select "Folder Tune".

2.Select One of the available Slide Tune and press ◯ to save it.

Folder Tune
1.On ⊙
2.Off ⊙
Back

MYPHONE

WALLPAPER

1.Press ⌒ , 5ᴬᴸ , 2ᴬᴮᶜ to select "Wallpaper".

2.Select the Image or Animations.

3.Select the desired Wallpaper using the ◉ and ◉ key.

4.Press the ⌒ or ◯ , then the Idle screen is changed.

Selections
1.Image
2.Animation
Select   Back

MYPHONE

GREETING

You can enter a greeting, set an animation for start-up or shutdown and set a greeting time.

1.Press 📞 , 5️⃣ , 3️⃣ **to select "Greeting".**

Greeting
1.Text
2.Selections
3.Greeting tone

Back

TEXT

1.Press 📞 , 5️⃣ , 3️⃣ , 1️⃣ **to select "Text".**

2.Enter a greeting of your own and press ⭕ **to save it.**

ABC..

Options   Back

SELECTIONS

1.Press 📞 , 5️⃣ , 3️⃣ , 2️⃣ **to select "Selections".**

2.You are to set one of the following options for either start-up or shutdown.

1.Start-up : Greeting / Animation / None
2.Shutdown : Animation / None

Selections
1.Start-up
2.Shutdown

Back

GREETING TONE

1.Press 📞 , 5️⃣ , 3️⃣ , 3️⃣ **to select "Greeting tone".**

2.On or Off to set a greeting tone when the phone is turned on.

Greeting tone
1.On
2.Off

Back

CALLER GROUPS

You can create Caller Groups from the contacts in your phone book to identify a caller by sound alone.

1.Press 📞 , 5ʲ , 4ᵍ **to select "Caller groups".**

Caller groups
1.Private
2.Business
3.Friends
4.Family
5.Others
Back

2.Use 🔘 **to moved to a caller group.**

3.Press ◯ **to select it.**

Private
1.Tune
2.SMS
Back

TUNE

1.Press 1ᵃ **to select "Tune".**

2.Select one of the available tunes and press ◯ **to save it.**

You can designate a tune for a group.

Tune
1.Bell 1
2.Bell 2
3.Bell 3
4.Bell 4
5.Bell 5
6.Bell 6
Play   Back

SMS

1.Press 2ᵃ **to select "SMS".**

2.Select one of the available alerts and press ◯ **to save it.**

You can designate a type of alert for a group.

SMS
1.SMS 1
2.SMS 2
3.SMS 3
4.SMS 4
5.SMS 5
6.SMS 6
Play   Back

LCD & LED

Your phone has a backlight LCD display with full graphic capability.
You can set contrast, backlight time and led light.
1.Press 📞 , `5 JKL` , `5 JKL` **to select "LCD & LED".**

BACKLIGHT TIME
1.Press 📞 , `5 JKL` , `5 JKL` , `1 ≋` **to select "Baclight time".**

2.Select one of the following backlight time and press ◯ **to save it.**

You can adjust how long the Backlight stays on. (20/40/60 seconds)

```
Backlight time
1.20 seconds
2.40 seconds
3.60 seconds

                    Back
```

LED LIGHT
1.Press 📞 , `5 JKL` , `5 JKL` , `2 ABC` **to select "LED light".**

2.mark it up to enable the LED service indicator.

```
     LCD & LED
1.Backlight Time
2.LED light

                    Back
```

FOLDER MANAGER

1.Press 📞 , `5 JKL` , `6 MNO` **to select "Folder manager".**

```
Massenger menu
📁 Inbox
📁 Drafts
📁 Sent
📁 Templates
📁 Friends
📁 Fun
Menu          Back
```

Press ✎ to select one of the following options.

Create new folder
Sort : Sort alphabetic / Sort by size / Sort by type / Sort by date

SETTINGS

The Settings menu is used to set basic parameters for the phone such as language, time & date, data transfer, security, network and call settings.

TIME & DATE

1.Press 📞 ,6ᴹⁿᵒ ,1ᵃˢ **to select "Time & date".**

Time & date
1.Set time/date
2.Summer time
3.World Time
4.Date format
Back

SET TIME / DATE

1.Press 📞 ,6ᴹⁿᵒ ,1ᵃˢ ,1ᵃˢ **to select "Set time / Date".**

2.You are to set the present time & date.

Set time/date
1.Time and Date
▶17:34
2.dd.mm.yyyy
▶02.01.2004
Back

84

SETTINGS

SUMMER TIME

1.Press 📞 ,6ᴹⁿᵒ ,1ᵃˢ ,2ᵃᵇᶜ **to select "Summer Time".**

2.Mark up 'Summer time' through ◯ **to apply daylight saving time.**

Box If you wish to apply daylight saving time

Time & date
1.Set time/date
2.Summer time
3.World Time
4.Date format
Back

WORLD TIME

1.Press 📞 ,6ᴹⁿᵒ ,1ᵃˢ ,3ᵈᵉᶠ **to select "World time".**

2.Use 🎛 **and** 🎛 **to select a timezone and press** ◯ **to save it.**

3.You are to select your current location.

World Time

(GMT) London
Back

DATE FORMAT

1.Press 📞 ,6ᴹⁿᵒ ,1ᵃˢ ,4ᵍʰⁱ **to select "Date Format".**

2.Select one of the date formats and press ◯ **to save it.**

Date format
1.DD.MM.YYYY
2.MM.DD.YYYY
3.YYYY.MM.DD
Back

85

SETTINGS

LANGUAGE

The display will change to the selected language.

1.Press ⌒ ,⁶ₘₒ ,²ₐᵦᵨ **to select "Language".**

2.Use ◉ **to select a language.**

3.Select one of the available languages and press ○ **to save it.**

4.The display will change to the selected language.

Language
1.Automatic
2.English
3.简体中文
Back

SETTINGS

DATA

You are set parameters for data transmission from your laptop or PC.

1.Press ⌒ ,⁶ₘₒ ,³ₐₑₚ **to select "Data".**

Data
1.Data cable
2.GPRS
Back

DATA CABLE

1.Press ⌒ ,⁶ₘₒ ,³ₐₑₚ ,¹ₐ **to select "Data Cable".**

2.Set each parameter and press ○ **to save it.**

- Bit rate : (300 / 1200~ / 115200)
- Reset : You are to reset it.

Data cable
1.Bitrate
2.Reset
Back

GPRS

1.Press ⌒ ,⁶ₘₒ ,³ₐₑₚ ,²ₐᵦᵨ **to select "GPRS".**

2.Set each parameter and press ○ **to save it.**

1. Attach on
2. Accept calls : You are to mark this up to enable it.

GPRS
1.Attach on:
2.Accept calls
Back

SETTINGS

SECURITY

1.Press 🔲 **, 6**, **4** **to select "Security".**

ENABLE PIN 1

1.Press 🔲 **, 6**, **4**, **1** **to select "PIN code 1".**

2.Mark it up to enable PIN code 1 and press ◯ **to save it.**

SETTINGS

CHANGE PIN1

1.Press 🔲 **, 6**, **4**, **2** **to select "Change PIN 1".**

2.Enter your old pin code followed by the new code.

3.Confirm it when prompted. Press ◯ **.**

That if you enter an incorrect PIN code three times in succession, your SIM card will lock and you must enter the PUK code to unlock. PIN and PUK codes are either supplied with your phone or must be obtained from your network provider or place of purchase.

SETTINGS

CHANGE PIN2

1. Press 📞, 6_{mno}, 4_{ghi}, 3_{def} to select "Change PIN 2".

2. Enter your old pin code followed by the new code.

3. Confirm it when prompted. Press ⭕.

SETTINGS

NETWORK

1. Press 📞, 6_{mno}, 5_{jkl} to select "Network".

SELECTION

1. Press 📞, 6_{mno}, 5_{jkl}, 1 to select "Select network".

2. Select Automatic or Manual.

SETTINGS

PREFERRED NET
1.Press 🔲 , `6` , `5` , `2` **to select "Preferred net".**

The phone will search this list from the top. Left softkey options roll-up enables you to Add or Insert a new network. If you use Add, the new network will be added to the end of the list (having the lowest priority). Insert will insert the network in the list where the cursor is placed.

```
        Network
1.USA T-MObile u...
2.USA T-MObile u...
3.USA T-MObile u...
4.USA 310
5.USA T-MObile u...
6.USA T-MObile u...
Options          Back
```

ADD NETWORK
1.Press 🔲 , `6` , `5` , `3` **to select "Add network".**

To add a new network, start by selecting an empty network entry from the Add network menu. Press OK. A text editor will appear. Enter the name(input english) of the network followed by the Mobile Country Code (MCC) and the Mobile Network Code (MNC). This information is supplied by your network operator.

```
        Network
1. ...............
2. ...............
3. ...............
4. ...............
5. ...............

Options          Back
```

BAND
1.Press 🔲 , `6` , `5` , `4` **to select "Band".**

2.Select one of the band and press ⬤ **to save it.**

```
        Network
1.GSM900/DCS18..
2.PCS1900



              Back
```

SETTINGS

CALL SETTINGS
1.Press 🔲 , `6` , `6` **to select "Call settings".**

```
     Call settings
1.Call forward
2.Call waiting
3.Optional func.
4.Call barring
5.Call time
6.DTMF tones      □
              Back
```

CALL FORWARD
1.Press 🔲 , `6` , `6` , `1` **to select "Call forward".**

```
     Call forward
1.Unconditional
2.All unanswered
3.No answer
4.Not reachable
5.Busy
6.Status all
              Back
```

①.**Unconditional:**
   To forward all incoming calls to a specified number.
②.**All unanswered:**
   To forward all calls that you do not answer within a specified period of time.
③.**No reply:**
   To forward calls those are not replied.
④.**Not reachable:**
   To forward calls when you are out of network range.
⑤.**Busy:**
   To forward calls when your phone is busy.
⑥.**Status all:**
   To summarize the status of call forward options.
⑦.**Cancel all:**
   To cancel all call forward settings

   A specific number can be designated for each option, and you can activate, view or cancel the present status. Follow the on screen instructions.

SETTINGS

CALL WAITING

1.Press ⌇ 6ᴍɴᴏ 6ᴍɴᴏ 2ᴀʙᴄ **to select "Call waiting".**

This function notifies you of another call during a telephone conversation. Enter the menu to Activate or Cancel Call waiting or to see the Status. If Call waiting is active, and you are called during a conversation, you will hear a faint ringing tone in the background. To answer the new caller without losing contact with the original party:

-Enter Options roll-up menu.
Select Switch calls.
-conduct the conversation with the new party and select Switch calls to return to the first caller.
Select Join calls to conduct a three-party conversation.

```
Call waiting

1.Activate
2.Cancel
3.Status



                    Back
```

OPTIONAL FUNCTION

1.Press ⌇ , 6ᴍɴᴏ 6ᴍɴᴏ 3ᴅᴇғ **to select "Optional func.".**

This menu contains various settings to facilitate daily use.

```
Optional func.

1.Redial          ☐
2.Shortcut dial   ☐
3.Any key answer  ☐



                    Back
```

94

SETTINGS

Redial

1.Press ⌇ , 6ᴍɴᴏ , 6ᴍɴᴏ , 3ᴅᴇғ , 1 **to select "Redial".**

Activates redialing of your last unsuccessful call. The number will be redialed after 5 seconds (1 time), after 1 minute (3 times) and after 3 minutes (10 times). If this sequence is completed without connection established, the number must be manually dialed for a new attempt.

To manually abort the redial sequence, press [📞].
To manually redial last number called, press [◯] twice in a row.

```
Optional func.

1.Redial          ☑
2.Shortcut dial   ☐
3.Any key answer  ☐



                    Back
```

Shortcut dial

1.Press ⌇ , 6ᴍɴᴏ , 6ᴍɴᴏ , 3ᴅᴇғ , 2ᴀʙᴄ **to select "Shortcut dial".**

If you activate Shortcut dial, you can dial phone numbers from the Shortcut list by pressing just one or two digits.

```
Optional func.

1.Redial          ☑
2.Shortcut dial   ☑
3.Any key answer  ☐



                    Back
```

Any key answer

1.Press ⌇ , 6ᴍɴᴏ , 6ᴍɴᴏ , 3ᴅᴇғ , 3ᴅᴇғ **to select "Any key answer".**

Set the phone to answer a call with any key, (except), e.g. the earpiece volume control on the side, to answer your calls.

```
Optional func.

1.Redial          ☑
2.Shortcut dial   ☑
3.Any key answer  ☑



                    Back
```

95

SETTINGS

CALL BARRING
1.Press ⌒ , 6ᴹᴺᴼ 6ᴹᴺᴼ 4ᴳᴴᴵ **to select "Call barring".**

You can lock the telephone to reject incoming calls or bar outgoing calls, domestic or international.
Call barring is a password protected network service, and details should be acquired from your network.

①.**Cancel all -** To cancel all call barring settings.

②.**Outgoing calls -** To cancel all call barring features of outgoing calls, or decide what
type of outgoing calls is to be barred.
(1.Cancel all / 2.All calls / 3.All internat. / 4.Except to home)

③.**Incoming calls -** To cancel all call barring features of incoming calls or decide what
type of incoming calls is to be barred.
(1.Cancel all / 2.All incoming / 3.When abroad)

④.**Password -** To set a password.

Call barring
1.Cancel all
2.Outgoing calls
3.Incoming calls
4.Password
Back

SETTINGS

CALL TIME
1.Press ⌒ , 6ᴹᴺᴼ 6ᴹᴺᴼ 5ᴶᴷᴸ **to select "Call time".**

You can keep track of your calling expenses by setting the "Call time" feature. Scroll to Billing.
Press [○]. Enter the submenus:

①.**Total calls** - To view the total amount of time and units used.

②.**Last call** - To view the duration of the last call.

③.**Set max units** - To set a maximum of units available for a call.

④.**Units left** - To view the number of units left on your account.

⑤.**Price/unit** - To enter a network price for the units.

⑥.**Currency** - Displayed if supported by your network.

Call time
1.Total calls
2.Last call
3.Set max units
4.Units left
5.Price/unit
6.Currency
Back

DTMF TONE
1.Press ⌒ , 6ᴹᴺᴼ 6ᴹᴺᴼ 6ᴹᴺᴼ **to select "DTMF tone".**

Call settings
1.Call forward
2.Call waiting
3.Optional func.
4.Call barring
5.Call time
6.DTMF tones
Back

Enabling DTMF tones allows you to remote control various telephone connected
devices, e.g. listen to your home telephone answering machine, or charge your
SIM.

Activates key lock after 30 sec. of idleness.

SETTINGS

RESET SETTINGS

1.Press ⌒, 6ᴹ, 7ᴾᴼᴿˢ **to select "Reset settings".**

Return all settings to factory defaults.
The power goes off automatically.

CHAPTER 4

PHONEBOOK

•Look up

•New

•PB Settings

•Voice mail no.

PHONEBOOK

Your can use either the SIM card or the built-in Contacts database as your Phonebook. The database can store up to 250 contacts, with three phone numbers per contact along with the contact's complete postal address and email address. Number of contacts on the SIM card depends on your network. Choice of phonebook is the Options soft key menu in look up menu. (Select use SIM/Use Phone)

PHONEBOOK

LOOK UP

When you select "Use SIM" in options. (Press)

1. Press , to select "SIM: Look up".

2. Scroll to find the desired contact and press .

3. Press to make a call.

Press [ ]and you will see the following items displayed.
New
Use phone
Delete
Edit
Search
View
Call

SIM: Look up
james
John
Jane
Options   Back

When you select "Use Phone" in options (Press)

1. Press , to select "Look up".

2. Scroll to find the desired contact and press .

3. Press to make a call.

Press [ ]and you will see the following items displayed.
New
Use SIM
Sorting
Delete
Edit
Search
View
Call

Look up
james
John
Jane
Options   Back

To add a contact to the SIM phonebook:

1.Press 🔘 , 2ᵃᵇᶜ .

When "Use SIM" is selected.

1.Move to each field and press ◯ to enter its information accordingly.

- A text editor appears.
- Enter a name and press [◯].
  Scroll [🔘].
- Enter a phone number and press [◯].

2.Press ⌒ to save it after entering information.

If you have chosen Phone as your phonebook, up to three numbers can be entered along with address information for each contact.

When "Use Phone" is selected.

1.Move to each field and press ◯ to enter its information accordingly.

All the above data can be entered.
1.First name 2.Last name 3.Home 4.Mobile 5.Work 6.Calling group
7.Address 8.Zip code 9.City 10.Province 11.Country 12.E-mail

2.Press ⌒ to save it after entering information.

If a different SIM card is inserted in the phone, you will be alerted of the option to copy data from this. You may also copy data to SIM cards, thus enabling you to share contact information with friends and colleagues. Copy features are located in the PB Settings submenu. (Optional)

PB SETTINGS

To alter settings in the Phonebook:

1.Press ⊙, 3ᵈᵉᶠ .

SHORTCUT DIAL

1.Press 1ᵃᵇ **to select "Shortcut dial".**

Make calls using only one or two keys. Define a key combination (2-21) for your most accessed contacts. To include or remove a contact in the shortcut dial list, select a position and:

-Select New or Delete in the Options softkey menu.

-Choose the appropriate contact from the phone book.
 Press [○].
-Any previous contact on the selected position will be overwritten.

If you select SIM as your Phonebook, you will not be able to use Contacts database features (three phone numbers, address information), but still allowed to use caller groups or shortcut dial.

FIXED LIST

1.Press 2ᵃᵇᶜ **to select "Fixed list".**

Use this to create a list of allowed numbers. When Active ☑ is ticked, the user can only access the listed numbers. Requires PIN 2 (see p. 90).

BARRED LIST

1.Press 3ᵈᵉᶠ **to select "Barred list".**

Use this to create a list of barred numbers (if supported by network).
If activated, the user can not access barred numbers. Requires PIN 2.

OWN NUMBER

1.Press 4ᵍʰⁱ **to select "Own number".**

Store your own number for future reference. Some SIM cards will install your phone number automatically. If yours is not, simply enter it in the editor and press [○].

PHONEBOOK

MEMORY STATUS

1.Press `5ⁿ` **to select "Memory status".**

Displays the used and free memory available in the respective phonebooks.
Reset Phone memory or SIM memory on left softkey.
Be advised that this will erase all entries in the Phonebook that is reset.

Memory status
Phone memory:
In use: 0
Free: 250
SIM card
In use: 0
Free: 250
Options   Back

LOCATION

1.Press `6ⁿ` **to select "Location".**

2.Select Use Phone or Use SIM.

Location
1.Use Phone
2.Use SIM
Back

PHONEBOOK

VOICE MAIL NO.

1.Press ⊙ , `4ⁿ` .

2.Enter a Voice mail number.
 - The options softkey allows you to do the following items.
   (Lookup / Back / Save)

Voice mail no.
Enter new number
Options   Back

> **Service numbers.**
> *This is a network service and the menu will only appear if your network operator supports this service.*
> *The menu may contain various services, depending on the network.*

MEMO

CHAPTER 5

MISCELLANEOUS

•Menu summary

•Cellular phone in brief

•Abbreviations and acronyms

•Questions and answers

•Technical data

Messages
SMS
Write new SMS
SMS Inbox
SMS Outbox
Delete
Delete Inbox
Delete Outbox
Delete all
SMS Template
SMS Settings
Format
S.C. number
Validity
SMS Bearer
Selections
SMS class 0
Verify send
Use template
Reply path

MMS
New message
Inbox
Drafts
Sent
Templates
Outbox
Settings
Exit
Cell Broadcast
Read
CB Settings
CB Enabled
Channels
Languages

Internet
Wap
Homepage
Bookmarks
Recent pages
Enter address
Resume
Settings
Offline pages

PUSH
Inbox
Drafts
Sent
Templates
Friends
Fun
Important

Organizer
Calendar
Day view
Month view
New
Meeting
Birthday
Memo
Delete
All
Week old
Month old
Tasks
Alarm
Alarm 1~3
Select all
Cancel all
Calculator

Games
Mini Golf
Mirror in action
Parking war

Myphone
Audio
  Incoming call
    Alert tune
    Alert type
    Volume
  SMS Attention
    Alert tune
    Alert type
    Volume
    Duration
  Keypad Type
    Natural Tone
    DTMF
    Mute
  Info Tones
    On
    Off
  Connect Tone
    On
    Off
  Folder tune
    On
    Off
Wallpaper

Greeting
  Text edit
  Selections
  Greeting tone
Caller groups
  Private
  Business
  Friends
  Family
  Others
LCD & LED
  Contrast
  Backlight time
  LED light
Folder manager

Settings
Auto key lock
Time & Date
  Set time/Date
  Summer Time
  Time zone
  Date format
Language
Data
  Data cable
    Bitrate
    Reset

GPRS
  Attach on
  Accept calls
Security
  PIN Code 1
  Change PIN 1
  Change PIN 2
Network
  Select Network
    Automatic
    Manual
  Preferred net
  Add network
Call settings
  Call Forward
    Unconditional
      Activate
      Cancel
      Status
    All Unanswered
      Activate
      Cancel
      Status

    No Reply
      Activate
      Cancel
      Status
    Not Reachable
      Activate
      Cancel
      Status
    Busy
      Activate
      Cancel
      Status
    Status All
    Cancel All
  Call waiting
    Activate
    Cancel
    Status
  Optional func.
    Redial
    Shortcut Dial
    Any key answer

MENU SUMMURY

Call Barring
    Cancel All
    Outgoing Calls
        Cancel All
        All Calls
        All Internat.
        Except to Home
    Incoming Calls
        Cancel All
        All Incoming calls
        when abroad
    Password
Call time
    Total calls
    Last call
    Set max units
    Units left
    Price/Unit
    Currency
DTMF tones
Reset settings

Phone Book
    Look Up
    New
    Settings
        Shortcut dial
        Fixed list
        Barred list
        Own Number
        Location
        Memory status
    Voice Mail no.

MISCELLANEOUS

CELLULAR PHONE IN BRIEF

Your cellular phone is essentially a highly sophisticated radio, basically no different from any other two-way radio system.
The ingenuity of the cellular system lies in the splitting of the broadcasting environment into a multitude of relatively small cells with low-power transmitters.

This "Cellular approach" to radio communication allows for extensive frequency reuse so that millions of people can use their mobile phones simultaneously although the number of frequencies are limited. The broadcasting cells are commonly illustrated as hexagons, typically 10 square miles in area with the base station in the center. This arrangement allows for non-adjacent cells to use the same frequencies without risk of interference.

Your cellular phone is in constant contact with the nearest base station. As you move from cell to cell, e.g. while driving in your car, the base station you are approaching takes over when you are within reach. This happens within split seconds without your noticing it.
All you experience is a stable and clear connection.

However, not all network operators provide the same coverage in all areas. Hence, if you travel near the limit of your network's coverage, you may experience difficulties in maintaining the connection.
The same may hap pen if the radio signal is blocked by obstacles such as high trees, hills or buildings, or if you are inside a heavily reinforced concrete building.

MISCELLANEOUS

To remedy the situation move closer to the nearest mast if possible or seek higher ground. If you are inside a building, try moving towards a window.

What is roaming? Roaming is the technique that allows subscribers to move from one cell to another or from one network to another without affecting the call.

What is digital? Early cellular phones relied on analogue systems.
Analogue radio systems transmit the voice signal in its original form, whereas digital technology transforms the microphone signal into number sequences (digits) and transmit these.
When received, the digital signal is decoded so that you can hear the sender's voice.
Digital signals do not degrade in quality as long as the data is received, and they can be compressed to take up less memory.

What is Tri Band? A tri band cell phone has the capability to automatically switch between frequencies and can thus operate on two or more frequency bands, e.g. 900,1800, and 1900 Mhz.

What is GSM? Global System for Mobile communications is the most widespread standard for digital communication in Europe, Australia and in large parts of Asia and Africa.
GSM uses frequencies in the 900 and 1800 Mhz bands.

What is APN? APN stands for Access Point Name and is basically an URL address on the Mobile Internet.

What is GPRS? General Packet Radio System is a service protocol built on GSM technology.
GPRS allows several mobile phone users to share the same connection. Charges may thus be based on the amount of transferred data rather than on airtime.

MISCELLANEOUS

What is CSD? A wireless service protocol used for WAP. CSD stands for Circuit Switched Data and will enable continuous connection and payment by the amount of data transferred.

What is SIM? Subscriber Identity Module or SIM is the little gold-plated plastic card that you get from your network operator and which holds the unique data the network needs to identify your phone.

What is PIN and what is PUK? Access to use a cell phone is most often protected by a code known as "PIN" - Personal Identification Number. Your SIM card comes with a default PIN that you can change to any code you prefer. See p. 88 for details. If you forget your code, or by mistake enter a faulty code three times in a row, the SIM card will lock. To unlock, you must enter the Personal Unblocking Key or "PUK" code that came with your SIM card.

What is IMEI? IMEI stands for International Mobile Equipment Identifier and is an identification system that can recognize every mobile phone by a specific number. If a phone is stolen, the IMEI system is capable of blocking it on all network operators that support the system.

What are MCC and MNC? Mobile Country Code is a code that identifies the country in which the subscriber lives. Mobile Network Code identifies the network operator.

What is DTMF? Dual Tone Multi Frequency or DTMF is a paging and remote control protocol that allows you to control certain functions via your phone, e.g. listening to your answering machine.

MISCELLANEOUS

What is Cell Broadcast?
Cell Broadcast is a service from your network provider. With CB, you will be alerted when entering a "cheap zone" or you can obtain traffic information, weather reports and other important information sent to you as text messages. Some providers also offer sports results, news bulletins or even commercials. If offering CB services, your network will forward a list of services and the relevant channels to enter.

What is WAP?
Wireless Application Protocol or WAP is a standard that allows you to access parts of the Internet, known as "Mobile Internet" via your cell phone. Using WAP will open many services to you, i.e. news and weather forecasts, ordering services and goods, accessing databases and more.

What is an URL?
Uniform Resource Locator or URL is an address system used on the Internet. All WAP homepages have a unique address, allowing browsers to distinguish one from the other. An URL always start with the text string: http://wap followed by the address.

What is ISP?
ISP stands for Internet Service Provider.

MISCELLANEOUS

QUESTIONS AND ANSWERS

Q:My phone does not switch on when I press the key ?
A:The keypress has been too short or the phone has shut down because the battery power level is too low to make calls. Recharge the battery fully.

Q:Stand-by time seems too short ?
A:You have made excessive use of the games or the Organizer or display light has been on continously due to unintentional key activation. Apply Keypad lock in left softkey menu.

Q:My phone displays: 'PLEASE INSERT SIM'?
A:You must insert the SIM before you can use the phone. If it is already installed, remove and clean the blank area with a dry cloth, then reinsert.

Q:My phone displays: 'INVALID SIM'?
A:The phone is SIM-locked and will not accept the inserted SIM. Insert the correct SIM or contact your dealer.

Q:My phone displays: "EMERGENCY CALLS ONLY"?
A:Your SIM card is not properly installed or configured, or you are out of network range.

Q:My phone displays: "NO NETWORK" ?
A:You are outside network range or there is no clear path to the transmitter. If you are inside a building, try moving towards a window.

MISCELLANEOUS

Q:Some calls are not processed. What is wrong?
A:A call bar has been set to restrict phone usage. Check call barring and cancel as necessary.

Q:Someone else is receiving my calls. What is wrong?
A:The phone has been set to forward your calls to another number.
  Cancel call forwarding as necessary.

Q:Can I send and receive emails and surf the Mobile Internet on my phone?
A:Yes. Your phone has WAP capability, which means that you can access the Mobile Internet
  from your phone.
  For sending and receiving emails, please contact your network operator.

Q:What type of networks are supported?
A:Check the technical specifications on p. 122.

MISCELLANEOUS

Q:Can I use my phone inside a car?
A:Road safety comes first. Always keep your eyes on the road if you are driving.
  You can install a "Hands free" set (see. p. 8) if you need to drive and talk at the same time.
  Always comply with local legislation.
  If your car is equipped with airbags, check safety precautions with your car dealer.
  See also "Warnings" .

Q:How do I clean my phone if it becomes soiled?
A:See "Cell phone care" on p. 126.

Q:Are cellular phones dangerous to my health?
A:No unambiguous scientific evidence exists at this point of time. We recommend that you keep
  abreast with the advice given by your domestic health authorities. See also "Warnings" .

Q:My phone has been lost or stolen. What do I do?
A:Contact your network operator immediately to close your account and prevent misuse.
  Report your phone stolen to local police.

Q:How do I reset my phone to factory defaults?
A:Enter the Settings menu and scroll to "Reset all".

MISCELLANEOUS

TECHNICAL DATA

Physical properties
Size : W-43.5 H-81.5 D-22 (mm)
Weight : 75g
Display : 65K Color (128X160 pixels)

Performance
EGSM : 900 DCS :1800 PCS : 1900
GPRS : Class 10
Standby : Standard-72h
Talk time : Standard-5h
Charging time : Standard-100±30min,
Radiation (SAR) : 2 w/kg averaged over a
                              10g cube

Communication features
Long SMS (459 latin chr.)
EMS (Sound & Picture attachment)
Call wait & Call hold
Conference call (Up to 5 participants)
Call forwarding & Call barring
Billing (AoC)
WAP

Personalizing features
Greeting
Wallpaper
40 Polyphonic ring tones
5 Caller groups

Organizing features
Calendar
Tasks
Alarm
Calculator

Leisure
3 games

Accessories
Contact local retailer

Woman software

CHAPTER 6

SAFETY

•Safety Information for Wireless Handheld Phones

•Cell Phone Care

•Driving Safety

•Electronic Devices

•Other Safety Guidelines

•Cautions

•Warning

•FCC RF exposure

SAFETY

Read This Information Before Using Your Handheld Portable Cellular Telephone.

EXPOSURE TO RADIO FREQUENCY SIGNALS
Your wireless handheld portable telephone is a low power radio transmitter and receiver. when it is ON, it receives and also sends out radio frequency (RF) signals.
In August 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

    ANSI C95.1 (1992) *
    NCRP Report 86 (1986) *
    ICNIRP (1996) *

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature.
For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C951).

SAFETY

The design of your phone complies with the FCC guidelines (and those standards).
*;
American National Standards Institute;
National Council on Radiation protection and measurements; International Commission on Nonionizing Radiation Protection.

ANTENNA CARE
Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

SAFETY

CELL PHONE CARE

Your phone is a state-of-the-art electronic device that will serve you well for many years provided it gets a minimum of attention and care from you. You should never attempt to open the phone casing.There are no user-serviceable parts inside,and you might damage sensitive electronic circuits and components. Unauthorized disassembly will void the warranty. You should never leave your phone in the window of your car or otherwise expose it to strong sunlight or excessive heat for a prolonged period of time as this may damage it. You should never handle your phone with wet hands or expose it to moisture or liquids of any kind.Continuous changes from a cold to a warm environment may lead to condensation inside the phone,resulting in corrosion and possible damage. If you pack your cell phone in your suitcase during travel,beware not to damage it.Cramming a suitcase may crack the LCD display.Remember to switch off your phone during air travel. Like with all other radio devices,touching the built-in antenna area during telephone conversation may impair the quality and lead to shorter stand-by time due to increased power consumption.

The battery. Your phone is equipped with a high-performance Li-Ion battery. Optional battery types may be available, check with your local retailer. Observe the maintenance guidelines and your battery should give you a long service life.

- At the beginning of the battery's life, fully charge and discharge (let it go flat)three times.
- Avoid repeated short charging.It is preferable to let the battery go flat and then recharge it completely.
- Avoid charging in strong heat or extreme cold.Ambient room temperature is preferable.
- Don't keep a battery near a fire and attempt to disassemble it.
- Use only the battery approved by manufacturer
- Never replace battery by an incorrect type.

SAFETY

- Never try to open the battery as it contains substances that might be harmful if swallowed or allowed to contact unprotected skin.
- Never short-circuit the battery,as it may overheat and course a fire.Keep away from jewelry and other metal objects.
- Never dispose of the battery by burning it.It could explode and release harmful substances into the environment.
- Never dispose of the battery with your regular household waste.Take it to a hazardous material collection point.

The charger. Use only the charger supplied with the phone.Newer pull charger cord to release it from mains,pull the charge itself.

Cleaning & storing. Your phone should always be handled with care,protected from dirt,dust and damp.To avoid scratches,never place the phone face down.

If cleaning is necessary,switch the phone off and wipe carefully with a a soft,slightly damp (not wet)cloth. Allow the phone to dry completely before switching it on.Never use solvents for cleaning.

If you wont use your phone for some time,fully charge the battery and store the phone in a dry place away from direct sunlight.The phone should be switched off during storage.

Point store member:

-Never disassemble the phone or battery.

-Never expose the phone to heat or strong sunlight.

-Never expose the phone to moisture or liquids of any kind.

-Do not paint the phone or otherwise block keypad,microphone or earpiece function,i.e.with stickers

-The battery has its optimum performance in an ambient temperature of +5 °C to +50 °C

SAFETY

DRIVING SAFETY

Talking on the phone while driving is extremely dangerous and is illegal in some states. Remember, safety comes first. Check the laws and regulations on the use of phones in the areas where you drive. Always obey them.
Also, if using your phone while driving please:

- Give full attention to driving. Driving safely is your first responsibility.

- Use hands-free operation, if available.

- Pull off the road and park before making or answering a call, if driving conditions require.

If you must use the phone while driving, please use one-touch, speed dialing, and auto answer modes.
An airbag inflates with great force. DO NOT place objects, including both installed or portable wireless equipment, in the area over the airbag or in the air bag deployment area.
If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

WARNING:
Failure to follow these instructions may lead to serious personal injury and possible property damage.

SAFETY

ELECTRONIC DEVICES

Most modern electronic equipment is shielded from RF energy.
However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers
The Health Industry Manufacturers Association recommends that a minimum separation of six (6") inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.
If you have a pacemaker:

- ALWAYS keep the phone more than six inches from your pacemaker when the phone is turned on.
- Do not carry the phone in a breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- If you have any reason to suspect that interference is taking place, turn your phone OFF immediately.

Hearing Aids
Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider (or call the customer service line to discuss alternatives).

SAFETY

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in healthcare facilities when any regulations posted in these areas instruct you to do so. Hospitals or healthcare facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF where posted notices so require.

SAFETY

OTHER SAFETY GUIDELINES

Aircraft

FCC Regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Potentially Explosive Atmospheres

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fueling areas such as gas stations; below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or articles, such as grain, dust, or metal powders; and any other area where you would normally be advised to turn off your vehicle's engine.

SAFETY

CAUTION

Your Handheld Portable Telephone is a high quality piece of equipment.Before operating the equipment,read all instructions and cautionary markings on (1)AC Adaptor (2)Battery and (3)Product Using Battery.

1.DO NOT use this equipment in an extreme environment where high temperature or high humidity exists.

2.DO NOT abuse the equipment.Avoid striking,shaking or shocking.When not using the unit,lay down the unit to avoid possible damage due to instability.

3.DO NOT expose this equipment to rain or spilled beverages.

4.DO NOT use unauthorized accessories.

5.DO NOT disassemble the phone or its accessories.If service or repair is required, return unit to an authorized Audiovox cellular service center.If unit is disassembled,the risk of electric shock or fire may result.

6.DO NOT short -circuit the battery terminals with metal items etc.

7. Use only the battery approved by manufacturer

8. DO NOT replace battery by an incorrect type.

SAFETY

WARNING

The following offenses are punishable by fine, imprisonment, or both:
- Using obscene, indecent, or profane language.
- Using the unit to give off false distress calls.
- Wiretapping or otherwise intercepting a telephone call, unless that person has first obtained the consent of the parties participating in the call.
- Making anonymous calls to annoy, harass, or molest other people.
- Charging to an account without authorization to avoid payment for service.
- Refusing to yield a party line when informed that it is needed for an emergency call (It is also unlawful to take over a party line by stating falsely that it is needed for an emergency).
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

SAFETY

FCC RF EXPOSURE

 WARNING! Read this Information before using your phone.

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters.
Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.
The design of this phone complies with the FCC guidelines and these international standards.

Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.
Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

SAFETY

Body-worn Operation
This device was tested for typical body-worn operation with the back of the phone kept 0.5 inches (1.27cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.5 inches (1.27cm) must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. All belt-clips, holsters and similar accessories used by this device must not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna(optional, if available)
A minimum separation distance of 7.9 inches (20cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure
requirements.

Note: For more information about RF exposure, please visit the FCC website at www.fcc.gov

DECLARATION OF CONFORMITY

Conformity Assessment Principles
Complies with the essential requirements of Article 3 of the R&TTE Directive 1999/5/EC,
if used for its intended use and that the following standards has been applied:

1. Health (Article 3.1.a of the R&TTE Directive)
   Applied standard(s) : EN50360:2001

2. Safety (Article 3.1.a of the R&TTE Directive)
   Applied standard(s): EN 60950:2000

3. Electromagnetic compatibility (Article 3.1b. of the R&TTE Directive)
   Applied standard(s): EN 301 489-1: v1.4.1 and EN 301 489-7: v1.2.1

4. Efficient use of the radio frequency spectrum (Article 3.2 of the R&TTE Directive)
   Applied standard(s): EN 301 511: v 9.0.2

We hereby declare that all essential radio test suites have been carried out and that
the above named product is in conformity to all the essential requirements of
Directive 1999/5/EC.