折线 折线 折线 折线

折线 折线 折线 折线 折线 折线

GEARGO

USER MANUAL

Model：S5

## In the box

Wireless Sond Bar

User Gide

3.5 mm AUX IN Cable

3.5mm RCA Cable



2*Screws

Adapter

Remote Control

## Installing the battery

The battery of the remote control is two no. 7 batteries. If the batteries need to be replaced, gently open the battery cover of the remote control, take two new batteries (no. 7 batteries), and place the positive and negative electrodes of the batteries in the remote control in the correct direction. Finally, return the battery cover to the remote control.

**NOTE:** The remote control shall be placed in the correct direction of positive and negative pole when installed.



"1" "2" "3"

## Location of controls

**SIDE PANEL**




1.[ POWER ] button: Power ON/OFF
2.[ MODE ] button: Switch modes
3.[ M / V- ] button: decrease volume skip to previous track
4.[ ⏯ ] button: Play/paevious track
5.[ M / V+ ] button: increase btton skip to next track
6.[ LINE IN 1 ] Input: Input LINE IN 1
7.[ LINE IN 2 ] Input: Input LINE IN 2
8.[ OPTLCAL ]: Input OPTLCAL
9.[ ARC ]: Input ARC
10.[ DC-18V ]: DC 18V IN jack

**FRONT PANEL**




11.[ LINE IN 1/2 ]: Input LINE IN 1LED indicator light（Red lights）/ Input LINE IN 2 LED indicator light（Blue lights）
12.[ OPTIARC ]: OPTICAL LED indicator light（Red lights）/ ARC LED indicator light(Blue lights)
13.[ BT ]: BT LED indicator light（The flashing blue lights）
14.[ IR ]: Infrared sensor

**REMOTE CONTROL**




1. [ ⏻ ] **Key:** Standby Power ON/OFF
2. [ 🔇 ] **Key:** Mute volume
3. [ + ] **Key:** Increase volume
4. [ ⏮ ] **Key:** Skip to previous track
5. [ ⏯ ] **Key:** Play/pause music
6. [ ⏭ ] **Key:** Skip to next track
7. [ − ] **Key:** Decrease volume
8. [LINE IN 1] **Key:** LINE IN 1 mode
9. [LINE IN 2] **Key:** LINE IN 2 mode
10. [OPTICAL] **Key:** Optical mode
11. [ ARC ] **Key:** ARC mode
12. [ BT ] **Key:** Bluetooth mode

## Mounting the speaker

1. Measure a width of 31.49 inches on the wall.
2. Mark the position of the mounting screws on the wall using a pencil.
3. Drill the supplied screws directly into the marks that you have made on the wall and leave approximately 0.3 inch length to hook the Wireless Sound Bar.
4. Put the Wireless Sound Bar onto the mounting screws. Make sure they are firm and stable.




1. Connect the DC power cord into a wall socket.
2. Turn the speaker on by pressing the **[POWER]** button on the speaker or remote control.
3. Press the [ BT ] Button on the speaker or remote control to enter Bluetooth Mode. A tone is heard and the Bluetooth LED indicator light will flash quickly.
4. Keep the speaker and your Bluetooth enabled device within 10m of each other during the pairing process
5. Set your mobile phone or other Bluetooth enabled device to search for compatible Bluetooth devices.

**Bluetooth Connection Method for Android system:**

1. Go to SETTINGS> BLUETOOTH(make sure bluetooth is turned ON)

2. When your bluetooth enabled device finds the speaker, select " S5 " from the list of found devices. When succeeding pairing, you will hear " beep beep " . And the blue led light will flash slowly.

**Bluetooth Connection Method for IOS system**

1. Go to SETTINGS> BLUETOOTH(make sure bluetooth is turned ON)

2. When your bluetooth enabled device finds the speaker, select " S5 " from the list of found devices. When succeeding pairing, you will hear " beep beep " . And the blue led light will flash slowly.

## Specification

- Size：940*84*73mm
- BT working distance：10m
- S/N：≥65db
- BT IC ：BK3254 /4.1
- Output power：10W*4
- Power DC：DC 18V
- Frequency Response：120Hz~16KHz
- Distortion：<0.5%
- Driver Size：2.5"*4

**Malfunction analysis:**
Consult the after-sale service for help.

**Legal information:**
Any copy, changes or modifications of the user manual not expressly approved unless dealer' s permission.

**Caution:**
1. Do not take this apparatus apart or repair it.
2. Do not use this apparatus near water and humid.
3. Clean only with a dry cloth.

**Limited Warranty:**
You may within 1 year from your original date of purchase return it to the authorized service for repair.

**Cautions and warnings:**
1. Do not use the bluetooth speaker near water or humid; do not use the device near the bathtub, water tank, swiming pool and so on.
2. Do not install the bluetooth speaker in the hot or cold environment.
3. Do not expose the device in the sunshine directly.
4. Do not use the device near fire, such as, stove, candle or fireplace and so on.
5. Do not use abrasive cleaning solvents to clean the bluetooth speaker.

## Warranty

Dear customer, thank you for purchasing GEARGO products!

After buying a product, please check whether the accessories are complete. Before turning on the device, please carefully read the operating instructions.
The warranty period for GRAEGO equipment is 12 months from the date of purchase.
Corrections, deletions or other changes in the warranty card are not allowed and lead to loss of warranty service.
With this warranty card, the manufacturer confirms that it has assumed the obligation to satisfy the consumer's requirements established by the current consumer protection legislation in the event that defects in the product are discovered. At the same time, the manufacturer reserves the right to refuse warranty service of the product in case of non-observance of the conditions set forth below.

Contact us
No.1 Amazon Customer Service Team

No.2 Contact us by email
GEARGO-SERVICE@hotmail.com Made in China

## FCC Statement

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

备注：送大货样，工程部确认尺寸、颜色及丝印内容后方可做大货

| | | | |
|---|---|---|---|
| 生产单号： | | 型号:S5 | |
| 料号：416-0S5AH081-00R | | 物料名称： 说明书 | |
| 其它要求：105g铜版纸，黑白 单面印刷<br>需按要求折叠，折叠后成品尺寸：85*110mm<br>内容以工程承认样品为准 | | | |
| 美 工 | | 结构 | |
| 电 子 | | 审核 | |