Date: 14 September 2018

User Manual For Gaming Headset System model number RZ04-0267 consist of Gaming Headset Model RC30-026701 and Wireless USB Transceiver RC30-0267

PACKAGE CONTENTS

- Gaming Headset (System model number RZ04-0267 consist of Gaming Headset Model RC30-026701 and Wireless USB Transceiver RC30-0267)
- USB wireless transceiver
- Charging cable
- 3.5mm combo cable
- Important Product Information Guide

SYSTEM REQUIREMENTS

HARDWARE REQUIREMENTS

- Devices with a USB port
- Mobile devices with a 3.5mm combo port

RAZER SYNAPSE 3 REQUIREMENTS

- Windows® 7 64-bit (or higher)
- Internet connection
- 500 MB of free hard disk space

2. REGISTRATION / TECHNICAL SUPPORT

REGISTRATION

Register your product online at razerid.razer.com/warranty to get real-time information on your product's warranty status.

If you haven't registered for a Razer ID yet, register now at razerid.razer.com to get a wide range of Razer benefits.

Your product's serial number can be found underneath the ear cushion, as shown here.

TECHNICAL SUPPORT

- 1 year limited manufacturer's warranty
- Free online technical support at support.razer.com

DEVICE LAYOUT

A. Auto-adjusting headband

B. Cooling gel-infused ear cushions

C. 50mm drivers with HyperSense Technology

D. Razer Chroma backlighting

E. Mic mute indicator

F. Retractable mic

G. Mic mute button

H. Game/Chat balance

I. Status indicator

J. Power button

K. Charging port

L. 3.5mm combo port

M. Volume control

N. Transceiver storage

O. USB wireless transceiver

P. Charging cable

Q. 3.5mm combo cable

SETTING UP YOUR RAZER NARI ULTIMATE

CHARGING YOUR HEADSET

Connect your Razer Nari Ultimate to a powered USB port using the charging cable.

For best results, please fully charge your headset before using it for the first time. A depleted unit will fully charge in about **4 hours**.

UNDERSTANDING THE CHARGING NOTIFICATIONS

Your Razer Nari Ultimate will send out notifications depending on its current charging status, as shown here:

STATUS INDICATOR		SOUND INDICATOR		DESCRIPTION
Static red	🔴	None	🔇	Charging/low battery
Static green	🟢	None	🔇	Fully charged/full battery
Blinking red	🔴	Warning tone	🔊	Battery is critically low

CONNECTING TO YOUR PC VIA USB PORT

1. Plug the USB wireless transceiver to your PC.

2. Right-click on the sound icon on the system tray, and then select **Sounds**.

3. On the Playback tab, select **Razer Nari Ultimate - Chat** from the list, and then set it as the **Default Communication Device**.

4. On the Playback tab, select **Razer Nari Ultimate - Game** from the list, and then set it as the **Default Device**.

5. In the Recording tab, select **Razer Nari Ultimate - Chat** from the list and click the '**Set Default**' button.

CONNECTING TO OTHER DEVICES VIA USB PORT

1. Push in the USB wireless transceiver until you hear a click then release your finger so that it ejects from your headset.

Push to Eject

Note: To return the USB wireless transceiver, push it into the compartment until you hear a click.

2. Plug the USB wireless transceiver to your device and make sure your Razer Nari Ultimate is the default input and output audio device.

USB

CONNECTING YOUR HEADSET

1. Power on your headset by holding the power button for at least 3 seconds or until you hear 2 short beeps.

Hold for 2secs

2. Wait until the status indicator is static blue.

NOTIFICATION		STATUS
Blinking		Pairing
Rapid blinking		Connecting
Static		Connected

Note: Keep your headset within close proximity of the USB wireless transceiver for a faster and more stable connection. If your headset fails to connect, it will automatically power off after a few minutes.

CONNECTING TO DEVICES VIA 3.5MM COMBO PORT

If your device has a 3.5mm audio + mic combined jack, simply plug the 3.5mm audio cable from your headset to your device's audio jack.

USING YOUR RAZER NARI ULTIMATE

USING THE VOLUME CONTROL

Rotate the volume control to increase or decrease the volume.

Audio volume down

Audio volume up

USING THE GAME/CHAT BALANCE

Rotate the game/chat balance to increase the in-game volume and decrease the voice chat volume or vice versa. By default, the notch on the wheel is set to the middle to indicate 50% chat and 50% game volume.

Chat volume

Game volume

USING THE RETRACTABLE MIC

Pull the tip of the mic until it is fully extended.

Bend the mic until it is parallel to your mouth, then adjust the length as preferred. Make sure the mic diaphragm is in front and the air vent is facing away from your mouth.

Mic diaphragm

Air vent

Press the mic mute button to mute or unmute the mic. The mic mute indicator will light up when muted.

EXTENDING YOUR HEADSET'S LIFESPAN

We recommend stretching the headset gently apart before placing them over your head to minimize headband stress. However, please avoid overstretching the headset beyond its technical limits.

INSTALLING RAZER SYNAPSE 3 FOR YOUR RAZER NARI ULTIMATE

Step 1: Make sure your Razer device is connected to the USB port of your computer.

Step 2: Install Razer Synapse 3 when prompted* or download the installer from razer.com/synapse.

Step 3: Create your Razer ID or log in using an existing account.

*Applicable for Windows 8 or later.

CONFIGURING YOUR RAZER NARI ULTIMATE VIA RAZER SYNAPSE 3

Unleash the full potential of your Razer Nari Ultimate by enabling these features from Razer Synapse 3:

HyperSense Technology – Feel the action and experience an additional layer of immersion.

THX Spatial Audio - 360° positional audio for a natural and lifelike experience.

LIGHTING EFFECTS

The Lighting tab enables you to customize the look of your Razer device by allowing you to choose from various lighting effects or fully customizing your own. These lighting effects can also be synchronized with other Powered by Razer Chroma devices that support the selected effect.

	Name	Description	How to set up
	Breathing	The lighting fades in and out of the selected color(s)	Select up to 2 colors or randomize
	Spectrum cycling	The LEDs will cycle between 16.8 million colors indefinitely	No further customization required
	Static	The LEDs will remain lit in the selected color	Select a color

Please refer to the Online Master Guide at support.razer.com for in-depth instructions on how to configure and use your Razer Nari Ultimate.

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Nari Ultimate, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for support.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in any activity that requires active awareness of your surroundings.

Listening to excessively loud volume over an extended period of time can damage your hearing. Furthermore, legislation of certain countries permits only a maximum sound level of 86dB for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

MAINTENANCE AND USE

The Razer Nari Ultimate requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2018 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks and trade names are the property of their respective owners and other company and product names mentioned herein may be trademarks of their respective companies.

THX and the THX logo are trademarks of THX Ltd., registered in the U.S. and other countries.

Lofelt is a registered trademark of Lofelt GmbH.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer NARI Ultimate (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit: razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

REGULATORY

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

For more information, refer to the online help system on **razer.com**.

FCC CAUTION STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and consider removing the no-collocation statement.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

REGULATORY

C E STATEMENT OF
COMPLIANCE WITH EU DIRECTIVE

ENGLISH
STATEMENT OF COMPLIANCE WITH EU DIRECTIVE
Hereby, Razer (Europe) GmbH, declares that this
Razer Nari Ultimate (Wireless USB Transceiver RC30-0267
and Gaming Headset RC30-026701) is in compliance with
the essential requirements and other relevant provisions of
Directive 2014/53/EU and 2011/65/EU.

Gaming headset:
Radio Frequency: 2.4GHz SRD
Operating Frequency: 2403.35-2477.35Mhz
Max Output power: 7.56dbm+/-2dbm

USB wireless transceiver:
Radio Frequency: 2.4GHz SRD
Operating Frequency: 2403.35-2477.35Mhz
Max Output power: 1.05dbm+/-2dbm

The full Declaration of Conformity can be requested via the following:

Company: Razer (Europe) GmbH

Address: Essener Bogen 23, 22419 Hamburg, Germany

E-mail: compliance@razer.com

Internet address: https://www.razer.com

Canada Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil ne doit pas produire de brouillage;
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.