Function

Button

Action

Sound

Function

Multi-function button

Un button

Down button

Magnetic sticking switch



Magnetic Sticking Switch



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Function	Action	Sound	OFF	OFF Available Power ON	Calls on a second (Incoming calls waiting)	Ringing	Talk with answer	Incoming Call	Outgoing Call	Ongoing Call	2nd Incoming Call	2nd Outgoing Call (Hold/Swap to others)	Busy Calls	Music Play
Power	**Press**													
Multi-function	**Short**	**wave**	-	**Power ON**	**Announce to the last answered device**	-	**Start Music**	**answer call**	**Cancel call**	**End call**	**Answer 2nd Incoming call (end and current call on hold)**	**Cancel 2nd Outgoing Call**	**Hold the current ongoing call (end and/or to holding call)**	**Pause**
	Long (2 seconds)	**beep**	-	**Pairing**										**Pairing Mode (Blue Light)**
Un Button	**Short**	**wave**	-	**Power ON**	**Reject call**	**Reject call**	**End Start / End Music**	**Reject call**		**Transfer Audio**	**End the Call and answer 2nd Incoming call**		**Switch call**	**End Start / End Music**
	Long (5 seconds)	**wave**	-	**Pairing**	**Pairing**	**Pairing**	**Pairing**	**Pairing**	**Pairing**	**Pairing**				
	Short	**wave**	-	**Power ON**	**Pairing**	**Pairing**	**Pairing**	**Pairing**	**Pairing**	**Pairing**				
Un Button	**Short**	**wave**	-	**Power ON**	-	-	-	**Increase Phone volume**	**Increase Phone volume**	**Increase Phone volume**	**Increase Phone volume**	**Increase Phone volume**	**Increase Phone volume**	**Increase music volume Next track**
	Long (2 seconds)	**wave**	-	-	-	-	-	-	-	-	-	-	-	-
Down Button	**Short**	**wave**	-	-	-	-	-	**Decrease Phone volume**	**Decrease Phone volume**	**Decrease Phone volume**	**Decrease Phone volume**	**Decrease Phone volume**	**Decrease Phone volume**	**Decrease music volume Previous track**
	Long (5 seconds)	**wave**	-	-	-	-	-	-	-	-	-	-	-	-
Multi-function + Un Button	**Short**	**wave**	-	-	-	-	-	-	-	-	-	-	-	-
	Long (2 seconds)	**wave**	-	**Power ON**	**Power OFF**	**Power OFF**	-	-	-	-	-	-	**Power OFF**	-
Multi-function + Down	**Short**	**wave**	-	**Power ON**	-	-	-	-	-	-	-	-	-	-
	Long (5 seconds)	**wave**	-	**Power ON**	**Reset paired device list**	**Reset paired device list**	-	-	-	-	-	-	-	-
Magnetic sticking switch	**Sticking ON**	**wave**	-	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**	**Power OFF**
		crowd	**ON**	**ON**	**ON**	**ON**	-	-	-	-	-	-	-	-
	Sticking OFF	**wave**	**Go to OFF and Available Power ON**	-	-	-	-	-	-	-	-	-	-	-
		crowd	**ON**	**ON**	**ON**	**ON**	-	-	-	-	-	-	-	-
											iPhone 6S	**iPhone 6S**	**iPhone 6S**	

Short : within 2sec
Long : more than 2sec
Very Long : more than 5sec
Sticking : 10 sec
Very Very Long : more than 15sec

Use device which is
Handfree