PCA3200

Polaroid

BLUETOOTH MONOPOD

QUICK STARTER

Quick Start Guide | Full Manual | Warranty Card

IN THE BOX

FEATURE OVERVIEW



TURNING ON MONOPOD

1. Connect the smallest end of the Micro USB cable to the Micro USB port on the Monopod's base.
2. Connect the large end of the Micro USB cable to your computer or other charging device.
3. The LED indicator light is RED when charging & off and off when the Monopod is fully charged.

Please make sure charging the Monopod for at least 1 hour before using it for the first time.

TURNING ON MONOPOD

1. Slide the power switch on the handle of the Monopod to the ON position.
2. Wait for the LED light to turn BLUE.
3. Pair the Monopod and Bluetooth enabled device within 3 feet of each other during the pairing process.
4. Check that Bluetooth is enabled on your device.

Make sure your device is compatible with Bluetooth 3.0 or higher and Bluetooth HID profile. Please check your device's manual for more information.

On an iPhone:
Go to Settings > Bluetooth > Bluetooth Monopod

TURNING ON MONOPOD (cont.)

On a Blackberry:
Go to Settings > Bluetooth > Bluetooth Monopod

On an Android Phone:
Go to Settings > Bluetooth > Bluetooth Monopod

TURNING ON MONOPOD (cont.)

On other G.B Phones/Devices:

1. When the Bluetooth screen appears, select "Bluetooth Monopod" from the list of Bluetooth devices.
2. If required, enter the password 0000. Select OK or Pair to pair the two units.

NOTE: If your device does not recognize the Monopod, please check your device's manual for the correct pairing procedure. On your device's Bluetooth settings, make sure that the Monopod is set to "Visible" or "Discoverable" and that the device's Bluetooth is ON and that the Monopod is within range.

Please make sure your device is compatible with Bluetooth 3.0 or higher and Bluetooth HID profile. Please check your device's manual for more information.

CONNECTING DEVICE

1. Place your smartphone in the phone clamp. You can adjust the length of the base of the clamp to the size of your phone.

2. Attach the phone clamp to the base screw by rotating the unfold until it is tight. Loosen the knob to adjust the angle of the smartphone clamp, then tighten it to secure the clamp.

3. Enter the camera app on your smartphone.

USING THE SHUTTER

4. Extend the Monopod to the desired length.

5. Focus on yourself and press the shutter button on the handle.

6. Before you connect your iPhone/6Plus, please make sure that the Bluetooth connection is properly secured. For iPhone/6Plus or Samsung GALAXY Note 3, remove the silicone attachment.



TROUBLESHOOTING

Non-responsive Bluetooth connection

1. Make sure the Bluetooth Monopod is turned ON before beginning the pairing process.
2. Pair the Bluetooth Monopod and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Check that your device's Bluetooth is ON.
4. Check that YOUR device's Bluetooth firmware is current OS.
5. Try repeating the pairing process, see "Pairing the Monopod".

Non-responsive Bluetooth connection

1. Make sure the Bluetooth Monopod is turned ON before beginning the pairing process.
2. The Monopod's LED light is BLUE.
3. The Monopod is not in pairing mode.

CARE & CLEANING

BLUETOOTH® LABELS MONOPOD WITH BLUETOOTH® WIRELESS TECHNOLOGY, SMARTPHONE CLAMP, ADJUSTABLE HANDLE, SHUTTER BUTTON, MICRO USB CHARGING CABLE, USER MANUAL, WARRANTY INFORMATION, CHARGING CABLE, CLAMP, CLAMP BASE, CLAMP BASE SCREW, CLAMP BASE SCREW BUTTON, HANDLE, SHUTTER, LED LIGHT, POWER SWITCH, LED INDICATOR LIGHT, MICRO USB CHARGING PORT, SILICONE ATTACHMENT, SILICONE ATTACHMENT, SILICONE ATTACHMEN