Welcome Guide

TeckNet BM308 Wireless Mouse

Product Layout

Scroll Wheel

Left Click Button

Right Click Button

DPI Switch Button

Froward Button

Low Battery Indicator

Backward Button

Technical Specifications

Button Count:	6 buttons
Bluetooth Version:	3.0
Number of Channels:	16
Resolution:	800/1200/1600/2000/2600DPI
Operating Voltage:	3.0V
Operating Current:	5.5 mA
Dimension:	106 x 67.8 x 38.5mm
Weight:	120g

Product Contents

1 x BM308 Wireless Mouse
1 x User Manual
1 x Warranty Card

System Requirements

To use this mouse, your computer must meet the following hardware requirements and run one of the operating systems listed below.

Hardware

• PC with a Pentium processor or equivalent AMD processors
• USB 2.0

Operating System

Windows 98/ME/2000/XP/VISTA/Windows7/Windows8/WIN10
Note: The scroll wheel only works under the operating systems listed above. If you use the mouse under a different operating system, the mouse may either not work or lose its enhanced features.

Instructions

Battery Installation

The BM308 optical mouse uses two AAA batteries (not included).
1. Open the battery cover.
2. Insert the batteries into the compartment, ensuring they correspond with the polarity markings.
3. Close the battery cover.
4. Switch on the BM308 by adjusting the power switch underneath the mouse. The red LED of the power indicator at the top of the mouse will flash.

Note: Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) markings in the battery housing.

24-Month Battery Life

The mouse consumes little power and offers a long battery life of up to 24 months without changing battery. However, the actual battery life may vary based on user and computing conditions.

Pairing

1) Turn on the Bluetooth of your device.


Manage Bluetooth devices

Bluetooth

On

Your PC is searching for and can be discovered by Bluetooth devices.

2) Switch on the mouse, press the pairing button for 2-3 seconds and the LED indicator will flash. Now the BM308 is in pairing mode.
3) The BM308 will be detected by your device, then click "Pairing".

| TeckNet BM308 Mouse |
| Ready to pair |
| Pair |

4) It will take a few seconds for pairing.

TeckNet BM308 Mouse

5) Your device will show "Connected" if successful. Now the BM308 is ready for use.

| TeckNet BM308 Mouse |
| Connected |
| Remove device |

Intelligent Power Saving (IPS)

The mouse is equipped with Intelligent Power Saving (IPS) function.
• When the USB Na no receiver is disconnected or the PC is switched off, the mouse will be switched off automatically for the purpose of power-saving.
• When the mouse is not operated for 3 seconds, it will automatically drop to the first level of IPS. To wake the mouse, click any button.
• When the mouse is not operated for 10 seconds, it will automatically drop to the second level of IPS. To wake the mouse, click any button.
• When the mouse is not operated for 8 minutes, it will automatically drop to the third level of IPS - sleep model. To wake the mouse, click any button

DPI Switch

The mouse supports 2600DPI, 2000DPI,1600DPI, 1200DPI and 800DPI.

To switch to either setting, press the DPI button. The default setting is 1200DPI.Click the DPI button on the top of the mouse once to switch from 1200DPI to 1600DPI, the second click to upgrade to 2000DPI, the third click to upgrade to 2600DPI,click once again to switch back to 800DPI.

DPI Switch

Low Power Indicator

The mouse is equipped with low power indicator. When the battery power gets low during the period of use, the indicator under the scroll wheel will flash. Please replace the battery.
Note: We recommend you to use AAA alkaline dry cell battery.

Reconnection

There is a connection code for this mouse. High temperatures, electro-magnetic fields or vibration may influence the code signal and the mouse may need to be reconnected.

Low Power Indicator

1. Ensure the battery voltage is correct; if the voltage is low, replace the batteries.
2. Press the pairing button for 2-3 second to reconnect.

Attention

1. To maximize battery life, it's recommended to use the mouse on a white or light color surface. As the mouse might not work smoothly on some special surfaces, such as smooth, dark or black, reflecting and 3D mouse pads surfaces.
2. If not used, the mouse will drop into auto-sleeping mode within 3 seconds. Press any key or scroll wheel to activate the mouse.
3. Do not use the mouse on a glass or mirrored surface, as these surfaces will cause the mouse to fail temporarily.
4. Avoid using the mouse on a metal surface. Metals, such as iron, aluminum or copper, shield the radio frequency transmission and may slow down the mouse presenter's response time or cause the mouse to fail temporarily.
5. If your PC has a metal case that contains aluminum or magnesium, use the mouse by the side of the PC. The display panel may interfere with the radio frequency if you use the mouse directly in front of the PC.

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.

1.SAVE THESE INSTRUCTIONS - This sheet contains important safety and operating instructions.

2.Before using the product, read all instructions and caution markings on the product, accessories and device using our product.

3.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

4.Children should be supervised to ensure that they do not play with the appliance.

5.Keep the product away from fire or explosion may occur.

6.For indoor use only. Do not expose to rain, water, excess moisture or snow.

7.Do not place product in or near inflammable, explosive or hazardous object.

8.Do not place in or near water, rain, excess moisture or extreme heat.

9.Do not operate product with damaged cord or plug.

10.Do not operate product if it has been damaged in any way.

11.Do not disassemble the product. Disassembly may result in a risk of safety hazards.

12.Do not throw or shake the product.

13.To reduce the risk of electric shock, unplug the product from the power supply when not in use or switch off the power supply.

Limited 18-Month Warranty:

What this warranty covers.

Shenzhen Unichain Technology Co., LTD. (Manufacturer: "Unichain") warrants to the original purchaser of this TeckNet product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Unichain warrants the TeckNet product for 18 Months.

What will we do to correct problems?

Unichain will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the TeckNet product is not provided to Unichain for inspection upon Unichain's request at the sole expense of the purchaser, or if Unichain determines that the TeckNet product has been improperly installed, altered in any way, or tampered with. The TeckNet Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to claim the warranty?

Please contact retailers or visit TeckNet website www.tecknet.co.uk for more information.

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

Warranty

We warrant that products purchased from authorized distributors will meet the applicable product specifications and be free from all defects in design, assembly, materials and workmanship. Please contact retailers or visit our website (www.tecknet.co.uk) for more information.

E-mail: support@tecknet.co.uk
Website www.tecknet.co.uk

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.