ZTE N762

User Guide

LEGAL INFORMATION

Copyright © 2011 ZTE CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements, information, and recommendations in this manual do not constitute a warranty of any kind, expressed or implied.

Version No.: R1.0

Edition Time: September 2011

Contents

For Your Safety 7
General Safety 7
Radio Frequency (RF) Energy 8
General Statement on RF Energy 8
Specific Absorption Rate (SAR) 8
Body Worn Operation 9
Limiting Exposure to Radio Frequency (RF) Fields . 12
Regulatory Information 12
Distraction 13
Driving 13
Operating Machinery 13
Product Handling 13
General Statement on Handling and Use 13
Small Children 14
Demagnetization 15
Electrostatic Discharge (ESD) 15
Antenna 15
Normal Use Position 16
Air Bags 16
Seizures/ Blackouts 17
Repetitive Motion Injuries 17
Emergency Calls 17
Loud Noise 17
Phone Heating 18
Electrical Safety 18

Accessories 18
Connection to a Car 18
Faulty and Damaged Products 18
Interference 19
General Statement on Interface 19
Pacemakers 19
Hearing Aids 19
Medical Devices 19
Hospitals 20
Aircraft 20
Interference in Cars 20
Explosive Environments 21
Petrol Stations and Explosive Atmospheres 21
Blasting Caps and Areas 21
Phone Overview 22
Keys Functions 24
Battery and microSD Card 25
Installing the microSD Card and Battery 25
Removing the Battery and microSD Card 27
Charging the Battery 27
Brief Introduction 28
Switching Your Phone On/Off 28
Switching to Sleep Mode 28
Waking up Your Phone 28
Home Screen 29

Status and Notification Icons.....29
Applications and Settings Preview 32
Entering Text.....37
Basic Function.....38
Making a Call.....38
Calling from the Dialer.....38
Calling from Your Contacts.....38
Calling from Your Call History.....39
Calling from a Text Message.....39
Using Speed Dial.....39
Import Contacts from the microSD Card or Export to the Card.....40
Sharing Contacts Information.....40
Sending a Message.....41
Taking Pictures with Your Camera.....41
Adjusting Camera Settings.....42
Shooting Video with Your Camcorder.....42
Adjusting Your Video Settings.....42
Listening to Your FM Radio.....43
Playing Your Music.....44
Playing Your Videos.....45
Opening Your Gallery.....46
Enabling GPS.....47
Signing in to Your Google™ Account.....48
Setting a Screen Unlock Pattern.....48

PC connection 49
Connecting to the Internet 49

For Your Safety

General Safety

	Don’t make or receive handheld calls while driving. And never text while driving.		Don’t use at petrol stations.
	Keep your phone at least 15mm away from your ear or body while making calls.		Your phone may produce a bright or flashing light.
	Small parts may cause a choking.		Don’t dispose of your phone in fire.
	Your phone can produce a loud sound.		Avoid contact with anything magnetic.
	Keep away from pacemakers and other electronic medical devices.		Avoid extreme temperatures.
	Switch off when asked to in hospitals and medical facilities.		Avoid contact with liquids. Keep your phone dry.
	Switch off when told to in aircrafts and airports.		Don’t take your phone apart.

	Switch off when near explosive materials or liquids.		Only use approved accessories.
	Don’t rely on your phone for emergency communications.		

Radio Frequency (RF) Energy

General Statement on RF Energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Specific Absorption Rate (SAR)

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg and the highest SAR value for this device when tested at the ear was 1.03 W/kg*. As mobile devices offer a

range of functions, they can be used in other positions, such as on the body as described in this user guide**.

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum power required to communicate with the network.

** Please see body worn operation.

Body Worn Operation

Important safety information regarding radio frequency radiation (RF) exposure:

To ensure compliance with RF exposure guidelines the phone must be used with a minimum of 15 mm separation from the body.

Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device

may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced

radio/ TV technician for help.

Limiting Exposure to Radio Frequency (RF) Fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using 'hands-free' devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page http://www.who.int/peh-emf (WHO Fact sheet 193: June 2000).

Regulatory Information

The following approvals and notices apply in specific regions as noted.

Please find the section Declaration of RoHS Compliance and CE DOC in the end of this manual.

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep it in a clean and dust-free place**.**
- Do not expose your phone or its accessories to open

flames or lit tobacco products.

- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories, only authorized personnel can do so.
- Do not expose your phone or its accessories to extreme temperatures, minimum - [5] and maximum + [50] degrees Celsius.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a

choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your phone for a long time.

Electrostatic Discharge (ESD)

Do not touch the SIM card’s metal connectors.

Antenna



Do not touch the antenna unnecessarily.

Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.



Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area.

Store the phone safely before driving your vehicle.

Seizures/ Blackouts

The phone can produce a bright or flashing light.

Repetitive Motion Injuries

- To minimize the risk of RSI when texting or playing games with your phone:
- Do not grip the phone too tightly.
- Press the buttons lightly.
- Use the special features which are designed to minimize the times of pressing buttons, such as Message Templates and Predictive Text.
- Take lots of breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Loud Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, Bluetooth stereo headsets or other audio devices.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit in the battery terminals.

Connection to a Car

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessory.

Only qualified personnel can service or repair the phone or its accessory.

If your phone or its accessory has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service centre.

Interference

General Statement on Interface

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Devices

Please consult your doctor and the device manufacturer

to determine if operation of your phone may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft. If your device offers a ‘flight mode’, this must be enabled prior to boarding an aircraft.

Interference in Cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Petrol Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas posted power off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.

Phone Overview




Charger/
USB Jack
Thumb
catch
Camera
Back
Cover

Keys Functions

Key	Function
Power Key	• Hold to select phone modes: Silent, Airplane or Power off. • Press to switch your phone to Sleep mode. • Press to wake up your phone.
Home Key	• Press to return to the Home Screen from any application or screen. • Hold to see recently used applications.
Menu Key	• Press to get the options for the current screen.
Back Key	• Press to go to the previous screen.
Volume Keys	• Press **Volume +** to turn the volume up. • Press **Volume -** to turn the volume down.

Battery and microSD Card

Installing the microSD Card and Battery

Switch off your phone before installing or replacing the battery, or memory card.

1. Remove the back cover.



2. Open the microSD card holder, hold your microSD card by the cut corner end and slide it in.



microSD logo is a trade mark of the SD Card Association.

3. Insert the battery by aligning the gold contacts on the battery with the gold contacts in the battery compartment. Gently push down on the battery until it clicks into place.



4. Press the cover gently back into place until you hear a click.

Removing the Battery and microSD Card

1. Make sure that your mobile phone is off.
2. Remove the back cover.
3. Lift the battery up and out.
4. Open the microSD card holder. Slide the microSD card down gently and remove it.

Charging the Battery

When you first get your new phone you'll need to charge the battery like this…

1. Connect the adapter to the charger jack. Ensure that the adapter is inserted with the correct orientation. Do not force the connector into the charger jack.



2. Connect the charger to a standard AC wall outlet.
3. Disconnect the charger when the battery is fully charged.

Brief Introduction

Switching Your Phone On/Off

Make sure the battery is charged.

- Hold **Power Key** to switch on your phone.
- To switch it off, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.

Switching to Sleep Mode

To save battery power, Sleep Mode suspends your device to a low-power-consumption state while the display is off. Your device also goes into Sleep Mode by itself when the display is automatically turned off after a certain period of time, which you can set in **Settings > Display > Screen timeout**.

Press **Power Key** to switch to Sleep Mode.

Waking up Your Phone

1. Press **Power Key** to activate your screen display.
2. Drag the icon to the right.

NOTE: If you have set an unlock pattern, PIN or password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Home Screen

You choose what is shown on your Home Screen. Set your own wallpaper, add the widgets or application shortcuts you need, or remove them as you like.



Status and Notification Icons

Your phone will tell you exactly what's going on by showing you simple icons. Here's what they mean.

	CDMA信号强度		Phone speaker off
	3G in use		Phone microphone off
	Error or warning		GPS on
	USB connected		Recording phone call
	Battery flat		microSD card removed
	Battery very low		Preparing microSD card
	Battery low		Connected to a Wi-Fi network
	Battery partially drained		Alarm set
	Battery full		Wired microphone headset
	Battery charging		Bluetooth on

	Syncing		Speaker on
	Vibrate mode		Problem with SMS/MMS delivery
	Airplane mode		New instant message
	New mail		Upcoming event
	New SMS/MMS/ voicemail		Song is playing
	New Gmail message		Downloading data
	Missed call		Content downloaded and installed successfully
	Call in progress		Sending data
	Call on hold		USB tethering is on
	Call forwarding		Portable Wi-Fi hotspot is on
	More (not displayed) notifications		New Wi-Fi network detected

Applications and Settings Preview

Programs Preview

Your phone has lots of functions. Tap to see the following…

Applications	Description
Alarm	Set alarms.
Browser	
Calculator	Do basic calculation.
Calendar	Schedule appointments and events.
Call log	Show the history call information.
Camcorder	Shoot video clips.
Camera	Take some great pictures.
Contacts	Manage your contacts information.
Dialer	Dial a number.
Docs To Go	Enables you to view your documents.
Downloads	Enables you to view your downloads files.
Email	Send and receive Emails.
Filer	Manage files on your microSD card.

Applications	Description
FMRadio	Search, listen to and save radio channels.
Gallery	Manage multimedia files.
Gmail	Access your Google Mail account and check your Emails on your mobile phone.
Google Search	Search for information online or on your phone.
Latitude	See your friends' locations on the map and share yours with them.
Maps	Track your current location, view real-time traffic, and receive detailed directions to your destination.
Market	Access useful applications and fun games which you can download and install on your phone.
Messages	Open the Messages screen, where you can send and receive SMS and MMS messages.
Music	Browse your audio files and listen to them in Music player.
Navigation	Use Google Maps Navigation which is an internet-connected GPS navigation system.

Applications	Description
News&Weather	Check out the latest news and weather forecast.
Note pad	Create text notes.
Places	Use the online map to search for the places such as restaurants, hotels, bars, etc.
Settings	Adjust phone settings.
Sound Recorder	Capture audio clips.
Stopwatch	Measure exactly how long it takes to do something.
Talk	Use Google Talk to send and receive instant messages.
Task Manager	Manage all the programs running on your phone.
TouchPal Input	Set TouchPal input.
Videos	Browse and watch video files.
Voice Search	Use your voice to search, control, and communicate.
YouTube	Watch YouTube videos.

Checking Your Settings

To change or view your phone's settings, tap **Home Key >** **> Settings**.

Or from the Home Screen tap **Menu Key > Settings**.

Wireless & networks	Configure and manage wireless connections, such as Wi-Fi, Bluetooth®, mobile networks, and Virtual Private Networks. You can also select **Airplane mode** from here.
Call settings	Set up voicemail, speed dial, call barring, voice privacy and international call settings etc.
Sound	Set sound settings, such as ringtones and notifications.
Display	Display settings, such as screen brightness.
Location & security	Create you screen unlock pattern, or manage the phone's credential storage. You can also select the sources to use when determining locations from **My Location**.
Applications	Manage your applications and installation of new ones.
Accounts & sync	Manage your accounts and configure synchronization settings.

Privacy	Configure privacy settings, such as back-up settings, and personal data.
Storage	Check available memory on the external card and the internal phone storage.
Language & keyboard	Set operating system language and region, plus text input options.
Voice input & output	If you have installed a text-to-speech (voice data) application, you can choose the settings.
Accessibility	Choose accessibility options.
Date & time	Set the date, time, time zone, and date/time format.
About phone	View phone status, battery use, and legal information, etc.

Entering Text

When you enter a field that needs text or numbers, a keyboard automatically appears on the screen. Hold the input box and select **Input method** from the pop-up menu to change input method.

Basic Function

Making a Call

There are many ways to make a call with your phone. And they're all easy to do.

Calling from the Dialer

1. Tap **Home Key >** **> Dialer** or on the Home Screen.
2. Enter the phone number with the on-screen keypad.
   Tap to delete wrong digits.
3. Tap

TIPS: To make international calls, hold  to enter the "+".

Calling from Your Contacts

1. Tap **Home Key >** **> Contacts**.
2. Slide your finger to scroll the contacts list and tap the contact you want to call.
   You can search for a contact by tapping and entering the contact name.
3. Tap .

Calling from Your Call History

1. Tap **Home Key >** **> Call log**.
2. Tap next to the number you want to call.

Calling from a Text Message

If a text message contains a phone number that you want to call, you can make the call while viewing the text message.

1. Tap **Home Key >** **> Messages**.
2. Tap the conversation and then the message that contains the phone number you need.
3. Tap the number.
4. Tap

.

Using Speed Dial

Press and hold 1 - 9 key from the dialer to call the corresponding speed dial number.

The number key 1 is reserved to speed dial your voicemail.

Assigning a speed dial key:

1. Tap **Menu Key > Settings > Call settings > Speed dial** from the Home Screen.

2. Tap a speed dial key.

3. Enter a phone number or tap to select one from the contact list.

4. Tap **OK**.

Import Contacts from the microSD Card or Export to the Card

You can import or export contacts from/to your microSD card. This is especially useful when you need to transfer contacts between different devices.

1. Tap **/Menu Key > Import/Export** from the Contacts Screen.
2. Choose to import or export contacts.
   - For export, the phone will prompt you with the name of the vCard file. Tap **OK** to create the file in the microSD card.
   - For import, you should have vCard files saved in the microSD card. If there's more than one vCard file, you need to select the vCard file and tap **OK**.

Sharing Contacts Information

1. Tap **/Menu Key > Import/Export > Share visible contacts** from the Contacts Screen. Your phone will export all information of the contacts in the Contact Screen to a temporary vCard file.
2. Choose how you want to send the vCard file. You can either send it via Bluetooth to another device, or as an attachment in an Email,Gmail or a message.

Sending a Message

1. Tap **Home Key >** **> Messages.**
2. Tap **New message**.
3. Enter the recipient's number or name. As you type, matching contacts will appear. Tap a suggested contact to add as a recipient.
4. Tap **Type to compose** and type your message.
   - Tap **Menu Key** to insert Quick Text, signature, smiley, or contact.
   - If you are sending an MMS, tap **Menu Key > Attach** to attach pictures, videos, audio, or slideshows.
5. Tap **Send** to send your text.

NOTE: Add an attachment to text message and it will be converted into an MMS automatically. Likewise if you remove all attachments from an MMS, it'll automatically become a text message.

Taking Pictures with Your Camera

Your phone has a 2-megapixel camera. Open it by tapping **Home Key >** **> Camera**.

Tap to take a shot. To view it, just tap the picture in the right corner of the screen. Or select **Menu Key > Gallery** to view all your pictures.

Adjusting Camera Settings

From the Camera Screen tap to set up exposure, picture size/quality, color effect, ISO, anti-banding, saturation, contrast, sharpness, or to restore camera settings.

Tap to choose whether to save photo's geographic location.

Tap to change white balance.

Tap to zoom in or out.

TIP: To change quickly from camera to camcorder or vice versa, use the switch icon. Use the bar to adjust the brightness.

Shooting Video with Your Camcorder

Open the camcorder by tapping **Home Key >** **> Camcorder**. Then select to start shooting, and to stop. Select the picture in the right corner of the screen to view the video you've just shot. Or tap **Menu Key > Gallery** to see all your video clips.

Adjusting Your Video Settings

From the Camcorder Screen, tap to adjust color effect, video quality, video/audio encoder, video duration, or to restore camera settings.

Tap to change white balance setting.

Tap to change video quality, video/audio encoder, and video duration together. And the icon will change to **High**, **Low**, **MMS**

or **YouTube.**

Listening to Your FM Radio

With the FM Radio, you can search for radio channels, listen to them, and save them on your phone. Note that the quality of the radio broadcast depends on the coverage of the radio station in your area. The wired headset that comes with your phone works as an antenna, so always connect the headset when using the radio. When you receive an incoming call while listening to the radio, the radio will be turned off.

To tune in, plug your headset into your phone. Tap **Home Key >** **> FMRadio**. This icon will pop up in the status bar.

Tap or to scan for available FM channels. If you need to fine tune the radio's reception, tap **Menu Key > Adjust**. Tap  change the frequency by +/–0.1 MHz.

Once you get the best reception of a channel, hold the frequency shown until a red box appears on the screen, and then drag it into the box to save, as shown in the next diagram.

- Press **Volume Keys** to adjust the volume.
- Tap **Menu Key > Sleep** to set the FM radio sleep timer.
- Tap to switch off the radio.

Playing Your Music

You can play digital audio files from your phone's memory card in **Music**.

6. Tap **Home Key >** **> Music** to open the Music Screen.
7. Select **Artists/Albums/Songs/Playlists** to find the songs you want to play.
8. Tap an item from the list to start playing.
9. Adjust the volume with **Volume Keys**.



Playing Your Videos

To play a video file, tap **Home Key >** **> Videos**. This will open the Videos Screen and show the video files saved in your memory card. Tap a video file to start playing. Tap on the screen and the control bar will appear as below. So now you can play, pause, fast forward, etc.



Opening Your Gallery

Gallery helps you view pictures and play videos. You can also do some basic editing of your pictures – such as setting them as wallpaper or contact icons, and sharing with friends.



Enabling GPS

1. Tap **Home Key >** **> Navigation**.
2. Read the pop-up instructions and tap **Accept**.
3. Tap **OK** in the **GPS is disabled** box to show the GPS settings.

Note: You can open the GPS settings by tapping **Home Key > Menu Key > Settings >Location & security.**

4. Select the **Use GPS satellites** check box.

Signing in to Your Google™ Account

Signing in to your Google account enables you use various Google services on the phone, such as Gmail, Calendar, and Google Talk. The first time you power on the phone, it will prompt you to set up your Google account.

1. Tap **Home Key >** **> Settings > Accounts & sync**.

2. Tap **Add account > Google**.

3. Follow the on-screen prompt to sign in or create an account.

Setting a Screen Unlock Pattern

You can protect your phone from unauthorized use by creating a personal screen unlock pattern.

1. Tap **Home Key >** **> Settings > Location & security > Set unlock pattern**.

2. Read the instructions and tap **Next**.

3. Watch the sample pattern and tap **Next**.

4. Draw your own pattern and tap **Continue**.



5. Draw your pattern again and tap **Confirm**.

PC connection

You can transmit data between PC and your phone.
Your mobile phone supports mass storage. To use this function, you need to connect your phone to your PC through a USB cable and mount the microSD card. To turn on USB storage, flick down the notification panel and tap **USB connected > Turn on USB storage**.

Connecting to the Internet

Using Wi-Fi

1. Tap **Home Key >** **> Settings > Wireless & networks > Wi-Fi settings**.

The Wi-Fi access points, or “hotspots”, that your phone has detected are displayed with their names and security settings.

2. Tap an access point to connect to it.

If security features are implemented, you’ll need to enter a password.

Using CDMA/EvDo

To get connected via CDMA/EvDo you need a data plan with your service provider. For detailed information, please contact with your provider.