SOUNDPODS INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

FOLDING INSTRUCTIONS



Front

iHip®

Bluetooth®

SoundPods™

USER MANUAL

READ INSTRUCTIONS BEFORE USE OF SoundPods™

KEEP FOR FUTURE REFERENCE

FC BC

Introduction:

① Multi-Function Button
② Earbud LED Indicator
③ Volume & Track Control
④ Charging Button
⑤ Charging Dock LED Indicators

Important information

- Both earbuds will automatically pair to each other when turned on. When Successfully paired, one of the two earbuds will flash red and blue while another will slowly flash blue.
- The earbuds will power off if they don't connect to any device within 5 minutes.

Pairing your earbuds

1. Turn on the Bluetooth on your device.
2. Long press the Multi-function button for 3 seconds to power SoundPods on. When the Earbud LED Indicators flash red and blue, they are ready to be paired.
3. Choose "SoundPods" on your list to connect.
4. When the Earbud LED Indicators slowly flash blue, they are successfully paired.

Bluetooth usage:

1. Making phone calls:
Be sure the earbuds are connected with your mobile phone. Once connected you can make phone calls. When making calls both earbuds will be working.

- To *answer a call*, short press the earbud Multi-function button one time.
- To *end a call*, short press the earbud Multi-function button one time.
- To *reject calls*, long press the earbud Multi-function button.
- You can *dial the last number* by quick pressing the earbud Multi-function button twice.

2. Listening to music:
Be sure the earbuds are connected with your mobile phone.

- To *pause/resume* music, short press the earbud Multi-function button one time.
- To *play next track*, short press the earbud volume "+" button.
- To *play previous track*, short press the earbud volume "-" button.
- To *increase the volume*, long press the earbud volume "+" button.
- To *decrease the volume*, long press the earbud volume "-" button.

3. Power off:
Long press the earbud Multi-function button for 5 seconds to power off earbud. The Earbud LED indicator will flash red 3 times indicating that the earbud has been powered off.

The earbuds will power off if they don't connect to any device within 5 minutes.

Charging your device

1. Charging your earbud(s):

- There will be a tone sound to indicate the earbuds need to be charged.
- Place earbuds onto charging dock and **press the charging button** to begin charge.
- The earbud(s) LED Indicator will turn red while charging and will turn off when fully charged.

Back

1. Charging your dock:

- While charging the dock, the LED Indicators will flash red and will change to a solid red when fully charged.

Specifications:

Bluetooth version:V5.0
Earbud Battery Capacity: 60mah each
Charging Dock Battery Capacity: 400mah
Play Time: Up to 21hrs

Features:

- Auto Connect Technology
- Built-in Microphone
- Up to 21hrs of play and charge time
- Connect wirelessly to iOS & Android devices
- Ergonomic design for a comfortable fit in your ear

Attention:

1. Handle with care. Do not throw, sit on, or store the SoundPods under heavy objects. Keep away from high temperatures and environments with high humidity. Store in an environment with a temperature between -10°C ~ 60°C.

2. Keep away from high frequency transmitting equipment such as WIFI routers which may cause sound interference or disconnection.

3. This product is a compatible with both iOS® and Android™ devices.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

© 2020 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., iPod, iPhone and iPad are trademarks of Apple Inc., The "Android" name, the Android logo, and other trademarks are property of Google LLC. , Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

Limited One Time Warranty.
To activate your product warranty go to our website. www.iHip.com & register this product.

iHip®
19 Progress St
Edison, NJ 08820
www.iHip.com

#iHip

Find us on Facebook.
Keyword: iHip: Portable Entertainment