www.1more.com

V1Q38

1MORE

TWORE Spearhead VR Gaming Headphones
User Guide

Content

Product Instruction

How To Use Retractable LED Lighting Tube

The USB cable connection allows for full functions of the Wireless 7.1 surround sound experience, which is compatible with your PC. To enable the synchronized vibration effect, please connect the headphones to your Spearhead VR Gaming Headphones, please download our driver
global.1more.com/download/spearhead-vr

Recommended Platforms: PC Windows 7 and above.

Compatible Platforms:

1. With USB cable, the functions of driver are compatible with PC (Windows 7, Windows 8.1, Windows 10).

2. With USB cable, Hi-fi audio (Hi-Res audio), microphone are compatible with Mac, Mac Book, PS3, PS4, Xbox 360, Xbox One (Xbox One Series Adapter Required, not included).

3. With 3.5 mm audio cable (4 pole) 1 mono (dialog) and microphone are compatible with PC, Mac, Mac Book, smartphones, PS3, PS4, Xbox 360.

*Please don't connect the USB cable and 3.5 mm audio cable at the same time. This could result in a failure of driver installation and functions.

*For first time use, USB C2 will stay in default or platforms above unless adjusted on your PC.

Basic Setting For Drive UI

Be sure to be wearing headphones and plug the USB cable to connect the headphones and your PC before the following operations.

How to adjust the headphones monitor volume:

Press and hold the left mouse button on the lower left icon and pull it up and down to adjust the speaker volume.

How to adjust the microphone volume:

Press and hold the left mouse button on the lower left icon and pull it up and down to adjust the microphone volume.

Synchronized vibration effect:

Press the mouse left icon using the left mouse button pin&pull up and down to adjust the synchronized vibration effect.

Environmental noise cancellation:

Click the left mouse button to enable the environmental noise cancellation function.

Head tracking function:

Click "head tracking" using the left mouse button to enter the custom setting interface.

Click the switch button on the top with the left mouse button to activate "head tracking", and reset according to the prompts.

LED light settings:

Single click "LED light setting" using the left mouse button to enter the custom setting interface.

Click the top switch button using the left mouse button to activate "LED light setting", and reset according to the prompts.

You can also choose the lower color options and use the LED color by clicking on the left mouse button.

Click the mode settings in left mouse button to choose the LED flashing mode.

If the selected LED flashing mode is "colorful breathing cycle light" and "breathing", you can also click in the left mouse button to cycle the "breathing rhythm" between Fast and Slow.



Equalizer settings:

Click the "Equalizer settings" using the left mouse button to enter the custom setting interface.

After the adjustment, you can click the "save" icon on the upper right corner in left mouse button, and name and save the Equalizer setting.
Note: the customizations must be different from at least one preset in the Noise&Hi-Res.

Click the top switch button using the left mouse button to turn on the "Equalizer settings".
You can select the Pre-set Equalizer by clicking the left mouse button.
Click and hold the Equalizer by clicking in the left mouse button and pulling it up and down.

The system allows up to 4 custom equalizer sound effects. If there are more than 4 sound effects, it is necessary to delete the existing sound effect before setting new ones.

Adjust The Headband For Comfortable Wearing

The flexible headband is designed to be as strong as possible, but can support only a certain amount of pressure and bending.
Adjust the ear cushions to the comfortable angles after wearing.

Wrong Usage

- To assure a full working life and prevent unexpected breakage, please do not bend or twist the headbands too many times/days.
- To assure the working life and avoid unexpected breakage, please do not place heavy objects on the headbands or LED lighting tube assemblies.

Limited Warranty

1MORE INC.,("1MORE") warrants to the original retail purchaser that the product (the "Product") will be free from defects in workmanship and materials for a period of two (2) years from the date of purchase. If it is proved, upon inspection, that the product (or any defective or other material or workmanship), 1MORE, at its option, will do one of the following: (1) repair the Product at no charge, using new or refurbished parts; (2) exchange the product in kind for a product available and current (or equivalent alternative) in quality and performance, 1MORE, at its sole option may replace the unit with a similar product, or (3) refund the purchase price. Repaired or replaced parts or the remaining portions may be required without a new location is established.
Warranty claims must be made within the warranty period, and prior to any repair or replacement under the terms of this warranty, please reach to dealer or 1MORE Customer Service for a return authorization number and instructions.
Return shipping for exchange/repairs is the sole responsibility of the original retail purchaser.

Limitations:
- This limited warranty does not cover failure of the product resulting from:
  - improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration;
  - any alteration or modification of any part of the product, including paint damage, or unauthorized damage to other components of the product, which may result for any reason from the failure of the product;
  - the product being used in full and not for personal use (and in accordance with 1MORE's instructions);
- This limited warranty is full and not for products with altered or missing serial numbers or for products purchased from unauthorized sellers or dealers.
- This limited warranty terminates if you sell or otherwise transfer the product to another party.

We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we are dedicated to bringing you the highest quality audio gear at a fair price.
Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one.

Important Safety Information

1. Long-term exposure to loud music may cause hearing damage. Avoid extreme volume when using headphones, and limit listening time to protect your hearing.
2. Do not use headphones while operating a motor vehicle or a bicycle. Doing so is dangerous and may violate local laws and regulations.
3. Keep headphones away from the cradle. It may contain sounds may present a danger to pets or children.
4. At all air conditions, static electricity can cause ear tingling. This is not a product defect.
5. Do not drop, pull, or pitch the headphones to not immerse in water.
6. Do not wear headphones in the rain.
7. Adult supervision is required in children age 6 and under.

FAQ

1. How to install the driver in a PC? What advanced functions can be realized by connecting to a PC?
Install the driver by connecting the wireless 7.1 surround sound USB cable, and scan the PC after installing the corresponding driver for MB-LS-V1, and connect custom vibration effect and volume control. Please visit the 1MORE official website, download the driver and USB-Wireless-Hybrid Tool (Simulation) to use.

2. What functions can be realized when devices are connected separately with 3.5 mm audio cable and USB cable?
With 3.5 mm audio cable connection, smart phones and other devices support stereo music playing and microphone functions. While with USB cable, devices support certain system such as Spatial Sound, Hi-Res Uncompressed Audio Transmission, and VR Gaming Interface.

3. What is the priority when connecting with 3.5 mm audio cable and USB cable at the same time?
The USB cable connection is a USB cable due to the default setting.

*The operating system in Windows 7 or Windows 8 with KB3033929 must be updated online first (one of the following two URLs) otherwise the headset driver cannot be installed. Please ignore the warning message during the driver installation.
Windows patch: http://www.microsoft.com/en-sg/download/details.aspx?id=46730
English patch: http://www.microsoft.com/en-us/download/details.aspx?id=47761

WEEE

Electrical and electronic equipment, parts and batteries marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. Find out about and dispose of separately collected waste in your area.

Your 1MORE retailer will deliver you of the correct way of disposal in your country.

CE

Hereby, TWORE, declares that Wired headphone is in compliance with the essential requirement and other relevant provisions of Directive 2011/65/EU.

FCC

Caution:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Content

產品概覽

伸縮式 LED 燈管操作

連接 Windows 7/8 電腦，用於獨聲音效與超級重低音振動效果，請下載安裝驅動程序：global.1more.com/download/spearhead-vr

連接手機，USB 數據線可以實現PC Windows 7 及以上系統

使用前的基本設定

請在連接耳機和電腦的情況下，進行以下操作，以調整耳機和電腦的設定。

調整耳機音量調節：
長按左側圖標，向上/下拖動，調節耳機音量。

調整麥克風音量：
長按左側圖標，向上/下拖動，調節麥克風音量。

調節同步震動效果：
長按左側圖標，再按壓一下，可在震動模式與音量調節模式之間切換。

環境降噪開關：
長按左側圖標，開啓/關閉降噪功能。

頭部追蹤開關：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉頭部追蹤，根據提示進行重置。

燈光設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉燈光模式。

長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓燈光模式。

均衡器設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉均衡器，調節，及保存預設均衡器。
*均衡器最多可設置4個自定義均衡器，當超過4個時，必須先刪除現有的一個，方可設置。
*自定義均衡器與Noise&Hi-Res的設置必須有一項不一樣的數值，否則不能保存。

長按左側圖標，開啓/關閉呼吸燈。

長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉均衡器，調節，及保存預設均衡器。

調整您的佩戴舒適

為確保耳機的使用壽命，及長期的一切使用，請勿過度彎曲或扭曲耳機。
請調整耳罩至適當的角度後佩戴。

錯誤的使用方法

- 為確保使用壽命，及長期的一切使用，請勿過度彎曲耳機頭梁。
- 請勿在耳機頭梁及伸縮式燈管上放置重物。

保固範圍

1MORE INC.,("1MORE")保證原始零售購買者(以下簡稱"購買者")在購買日期的兩年期間內，產品(以下簡稱"產品")沒有任何材料和工藝上的缺陷。如果產品在檢查中被證明有缺陷，1MORE，其選擇，將以下任何一項：(1)修復產品，使用新或翻新的零件；(2)用類似產品交換產品，1MORE，其選擇，可以用類似產品替換該產品；或(3)退款購買價格。
維修或更換的產品或剩餘部分可能需要在沒有建立新的保修期的情況下。
1MORE，其選擇，可以用類似產品替換，維修，翻新，或退款。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
原購買者的保修期內，維修或更換產品的運費是唯一責任。
原購買者在購買後，產品，不再轉售給其他買家。

感謝您的購買

為確保您的產品物盡其用，請務必閱讀以下安全說明。
請妥善保管本說明書以便日後查閱。
請勿將產品浸入水中。
請勿在雨天佩戴。
請勿在無人監護下讓6歲及以下兒童使用。

安全須知

1. 長期聽高音量音樂可能會對聽力造成損害。為保護聽力，請勿長時間使用高音量。
2. 駕駛機動車輛或騎自行車時，請勿佩戴耳機。這樣做可能會違反當地法律法規。
3. 請將耳機遠離充電底座。底座內部可能產生聲音或電磁干擾，可能對寵物或兒童造成潛在危險。
4. 請勿拋擲、拉扯或投擲耳機。
5. 請勿將耳機浸入水中。
6. 在任何天氣條件下，靜電可能會導致耳朵刺痛。這不是產品缺陷。
7. 請勿在雨天佩戴耳機。
8. 6歲及以下兒童需在成人監護下使用。

產品概覽

伸縮式 LED 燈管操作

連接 Windows 7/8 電腦，用於獨聲音效與超級重低音振動效果，請下載安裝驅動程序：global.1more.com/download/spearhead-vr

連接手機，USB 數據線可以實現PC Windows 7 及以上系統

適用平臺的基本設定

請在連接耳機和電腦的情況下，進行以下操作，以調整耳機和電腦的設定。

調整耳機音量調節：
長按左側圖標，向上/下拖動，調節耳機音量。

調整麥克風音量：
長按左側圖標，向上/下拖動，調節麥克風音量。

調節同步震動效果：
長按左側圖標，再按壓一下，可在震動模式與音量調節模式之間切換。

環境降噪開關：
長按左側圖標，開啓/關閉降噪功能。

頭部追蹤開關：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉頭部追蹤，根據提示進行重置。

燈光設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉燈光模式。

長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓燈光模式。

均衡器設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉均衡器，調節，及保存預設均衡器。

調整您的佩戴舒適

為確保耳機的使用壽命，及長期的一切使用，請勿過度彎曲或扭曲耳機。
請調整耳罩至適當的角度後佩戴。

錯誤的使用方法

- 為確保使用壽命，及長期的一切使用，請勿過度彎曲耳機頭梁。
- 請勿在耳機頭梁及伸縮式燈管上放置重物。

保固範圍

1MORE INC.,("1MORE")保證原始零售購買者(以下簡稱"購買者")在購買日期的兩年期間內，產品(以下簡稱"產品")沒有任何材料和工藝上的缺陷。如果產品在檢查中被證明有缺陷，1MORE，其選擇，將以下任何一項：(1)修復產品，使用新或翻新的零件；(2)用類似產品交換產品，1MORE，其選擇，可以用類似產品替換該產品；或(3)退款購買價格。
維修或更換的產品或剩餘部分可能需要在沒有建立新的保修期的情況下。
1MORE，其選擇，可以用類似產品替換，維修，翻新，或退款。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
原購買者的保修期內，維修或更換產品的運費是唯一責任。
原購買者在購買後，產品，不再轉售給其他買家。

感謝您的購買

為確保您的產品物盡其用，請務必閱讀以下安全說明。
請妥善保管本說明書以便日後查閱。
請勿將產品浸入水中。
請勿在雨天佩戴。
請勿在無人監護下讓6歲及以下兒童使用。

安全須知

1. 長期聽高音量音樂可能會對聽力造成損害。為保護聽力，請勿長時間使用高音量。
2. 駕駛機動車輛或騎自行車時，請勿佩戴耳機。這樣做可能會違反當地法律法規。
3. 請將耳機遠離充電底座。底座內部可能產生聲音或電磁干擾，可能對寵物或兒童造成潛在危險。
4. 請勿拋擲、拉扯或投擲耳機。
5. 請勿將耳機浸入水中。
6. 在任何天氣條件下，靜電可能會導致耳朵刺痛。這不是產品缺陷。
7. 請勿在雨天佩戴耳機。
8. 6歲及以下兒童需在成人監護下使用。

產品概覽

伸縮式 LED 燈管操作

連接 Windows 7/8 電腦，用於獨聲音效與超級重低音振動效果，請下載安裝驅動程序：global.1more.com/download/spearhead-vr

連接手機，USB 數據線可以實現PC Windows 7 及以上系統

適用平臺的基本設定

請在連接耳機和電腦的情況下，進行以下操作，以調整耳機和電腦的設定。

調整耳機音量調節：
長按左側圖標，向上/下拖動，調節耳機音量。

調整麥克風音量：
長按左側圖標，向上/下拖動，調節麥克風音量。

調節同步震動效果：
長按左側圖標，再按壓一下，可在震動模式與音量調節模式之間切換。

環境降噪開關：
長按左側圖標，開啓/關閉降噪功能。

頭部追蹤開關：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉頭部追蹤，根據提示進行重置。

燈光設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉燈光模式。

長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓燈光模式。

均衡器設置：
長按左側圖標，進入自定義設置界面。

長按左側圖標，開啓/關閉均衡器，調節，及保存預設均衡器。

調整您的佩戴舒適

為確保耳機的使用壽命，及長期的一切使用，請勿過度彎曲或扭曲耳機。
請調整耳罩至適當的角度後佩戴。

錯誤的使用方法

- 為確保使用壽命，及長期的一切使用，請勿過度彎曲耳機頭梁。
- 請勿在耳機頭梁及伸縮式燈管上放置重物。

保固範圍

1MORE INC.,("1MORE")保證原始零售購買者(以下簡稱"購買者")在購買日期的兩年期間內，產品(以下簡稱"產品")沒有任何材料和工藝上的缺陷。如果產品在檢查中被證明有缺陷，1MORE，其選擇，將以下任何一項：(1)修復產品，使用新或翻新的零件；(2)用類似產品交換產品，1MORE，其選擇，可以用類似產品替換該產品；或(3)退款購買價格。
維修或更換的產品或剩餘部分可能需要在沒有建立新的保修期的情況下。
1MORE，其選擇，可以用類似產品替換，維修，翻新，或退款。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
保修期內提出索賠；及，1MORE，其選擇，在產品的剩餘期內。
原購買者的保修期內，維修或更換產品的運費是唯一責任。
原購買者在購買後，產品，不再轉售給其他買家。

感謝您的購買

為確保您的產品物盡其用，請務必閱讀以下安全說明。
請妥善保管本說明書以便日後查閱。
請勿將產品浸入水中。
請勿在雨天佩戴。
請勿在無人監護下讓6歲及以下兒童使用。

安全須知

1. 長期聽高音量音樂可能會對聽力造成損害。為保護聽力，請勿長時間使用高音量。
2. 駕駛機動車輛或騎自行車時，請勿佩戴耳機。這樣做可能會違反當地法律法規。
3. 請將耳機遠離充電底座。底座內部可能產生聲音或電磁干擾，可能對寵物或兒童造成潛在危險。
4. 請勿拋擲、拉扯或投擲耳機。
5. 請勿將耳機浸入水中。
6. 在任何天氣條件下，靜電可能會導致耳朵刺痛。這不是產品缺陷。
7. 請勿在雨天佩戴耳機。
8. 6歲及以下兒童需在成人監護下使用。

Table de matières

Instruction du produit

Comment utiliser le tube d'éclairage à LED rétractable

Pour profiter de l'expérience audio de Wireless 7.1 surround sound, le câble USB est compatible avec votre PC. Pour activer l'effet vibration synchronisé, veuillez connecter votre casque au SpearHead VR Gaming Headphones, veuillez télécharger le lecteur :
global.1more.com/download/spearhead-vr

Plateformes compatibles:

1. Avec le câble USB, les fonctions du contrôleur sont compatibles avec PC (Windows 7, Windows 8, Windows 8.1, Windows 10).

2. Avec le câble USB, la sortie audio Hi-Fi (Hi-Res audio), le microphone sont compatibles avec PC, Mac, Mac Book, PS3, PS4, Xbox 360, Xbox One (adaptateur série Xbox One requis, non inclus).

3. Avec un câble audio de 3.5 mm, 1 prise (1 pôle) 1 le microphone sont compatibles avec PC, Mac, Mac Book, smartphones, PS3, PS4, Xbox 360.

*Veuillez ne pas vous connecter : avec un câble USB et un câble audio de 3.5 mm en même temps. Cela peut entraîner un échec de l'installation et des fonctions de réglage pour certaines.

*À la première utilisation, les LED ne présentent pas par défaut sur les plates-formes ci-dessus, à moins qu'elles ne soient réglées sur votre PC.

Paramètre de base pour l'interface utilisateur du lecteur

Assurez-vous de porter des casques et utilisez le câble USB pour connecter le casque à l'ordinateur et le personnaliser.

Réglage du volume du haut-parleur du casque :
Appuyez sur le bouton gauche de la souris sur l'icône en bas à gauche et faites-le monter et descendre jusqu'à ce que le volume du haut-parleur.

Réglage du volume du microphone :
Appuyez sur le bouton gauche de la souris sur l'icône en bas à gauche et faites-le monter et descendre jusqu'à ce que le volume du microphone.

Synchronisation vibration effect :
Appuyez sur le bouton gauche de la souris sur l'icône en bas à gauche et faites-le monter et descendre jusqu'à ce que le volume du haut-parleur.

Environnement noise cancellation :
Cliquez sur le bouton gauche de la souris pour activer la fonction de suppression du bruit ambiant.

Head tracking function :
Cliquez sur le bouton gauche de la souris pour activer la fonction de suivi de la tête.

Cliquez sur le bouton gauche de la souris pour activer la fonction de suivi de la tête et suivez les étapes.

Paramètres de détection de tête :
Cliquez sur le bouton gauche de la souris pour cliquer sur « head detection » pour activer la fonction de réglage personnalisé.

Utilisez le bouton gauche de la souris pour cliquer sur le bouton supérieur de commutation pour activer « head detection » et réinitialisez selon les étapes.

Réglage de l'éclairage :
Utilisez le bouton g