DBI-TX2 User Manual U.S. Version

Free Balloon Envelope Radiation Temperature Wireless Transmitter



Safety

The manufacturer has designed this instrument to be safe when operated. Do not use this instrument for any other purpose than stated.

Operating restrictions

- This instrument should ONLY be used in ships referred as *free manned balloons*.
- The DBI-TX2 must be mounted in the balloon exactly as shown in this manual. The responsibility however for the safety of the mounting of the sender is not a subject for the manufacturer or their representatives.

Abbreviations

DBI-002	DigiTool Instruments Free Balloon Flight Instrument	
DBI-TX2	DigiTool Instruments Envelope Radiation	
	Temperature Wireless Transmitter.	
RF	Radio Frequency	

Table of Contents


1.	DESCRIPTION	4
1.1.	GENERAL	4
1.2.	DBI-TX2 Рното	5
2.	SPECIFICATION	6
2.1. 2.2.	ENVELOPE THERMOMETER ACCURACY	
2.2.	PHYSICAL DIMENSIONS ENVIRONMENTAL RATINGS	
2.4.	RADIO FREQUENCY TRANSMISSION	
2.5.	POWER SUPPLY	
2.6.	RF TRANSMIT CONTROL	7
3.	INSTALLATION	8
3.1.	SAFETY	8
3.2.	ATTACHMENT	8
4.	OPERATION	9
4.1.	DBI-TX2 IDENTIFICATION CODE	9
4.2.	DBITX2 IDENTIFICATION CODE PROGRAMMING	9
4.3.	Power On / Off	9
5 .	MAINTENANCE	10
5.1.	BATTERY (LITHIUM CELL) REPLACEMENT	10
5.2.	APPROVED SERVICE AGENTS	

1. Description

1.1. General

- The DBI-TX2 is a wire less transmitter monitoring free hot air balloon envelope top radiation temperature. It transmits data to the DBI-002 flight instrument where temperature is displayed.
- The unit consists of a sturdy aluminum tube enclosure attached by a velcro strap to the basket overhead frame.
- The unit is power supplied with a replaceable long life lithium battery. Battery replacement interval is typically four years.
- Power on/off is controlled automatic by the difference of device (ambient) and radiation (envelope fabric) temperatures. No operator action is required.
- Each unit has a unique serial code that is matched with the receiver DBI-002. DBI-002 data reception is qualified by serial code and comprehensive transmission error detection.
- Short duty cycle and low RF power data transmission enables interference free operation and multiple units to operate in close proximity.
- Conforms to FCC part 15.249
- FCC approval identification: TDJGC132926

1.2. DBI-TX2 Photo



2. Specification

2.1. Envelope thermometer accuracy

Range °F	Total error +/- °F
-15 to 32	9
32 to 122	7
122 to 167	6
167 to 257	4
257 to 302	6
302 to 347	7
347 to 392	9

2.2. Physical dimensions

Item	Value	Value
Length	110 mm	4.4 inch
Diameter	50 mm	1.9 inch
Total weight	200 gram	5.6 ounce

2.3. Environmental ratings

Item	Value
Box sealing class	IP65
Box temperature High	257 °F
Box temperature Low	-22 °F

2.4. Radio frequency transmission

Item	Data
Frequency	914.5 MHz
RF Power	+0 dBm (1mW)
Modulation	FM, deviation +/- 30 kHz
Type Approval	
EMC conformity	FCC part 15.249
Placard marking	DBI-TX2
	FCC ID: TDJGC132926
	Code: NNNNN
Transmit duration	37 milliseconds
Transmit repetition interval	2.3 seconds
Transmit duty cycle	0.016

2.5. Power supply

Power supply	CR2450 3 Volt Lithium Cell
Cell life (on)	> 1000 hours
Cell life (off)	> 10000 hours
Lithium cell replace interval	1 years

2.6. RF transmit control

Transmit on differential temperature threshold, (probe – box).	> 10 °F
Transmit off differential temperature threshold, (probe – box).	<= 10 °F
Transmit on minimum duration	5 minutes

3.Installation

3.1. Safety

Always consult corresponding envelope flight manual for safe attachment.

3.2. Attachment



The DBI-TX2 attaches on one overhead frame rod. The IR lens aperture shall point straight up to the top centre of the envelope on a free line of sight.

4. Operation

4.1. DBI-TX2 identification code

Transmitter identification code is marked on the box placard.



4.2. DBITX2 identification code programming

Program the DBI-TX2 identification code to the DBI-002 flight instrument by using the DBI-002 PC application software. Refer to "DBI-002 User Manual".

4.3. Power On / Off


The power on / off is automatic:

- The DBI-TX2 will start transmission when a temperature difference between the ambient and the radiation temperature is greater than 10 °F.
- The DBI-TX2 will stop transmit after 5 minutes when a temperature difference between the ambient and the radiation temperature is greater than 10 °F.
- For permanent power off, remove internal battery coin cell. See "5.2 Battery replacement".

5. Maintenance

5.1. Battery (Lithium cell) replacement

- During normal operation, the internal battery will last for typical 2 years. Recommended replace interval is 1 years.
- Replace battery if DBI-TX2 does not operate properly.



5.2. Approved service agents

Name	Location	Contact
DigiTool AB	Box 6190 100 00 Stockholm Sweden	tel +46 8 343410 Email service@digitool.se