



The ActiLink Personal™

Step 1: Logon to www.actihealth.com.


Step 2: Download the ActiLink Software: Go to the tab marked **downloads** and click **Download ActiLink Software**. This will automatically begin the download process. At the end of the process you will have the  icon in your system tray.



Step 3: Plug the ActiLink™ into an available USB port.


ActiLink Software

The installation of the ActiLink software will put an ActiHealth icon  in your notification bar (system tray). This is typically located on the bottom right hand corner of your Windows Task Bar. See picture below:



With this icon you can click on  and it will open your web browser and automatically take you to www.actihealth.com. (If you have previously logged in and used the remember me check box, this will take you right to your dashboard!)

You can also right click on  to get to a list of maintenance options. When the  icon is yellow, this indicates there is no Internet connection.

When the  icon is white with red, this indicates there is no ActiLink™ plugged in to your USB.

Disclaimer

The ActiLink™ is not a medical device. This device is provided for feedback on exercise and routine activity only. FitSense recommends that you consult a physician before beginning any exercise program or performing strenuous activity.

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

Regulatory Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Patents

The ActiLink™ is covered in whole or in part by patents pending.

Specs

USB 1.0/2.0
Battery: N/A
Dimensions: .2.35 x .675" or .3"
Weight: 8 grams
Water Resistant: N/A
Operating Temperature: 14F to 104F
Storage Temperature: -4 to 122F
Transmission Distance: Up to 30 ft
Radio Frequency: 2.429Ghz
Compliance: FCC

Limited Warranty

The ActiLink™ is warranted against defects in material and workmanship for one year after purchase. Defective products will be repaired or replaced. The warranty does not cover normal wear, damage, loss or commercial use. The warranty is void if the unit is disassembled by anyone other than a FitSense Authorized Technician.

For any warranty claims please contact your plan administrator.

THE FORGOING IS YOUR SOLE REMEDY UNDER THIS LIMITED WARRANTY. IN NO EVENT WILL FITSENSE TECHNOLOGY INC. BE LIABLE FOR ANY INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF ABILITY TO USE THE PRODUCT EVEN IF FITSENSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.