

**How to put on your ActiPed on your footwear?**

There are two important things to remember when putting on your ActiPed.

1. It must be located on the top of your shoe between your toes and the front of your ankle.
2. It must be snug to your shoe and not loose where it can move or flop around.

For sneakers or shoes with laces, slide the ActiPed clip underneath 2 or 3 lace crossings and place the ActiPed™ near the top middle of your shoe. For shoes **without** laces, slide the clip underneath a strap, the tongue or anyplace that is on top of the shoe that the clip can snugly grip to.

**What does the ActiPed collect for your activity?**

The ActiPed™ collects activity data as steps, activity time, calories burned and distance traveled. It measures activity data for your run steps, walk steps or moving around.

It does not work for all types of activities, the ones primarily where your foot isn't hitting the ground in a manner that could be considered a verifiable foot strike. For example, elliptical machines and cycling.

The ActiPed™ will store approximately 10 to 30 days of activity data depending on how much you wear you ActiPed and your daily activity levels.

**How does my activity data get transferred from my ActiPed to my personal web account?**

The ActiPed™ wirelessly transports your activity data when it contacts an ActiLink data access device. This can be through either an ActiLink Personal USB device in your computer or other ActiLink devices set up in a building, facility or worksite.

**Need Help or Answers to Questions?**

For Help: Go to [www.fitlinxx.com](http://www.fitlinxx.com) click on Help and then look through the Frequently asked Questions or Email us at [support@fitlinxx.com](mailto:support@fitlinxx.com).

**Additional Information (Specifications):**

Battery Type: CR2032 Lithium 3V – non replaceable battery  
 Water Resistant: Non Submersible  
 Operating Temperature: 14F to 104F  
 Storage Temperature: -4F to 122F

**Limited Warranty**

The ActiPed™ is warranted against defects in material and workmanship for one year after purchase. Defective products will be repaired or replaced. The warranty does not cover normal wear, damage, loss or commercial use. The warranty is void if the unit is disassembled by anyone other than a FitLinxx Authorized Technician. For any warranty claims please contact your plan administrator.

**THE FORGOING IS YOUR SOLE REMEDY UNDER THIS LIMITED WARRANTY. IN NO EVENT WILL FITSENSE TECHNOLOGY INC. BE LIABLE FOR ANY INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF ABILITY TO USE THE PRODUCT EVEN IF FITSENSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.**

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

**Disclaimer**

The ActiPed is not a medical device. This device is provided for feedback on exercise and routine activity only. FitLinxx recommends that you consult a physician before beginning any exercise program or performing strenuous activity.

**Regulatory Information**

FCC ID: O9DAP4 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Fitlinxx could void the user's authority to operate the equipment.

**Patents**

The ActiPed is covered in whole or in part by the following patents: 6,336,365; 6,018,705; 6,052,654; 6,493,652; 6,298,314; 6,122,340; 6,357,147; 6,536,139; 6,560,903; 6,611,789; 6,882,955; 6,876,947 and other patents pending.