

IDEA

www.ideaworldhk.com

Ease Talk™

AI Translator



Artificial intelligence
simultaneous instant translation machine
born for the exchange of translation
【It's easier to communicate without language barriers】

“ Because of intelligence, we not only break through, but also broaden our vision, so we create a more convenient cross-boundary communication tool, "a tool to translate the language as soon as we speak", without the need to type, just to say what you want to say, it is so easy..

Product features

- Intellectual property patent voice-translation system and processing device, market exclusive applications
- Instant visual interface design, easy to operation
- Press the up or down key to translate the language, Press the down key to translate own language. Press the up key to translate the other language
- The translation language and grammar database keeps updating, keeping pace with The Times and enjoying free language upgrading
- Supports 28 languages and continues:

British English American English Japanese cantonese Arabic polish Danish German Russian French French (Canada) Finnish Korean Dutch Czech romanian Portuguese Portuguese (Brazil) Japanese Swedish Thai Greek Spanish Hungarian Spanish (South America) Italian Chinese traditional

Basic use guide

- **Switch machine**

Changan power supply key 2s. The screen lights up the power drawing, until the standby page can be used normally.

Turn off the machine and press the power button for more than 2s.

- **Display Screen**

Touch screen operation to enter the next menu or select the translation language.

The WIFI network is displayed when the data card is not inserted

Over the top of the screen, the wifi is displayed when the network is connected, and the 4G signal has data transmission, which shows that the power is presented by the battery pattern

- **Lock**

Press the power button to lock the machine, and press unlock again. The translation machine is not operated (time based on user's custom) for a certain amount of time.

- **Automatic translation**

Press the button below, listen to the prompt and enter the first language of speech. After release, you can play the second choice of language translation results.

Press the button on the top, listen to the prompt and enter the second select language, then play the first choice of language translation results.

Touch screen selection, the left side is the first choice language, the right side is the second choice language, the double arrow in the screen clicks the first second language switch.

- **The volume button**

Side keys adjust volume, click the volume to reduce the key to the minimum silent mode.

- **Reset**

At the same time, press the power button and the volume reduction button, and the interpreter restart.

Product parameters

The wireless network	WIFI	USB	Micro 5Pin USB(支持 1.5A 快充)
Bluetooth		battery	1300 mAh
The adapter	5V/1A	bugle	2030BOX
Network band	NO		

Operation:

The product components contain metal, plastic and internal sensitive electronic components. If it is thrown, burned, pierced, squeezed or exposed to chemical liquids, it can lead to damage.

maintenance:

Please do not disassemble the interpreter and try to repair it on its own. If there is any damage, failure or contact with liquid, please contact customer service.

Using the environment:

Avoid using a translator in an environment of too high or too low temperature to avoid prolonged exposure to the sun. Please keep the interpreter and power adapter in a well-ventilated environment to avoid metal corrosion.

charging:

Using a cable and power adapter; Or in line with the national 3C certification input: 100-240v ~ 50/60hz0.2a output Qoutput:5V== = a standard of power supply. Please check the power adapter manufacturer carefully to find out if it meets the requirements.

Operating temperature:

Translation machine is suitable for the temperature between 55 ° ~ 10 ° ~ work environment, if working environment over the temperature range, translation machine may lead to failure, and shorten the battery life, please avoid direct sunlight, heat, cold, damp environment use.

Precautions for use:

To ensure the quality of translation and the integrity of the sentences, press the translation key and then, after 1 second, you will be asked to translate the sentence. Please use normal speed to speak coherently, please do not stop many times during the speech, or two sentences and say that the above situation is easy to cause the translation is not allowed, please try to avoid. Try to avoid catchphrases or local slang.

After talking, you can check what you have said through the text displayed on the screen. When using a translator for charging, the heat of the machine is normal.

If you choose Chinese recognition, but the translation is not accurate, you can try to change another expression.

Common problems

1、 The product can't start?	<ul style="list-style-type: none">Check whether the electromagnetic charge is on commission and insert charging line to charge the product.Press the power button and release it to determine whether the boot screen is open normally.
2、 Voice recognition is not accurate?	<ul style="list-style-type: none">Please press the button to hear the prompt and then speak. After that, please release the key.please speak standard language and avoid using dialect or slang.speak in a coherent, clear, natural way and avoid multiple pauses or merging statements.
3、 Unable to connect	<ul style="list-style-type: none">Make sure to connect to WIFI properly and enter the correct password.currently, there is no support for the WIFI source that needs to be logged in, such as hotels,

to WIFI?	airports and public places.
4 、 Can't normal charge?	<ul style="list-style-type: none"> • Check for the correct matching power adapter. • check whether the wires and interfaces are properly connected.
5 、 How to maintain the product properly?	<p>press the shutdown key to disable the machine when not in use.</p> <p>, avoid - 10 ° ~ 55 ° outside the temperature range of use.</p> <ul style="list-style-type: none"> • this product is not waterproof, please do not put the product into the water.

warning

Translation machine is authenticated by the form of qualified low power frequency electrical appliances, and without permission or users shall not change the battery company, a firm, increase the features of electric power or change the original design. This product is not suitable for children under 14 years of age. Please use it with your parents.

Before the signal is used, please do not affect the safety of the flight and interfere with the legal communication. When it is found that there is interference, it should be discontinued immediately until there is no interference.

Failure to comply with safety instructions may result in fire, electric shock, injury or damage to the translation machine or other property. Please read the safety instructions before using any problems or maintenance.

Exemption clause

Please read the product description carefully before using:

- this product is not responsible for translation results
- , do not put the product placement in 55 ° ~ 10 ° outside the temperature range of use
- this product is not waterproof, do not put the product into the water
- children over 14 years of age should be used under adult supervision

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Certificate of conformity

Product name: artificial intelligence • simultaneous instant translation machine

Product model: S350

Name : _____

Phone call: _____

Customer address: _____

The content of the warranty _____

After the sale _____

Customer signature _____

satisfaction dissatisfied

Warranty regulations

- 1、The warranty period of this product is 3 months
- 2、During the warranty period, a failure occurred in the case of the normal use of the instructions in accordance with the instructions(Judging by the after-sale service personnel of NingQuc Technology), Give free repair
- 3、During the warranty period, the following conditions are not in the scope of free warranty:
- 4、Can not provide this guarantee and valid purchase certificate
- 5、Malfunction and damage caused by misuse and unsuitable repair
- 6、Failure and damage caused by other unavoidable external factors
- 7、Damage caused by improper use of water or other solutions caused by improper use of the equipment
- 8、Damage caused by the use of other power supplies and voltages
- 9、only more than that without any other express or implied warranty (including merchantability, for a particular application and the rationality of the implied warranty), whether in contract, tort or other aspects, the company responsible for any special, incidental or consequential damages.
- 10、This guarantee is valid only within the territory of People's Republic of China