TBLTXB3A

User Manual

NOTICE

This manual, software and electronic circuitry are copyrighted. All rights reserved. Under the copyright laws, this manual, software and electronic circuitry may not be copied, in whole or in part without written prior consent of Lee Technology.

All information provided in this document is carefully prepared and offered in good faith as a guide in the installation, use and servicing of our products. Installers must ensure that the final installation operates satisfactorily within the relevant regulatory requirements. Lee Technology accepts no responsibility for incorrect installation. Lee Technology reserves the right to change products, specifications and installation data at any time without notice.

Lee Technology makes certain limited warranties with respect to defective diskettes, documentation and electronic circuitry. Please see the associated information contained on this page.

LIMITED WARRANTY

With respect to the physical documentation and physical electronic circuitry enclosed herein, Lee Technology warrants the same to be free of defects in materials and workmanship for a period of one year from the date of purchase. In the event of notification within the warranty period of defects in material or workmanship, Lee Technology will replace the defective diskettes, documentation and electronic circuitry. The remedy for breach of this warranty shall be limited to replacement and shall not encompass any other damages including but not limited to loss of profit and special incidental, consequential, or other similar claims.

Lee Technology Korea specifically disclaims all other warranties, expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose with respect to defects in the documentation and electronic circuitry and the program license granted herein, in particular, and without limiting operation of the program license with respect to any particular application, use or purpose.

1. SYSTEM INTRODUCTION

1) SYSTEM SUMMARY

LEETEK's Tablecall Paging System was designed specifically to help guests immediately page their servers or managers when they need anything, so they can be served whenever they want. With this solution, it is needless guest's are waiting for their turns for served and servers are more convenient because it is needless to visit guest's table twice and it will keep servers from duplicating with each other. It will help reduce the number of servers and also reduce the noise as well. Your restaurant will be more quiet and high-quality. It'll help you provide "Always Customers First" Services.

2) SPECIFICATION

FEATURE	BENEFIT
TECHNOLOGY	° UHF Technology (450~470MHz)
	° Perfect for large restaurant, Café and Bar
	° Wireless Paging System
TABLECALL TRANSMITTER	° POCSAG Code
	° Operate in FM mode on UHF
	° 3 kinds of Version
	° Output Power: 13 dBm
	° Dimension: W(109) X D(107) X H(15)
	° Weight: 120g
	° PC Programmable
	° Rechargeable
	° SMART CHARGING (with own charger base)
TABLECALL PAGER	° POCSAG Code
	° 12 Segments Display
	° 2 kinds of pager (Belt Type / Watch Type)
	° Belt Type – Rechargeable (with own charger base)
	° Watch Type – Operated by AAA Battery
	° Automatic Back Light
	° Various Alert Type (Vibe / Beep / Flash) Selectable
	° Auto Delete
	° Waiter & Manager Pager Available
RESTAURANT SYSTEM ID	° Unique Base ID to eliminate overlapping message
APPLICATION	° Restaurant, Café and Hotel

2. INSTALLATION

1) EQUIPMENT SETUP

(1) Transmitter

Unwrap all sending unit components. Plug the power supply with the large tip into a standard outlet and plug it into charger base for transmitter. Stack the transmitters on the charger base. The red indicator will be lighted on and it means the transmitters are charged properly. We recommend some type of surge suppressor on the power supply for protection. Power surges are not covered under system warranty.

(2) Pager

Locate the charger base in a sturdy, out of the way location. Connect the charger base with TX charger base using included jump wires. Be sure to plug the jump wires & power supply jack in all the way.

Insert the pagers on the charger base. The pager number will always face top and the red charging indicator will be lighted.

You should check a charging indicator appear on each pagers. This light indicates proper charging is taking place.

On the top of each pager is your pager number.

2) PLACEMENT

(1) Transmitter

Place the tablecall transmitter on the proper location of table. Be sure that transmitter will not be dropped by mistaken and check the transmitter number is match with the table number.

(2) Pager

Attach the pager on the waiter(manager)'s belt using its belt clip. Be sure that the message "READY" is displayed on the screen. If the message is not displayed, then the pager is now turned off. So please press and hole the side button until it is turned on.

3. OPERATION

1) To page Waiter

- When you press WAITER button shortly, it transmits and displays "TABLE Number" to the waiter pager.
- After transmitting is finished, red LED blinks once.

2) To page Manager

- When you press MANAGER button shortly, it transmits and displays "TABLE – Number" to the manager pager

- After transmitting is finished, red LED blinks once.
- 3) To cancel page
- When you press CANCEL button, it transmits and erases the previous page(Table No.).

4. HOW TO USE

1) Restaurant, Hotel, Café

- (1) Direction for Use
 - For calling staffs
- (2) Process
 - A guest can page to waiters by pressing the "WAITER" button on the transmitter, when the guest needs some help to request such as receipts or menu order.
 - If the guest is not satisfied by the services from waiters, he/she can page to Manager by pressing the "MANAGER" button on the transmitter.
 - After serving the services, the waiter can press the "CANCEL" button to complete the guest's requests.

(3) Merits

- This new premium paging system is not compared to the exited call bell systems. In addition, it helps you to provide the high-quality services to your customers.
- It eliminates the noise from the bells, and makes customers feel more comfortable.
- It will also help reduce the number of servers.

2) Hospital, Silver Town

- (1) Direction for Use
 - For calling Nurses
- (2) Process
 - A patient can page to Nurse by pressing the "NURSE or EMERGENCY" button, when a patient needs some help.
 - A nurse can come to the patient room and serving the patients. After serving the services, the nurse can press the "CANCEL" button to complete the patient's requests.
- (3) Merits
 - When emergency occurred, the patient can immediately call to nurses.
 - Nurses can check the calls from patients on real time.

3) Casino, Night Club

(1) Direction for Use

- For calling staffs
- (2) Process
 - A guest can page to waiters by pressing the "WAITER" button on the transmitter, when the guest needs some help.
 - After serving the services, the waiter can press the "CANCEL" button to complete the guest's requests.
- (3) Merits
 - This paging system can be used in a crowd place where guests are not able to call waiters by voices.
 - It will also help reduce the number of servers.

4) Pool Side

- (1) Direction for Use
 - For calling staffs
- (2) Process
 - A guest can page to waiters by pressing the "WAITER" button on the transmitter, when the guest needs some help.
 - After serving the services, the waiter can press the "CANCEL" button to complete the guest's requests.
- (3) Merits
 - It will help reduce the number of servers and also reduce the noises well.

Caution

Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.