

SET UP INSTRUCTIONS EXTRA PENDANT Model #41915

Contents



Pendant



Belt Clip



**Rechargeable Li-Ion Special
Pendant Battery - 1 piece**



Wrist strap



Lanyard

This Extra Pendant is to be used with the CaretakerSentry product model 40914. Up to 9 pendants (or a total of 9 DECT and 433 pendants and Emergency Wall Communicators) can be taught to one base unit. For full instruction on the use and limitation of this product - refer to the CaretakerSentry user manual.

Before programming this extra pendant to work with you CaretakerSentry base unit, you must acknowledge that all of the Warnings, Limitations of Liability, Disclaimers, FCC information and Testing Instructions written in the CaretakerSentry instruction manual pertain to the use of this product as well when used with the CaretakerSentry product. By programming this extra pendant to your CaretakerSentry product, you acknowledge that you have a copy of these instructions and have read them. If you do not have a copy, you can always get a copy off of our website or by calling our company and requesting one.

Installing the Battery

The Pendant requires one of the white Li-Ion (Lithium Ion) batteries at any given time. The pendant should be able to run up to 4 months on a fully charged battery. Simply slide the pendant battery cover latch and install the Pendant battery following the direction diagram inside of the battery compartment. You will hear a voice confirmation of the battery status when properly installed.

Teaching the Extra Pendant to the CaretakerSentry System.

On the Base Unit:

1. Push and release the RED Code Learn button on the back of the base unit. You will hear a voice prompt “Pendant Learning”

On the Pendant:

2. PUSH the Blue Emergency button and then IMMEDIATELY push the Gray Test button –HOLD both buttons until you hear “Pendant Learning” from the pendant - then release both buttons on the pendant.
 - If “Base and Pendant out of Range” is

heard from the pendant, STOP - wait 30 seconds and start at step #1 again.

3. When Pendant learning has been successful you will hear “Pendant Code Learned” and then it will announce the call setting that the base is set to – Programming Mode or Emergency Call Mode.
 - If “Base and Pendant out of Range” is heard from the Base or Pendant, STOP - wait 30 seconds and start at step #1 again.

Notes:

- You have up to 45 seconds after pushing the RED Code Learn button on the base unit to get the pendant to enter “Pendant Learning”.
- Teaching additional pendants does not erase previously learned pendants.
- The base unit will automatically exit the pendant learning mode after several seconds or “Pendant Learning Failed”.
- If you hear the voice prompt “Base and Pendant Out of Range” an error has occurred, wait 30 seconds for the base to

reset and repeat steps 1 & 2.

- A combined total of 9 pendants and Emergency Wall Communicators can be learned to a base unit. If a pendant has been lost or replaced - erase all pendants and relearn all current pendants and any Emergency Wall Communicators.

At a later point in time, you might want to erase your previously learned pendants. You can erase all previously learned pendants by simply holding down the red **Code Learn** button at the back of the Base unit for 8-10 seconds. you will hear the confirmation of “Previous Pendant Codes Erased” from the Base unit. After that, you can program a new pendant to the base unit following the steps above as desired.

Battery Check / System Check:

The CaretakerSentry has a built-in battery tester and method to check the whole system. You should make yourself familiar with these tests from the main CaretakerSentry users manual. If you do not have these important safety instructions, please get them from our website or by calling the company.

Water Resistance:

Please note that although the pendant is water resistant, it is not waterproof. Regular exposure to water, soaps, shampoos and conditioners can damage the water seals over time as well as affect the performance of the speaker – reducing the volume. To prolong the life of your pendant, we recommend laying the pendant just outside of the shower or bathtub – but well within reach should an accident happen in the shower or bathtub area.

If you have further questions on this product, call our TECH SUPPORT department at 1-888-283-6516.

Information The FCC Wants You To Know:

Caretaker Sentry 2-way Voice Pendant - Model 41915

FCC ID: TYD-CS41915

IC: 8471A-CS41915

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This portable transmitter with its antenna complies with FCC/IC RF exposure limits for general population/uncontrolled exposure.

This Device complies with Industry Canada License-exempt RSS standard(s). Operation is subject to the following two conditions: 1) this device may not cause interference, and 2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme à Industrie Canada exemptes de licence RSS ou les normes. Opération est sujette aux deux conditions suivantes: 1) cet appareil ne doit pas brouillage et 2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable du dispositif.

ONE YEAR LIMITED WARRANTY

LogicMark, LLC warrants to the original consumer/purchaser that this product shall be free of defects in material and workmanship under normal use and circumstances for a period of **one** (1) year from the date of original purchase for use. When the original consumer/purchaser returns the product pre-paid to LogicMark, LLC; 10106 Bluegrass Pkwy; Louisville KY, 40299, USA within the warranty period, and if the product is defective, LogicMark, LLC will at its option repair or replace such.

This warranty shall constitute the sole liability of LogicMark, LLC concerning the product. LogicMark, LLC expressly disclaims all other warranties INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO PERSON, FIRM, OR CORPORATION IS AUTHORIZED TO ASSUME FOR LogicMark, LLC. ANY OTHER LIABILITY IN CONNECTION WITH THE SALE AND USE OF THE PRODUCT. LogicMark, LLC and agents and distributors will bear no liability whatsoever for incidental or consequential damages or charges of any kind.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above disclaimer regarding incidental or consequential damages may not apply to you.

This warranty is void if the product has been damaged or tampered with or if the product or any such parts have been opened. In all cases of damage during shipment, a claim must be filed with the shipping carrier and not with LogicMark, LLC.

This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

OUT OF WARRANTY REPAIRS

If the warranty period has expired or if you are not the original owner of the product, LogicMark, LLC will at its option either (1) replace this product with a functionally similar (but not necessarily identical) refurbished product or (2) repair the original product and return it to the original consumer/purchaser after payment of repair/replacement charges has been received.

LogicMark

10106 Bluegrass Pkwy
Louisville KY, 40299

Tel: 1-502-410-0402

Toll Free: 1-888-283-6516

Fax: 1-703-934-7935

www.LogicMark.com