
Operation manual

Thank you for choosing OZNER Smart Cup, please read this manual carefully before using. OZNER Smart Cup will lead you step into a new era of access to healthy drinking water.

Make sure to read before using

Please make sure to read the following notes for safety in order to avoid any inconvenience caused to you.



Please don't dip the cup into the water for a long time.

Never heavily strike the cup due to ceramic cup body used in this product to avoid any damage.

Never clean the cup into the dishwasher or heat in the microwave oven.

Always charge the cup with standard USB interface or high-quality USB charger, and make sure no water stain left on the charging outlet before charging.

Never heavily strike the cup when using. Water drinking volume is collected by the high-precision sensors. Strong impact may cause the sensor error increases, or even damaged.

Register using flow

Step I: Download the APP of OZNER, please scan the QR code as follow:



Scan the QR code, focus on Ozner water purification technology, enter my menu, click on "I", download mobile phone APP.

Step II: Log in APP to match the OZNER Cup. First, reversely place the OZNER Cup while matching the OZNER Cup, and then match according to the tips of APP.

Step III. Complete personal data and set the reminder of smart water Drinking.

You can start using the OZNER Smart Cup.

Introduction to functions

01. Bottom navigation

There are four buttons at the bottom of the navigation:

Smart control:

a. OZNER Cup:

Enter the control page of OZNER Cup

b. Water purifier:

Enter the product page of water purifier

Have a test:

a. Determine the TDS of this cup of water:

This function automatically reads the TDS of the cup connected currently, the firstly activated cup shall work if two and above cups are connected. Click on the question mark to view the explanation and description of TDS numeric value meaning.

Share it in the moments via the sharing button on the top of right corner.

b. Detect the temperature of this cup

Awake the cup, and view current temperature of this cup via APP.

c. Determine the volume of water drinking

Awake the cup. And view the drinking volume via APP at this time.

Discovery:

Health Group: Recommendation of Healthy Products Water Knows Health: Share of Water Purification Tips Gift card: Enter the gift member page of OZNER

Service branches search: View the national service networks of OZNER

Me:

Individual data card: View and modify personal data

My private coffer: View personal scores

My advice: Comment, suggestion and feedback

02. Home page of OZNER Cup

Dynamic report of water drinking today: Count the TDS, water drinking state and drinking temperature today. And at the same time, display the state and distribution of three indexes on the same day.

03. Navigation on the left

The content of navigation column on the left differs when current user selects each smart products. The navigation column may be either marked out from the left of the screen or click and call out from the icon on the top left corner. Currently for smart cup products, the content of navigation column is as follows:

Healthy water drinking report

View the water drinking report of current week and month. View water drinking details of my cup and family members. Choose the specific cup and then view the data when some cups of families are added.

My list member

a. Add the list member:

The user may find and add his/her list member via mobile number or nick name.

b. View the ranking:

It can view the water drinking volume of other friends and check the TDS and ranking of water drinking volume in current week and month. Know the water drinking volume of friends in current week.

c. OZNER Cup matching

First, the "cup matching" page is skipped when the user clicks "Add the cup". After scanning the pairing is successful, fill in the name of OZNER Cup and choose "My Cup" or "Cup of Family Member" to conduct matching setting.

Smart water drinking reminder

This function mainly aims at setting the water drinking reminder of OZNER Cup, there are different pages for my cup and cup of family, the content of this page will automatically change when the user selects "My Cup" and "Cup of Family Member".

For the setting of optic circle, it displays the TDS and temperature (Optional).

State of OZNER Cup

Check the remaining battery of cup and the Bluetooth is connected or not.

About OZNER Cup

Introduction and operation manual of OZNER Cup

Main technical parameters

Model CUP B1 office white series

CUP B2 office black series

Dual-cup of CUP P friends series

Triple-cup of CUP H family series

Communication protocol Bluetooth 4.0

Power supply mode Standard USB 5V 500mA

Applicable water temperature $0\sim100$ °C

Appropriate environment temperature 0~40°C

Cup volume $300 \pm 20 \text{ml}$

Size $138 \times \Phi 72 \text{ mm}$

Weight 350g

Online Upgrade

The system can automatically monitor the software situation of APP new version. When the APP has a new version, the user is prompted to upgrade.

For Apple users, they can prompt the upgrade and automatically jump to the APP Store to upgrade; For Android users, the system can alert the user to upgrade and confirm. If the user clicks "OK", the system will automatically download the latest installation package and automatically upgrade.

Support phone and systems

Android smart devices	Bluetooth 4.0, above android 4.3	
Iphone	4s and above, above IOS 7 systems	

Fittings of OZNER Cup

		•	
	Single-cup	Dual-cup	Triple-cup
Cup(number)	1	2	3
Charging Cable(number)	1	2	3
Certificate(page)	1	1	1
Warranty card(page)	1	2	3

FAQs treatment

Question	Solution	
	Confirm open Bluetooth , and make sure the phone	
	models are supported.	
	When searching for the cup match, please make sure	
	the cup is received within Bluetooth range.	
Unable to find cups	Confirm cups have adequate power.	
	If not resolved, please contact customer service.	
	Bluetooth services occasionally abnormal on	
Occasionally cups connection is closed	Some phones, Please try a few times.	
	Due to energy-saving requirements, there may	
Don't appear immediately drinking	be some delay statistics	

After-Sale Service Hotline

If you can not solve the problem, please call 400-820-2667, there is our customer service staff to serve you.

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Shanghai Ozner Comfort Environment & Science Company Limited** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.