

Product Specification

1. Current consumption: 1.35mA av.
2. Amount of constant test time: 220 hours.
3. Work Environment: temperature: between 5°C and 40 °C. Humidity: <70%
4. Moisture content range: 20%-60%
5. Error: <1%
6. Size: 27mm*22mm*63mm
7. Working together with Application: Meijia

Product Function

As a small-size and stylish-design one, our product is convenient to use and carry. Basing on the technology of detecting Biological impedance, accompanied with data mining technology in our App “Meijia”, our product manages to test out moisture content of human’s skin and then give out deep analysis.

The whole test process takes about 5 seconds, whose result then will be sent to Smart Phone through Bluetooth Low Energy and shown in our App. Besides, according to the real-time value of your skin moisture content and your personal body message, we will provide the accurate and exclusive skin care advice.

Instructions

- 1st.take away the cap.
- 2nd.Press the button on the bottom of product. Then the blinking green led means the device is waiting for connection.
- 3rd.Run the Meijia APP on your mobile phone, led will turn constant green if connection is successful.
- 4th.Chose one position of your body in App, then put the sonde of product on the position correctly(the sonde must be pressed wholly), the test will begin automatically.
- 5th.While testing, led will turn constant blue, do not move away the sonde until test finishes when the led will turn back constant green.
- 6th.Redo step 4&5 if you want to retest.
- 7th.Press the button on the bottom of product again to turn it off.
- 8th.Wipe the sonde with alcohol drenched cloth and replace the cap.
- 9th.For an accurate result, please wipe the test position cleanly, in case of the sweat and other materials affect the result.

Common questions

- 1st.If led keeps blinking green, it means product and app do not connect.
- 2nd.If led keeps constant green, it means product and app connect successfully. Test can begin now.
- 3rd.If led keeps constant blue, please do not move away the sonde until the test finishes when led will turn back constant green.
- 4th.If led keeps constant red, it means wrong operations have been done. Wait until led turn back constant green and test again.

guarantee

- 1st.Keep the sonde of product clean.
- 2nd.Plsase do not dismounting the product.
- 3rd.Please prevent product from high-temperature and high-humidity environment.
- 4th.Please put back product into box after use.
- 5th.Be aware of water and liquid entering into product. Wiping product with acid and alkaline liquid is forbidden.
- 6th.If the battery's electric quantity is insufficient, we will give you a new one for free.

Using steps:

- 1st.Open the Bluetooth on your phone, run our App "MeiJia".
 - 2nd.Press the button on the bottom of product, the blinking green led will turn constant green if BLE connection is successful.
 - 3rd.Put the sonde of product on test position, press slightly then test will begin while led will keep constant blue.
- *If led turns constant red means wrong operations have been done.
- 4th.After analysis within 5 seconds, the result will be shown in our App "MeiJia".

Moisture content at Spring&Autumn(normal value)

Orbital(35%~50%)

Forehead(30%~43%)

Cheek(32%~47%)

*At summer the moisture content varies about 3% while at winter varies about 5%

Supported phone's system and type

Iphone4s,Iphone5,Iphone5s,Iphone5c

The ones which support Bluetooth 4.0 and are assembled with IOS 5/6/7:

Iphone4s,Iphone5,Iphone5s,Iphone5c

Samsung Galaxy S3/S4、 Samsung Note 3 and so on;

The most ones which support Bluetooth 4.0 and are assembled with System of Android 4.3 or upgrade from System below Android 4.3

Notes:

- *Before using, please read carefully and follow the operation instruction.
- *For an accurate result, please wipe the test position cleanly, in case of the cosmetic、 oil and other materials affect the result.
- *Although the design of product has controlled the pressing strength in a specific range, its value will still affect the result a little bit. So please mind the strength while pressing, better at the level when transparent shell touches the skin.
- *Keep snode in touch with skin without shaking in 5 seconds in order to decrease error probability and increase reliability.
- *Keep snode of product clean.
- *Metal allergies should use with caution.
- *Do not use while the skin has wound or inflammation.
- *This product is not waterproof. Please do not soak it in water.
- *If the instruction led does not work, please contact our company and do not dismantling the product.

Guarantee

Shenzhen Mlizi Science and Technology Limited Company obeies strictly <Product Quality Law of The People's Republic of China> and <Law of the PRC on the Protection of the Rights and Interests of Consumers> ,also gives out Three Guarantees For Products to customers. If our Terms of Service is not compatible with Three Guarantees For Products, refer the rules and content of latter one. For those of regions that execute special directory of Three Guarantees of Products, Shenzhen Mlizi Science and Technology Limited Company will obey local relative rules.

Please note: Any situation mentioned below does not belong to the range of Three Guarantees For Products.

1st.Product that out of date.

2nd.Damage caused by using/maintaining/keeping product that have not followed the product operation instruction.

3rd.Danage caused by dismount by the ones who do not undertake the Three Guarantees of Products.

4th.Without the Three Guarantees of Products certificate or effective invoice(except the ones that can prove the product is within the date).

5th.Unauthorized alter of Three Guarantees of Products certificate.

6th.The type or number of product in Three Guarantees of Products is not compatible with product in kind.

7th.Without manufacturer's name、 manufacturer's address、 manufacture date or manufacturer's certificate.

8th.Cause by unpreventable strength.

Contact us directly if you have any question

Shenzhen Mlizi Science and Technology Limited Company

Guarantee Address: Shenzhen City, Nanshan District, SangTai Buliding, Block A, 1901

Service hotline: 0755-26607306

1. This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received,including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.

- - Increase the separation between the equipment and receiver.

- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

.