AFP1-Smart-Tool

AFP1 - SmartTool


SHORT INSTRUCTION MANUAL

General description

Congratulations on your purchase of a ROTRONIC AFP1 probe. Please read this short operating instructions carefully before putting the unit into operation. The document is limited to the description of the main features and the installation of the device.

The AFP1 probe measures along with humidity and temperature also wind speeds of 0.5 to 20 m/s.

Dimensions



Energy supply

The AFP1 is powered by two CR2032 button batteries.

When inserting or replacing the batteries, place them on top of each other in the battery compartment slide (observe polarity).

Federal Communication Commission Interference Statement

his equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures

- -Reorient or relocate the receiving antenna. Increase the separation between the equipment and receive
- -Connect the equipment into an outlet on a circuit different from that
- to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation


- IMPORTANT NOTE:
- Radiation Exposure Statement

The product comply with the US portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Device Operation via multifunction key

The AFP1 features a multifunction button, which is located on the front, below the sensor head. The following functions are controlled via the button: Switch on with auto-power-off after 5 minutes

- Switch on
- Switch off -
- . Calibration mode humidity





AFP1 on the Smart Device


After commissioning of AFP1 the LED should light up green. The device is now switched on and ready to perform measurements. To measure wind speeds ensure that the wind turbine rotates freely and the sign "AIR IN" points in the direction of the measured air flow. Operation of AFP1 sensor via the ROTRONIC smartphone application "ROTRONIC" which is available in the App Store (iOS) or in Play Store (Android) for free.

Use the app to display, log and send the desired measurement values by email. Furthermore, among other things, measurement-specific settings and options can be set.

The "ROTRONIC" APP







Menu Home View current measuring values Feedback Data export Export saved data Feedback Send feedback to ROTRONIC About TOTRONIC contact information Parameter settings To make alarms or parameters specific settings, just click ≫ Vo the appropriate parameter on the home screen. High Alar Features Low Alar Set high and low alarms 🗖 🚍 🖪 Parameter-specific settings Picture mode The "Picture Mode" has been implemented to photograph specific measuring points at which the measurements are saved directly on the photo.

Graphical mode In the "Graphical Mode" the current measured values can be graphically displayed and viewed. To toggle the visibility of a certain curve click on the corresponding parameter symbol Data export Stored data will be saved in the "Data Export" menu and logfile1 14.11.2015 09:23 09:54 can be renamed, deleted, or sent via e-mail. logfile2 14:10 16:04 About The menu "About" includes contact information of all Switze ROTRONIC Grindelstra CH-8303 B +41.44 830 www.rotro ROTRONIC AG offices. Street address German Phone number France Italy Website UK E-mail address USA Singapore China Canada

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and (1)
- This device must accept any interference received, including interference that may (2) cause undesired operation.

| rechnical specifications | 1 |
|-----------------------------|---|
| General | |
| Sensor type | Vane anemometer |
| | ROTRONIC HYGROMER® IN-1 |
| | NTC |
| Measuring range | 0.520 m/s |
| | 0100 %RH |
| | -2060 °C |
| Accuracy | ±(3 %reading + 0.2 m/s) |
| | ±3 %RH (at 25°C) |
| | ±0,3 K (at -2050°C) |
| Log interval | 1 s |
| LED | 1 dual color LED |
| | Red: Battery level too low to maintain proper operation |
| | Green: Battery and communication normal |
| Power supply | 2 x 3 V CR2032 batteries |
| Power consumption | <5.3 mA |
| Dimensions measuring head | 150 x ø18 mm or 150 x ø28 mm |
| Dimensions telescopic stick | Retracted: 0,55 m |
| | Withdrawn: 1,2 m |
| Weight | XXX |
| Software | "ROTRONIC" App (iOS, Android) |
| Delivery | Factory certificate |
| | Short manual instructions |
| | APP (online) |
| | Soft case |
| | Batteries 2 x 3 V (CR2032) |

ROTRONIC AG, CH-8303 Bassersdorf Tel. +41 44 838 11 44, www.rotronic.com ROTRONIC Messgeräte GmbH, D-76275 Ettlingen Tel. +49 7243 383 250, www.rotronic.de ROTRONIC SARL, 56, F - 77183 Croissy Beaubourg Tél. +33 1 60 95 07 10, www.rotronic.fr ROTRONIC Italia srl. I-20157 Milano Tel. +39 2 39 00 71 90, www.rotronic.it ROTRONIC Instruments (UK) Ltd, West Sussex RH10 9EE Phone +44 1293 571000, www.rotronic.co.uk ROTRONIC Instrument Corp, NY 11788, USA Phone +1 631 427-3898, www.rotronic-usa.com ROTRONIC Canada Inc..Canada L8W 3P7 Phone + 1 416-848-7524, www.rotronic.ca ROTRONIC Instruments Pte. Ltd., Singapore 159836 Phone +65 6376 2107, www.rotronic.sg

ROTRONIC Shanghai Rep. Office, Shanghai 200233, China Phone +86 40 08162018. www.rotronic.cn

Technical specifications