

2. To make a phone call :

- 2-1. Well connect the Transfer Unit and the cellular mobile phone (Handy) by connecting wire and correct adaptor as the mobile phone applied accordingly (As the illustration dia 1).**
- 2-2. Hook the Earphone on either your right or left ear properly.**
- 2-3. Press the Clear button "Ⓢ" or "Ⓢ" on the mobile phone. And then, press the Connecting Switch on the Earphone.**
- 2-4. When Earphone sounds the tone, start to dial.**
- 2-5. Talk normally.**
- 2-6. Earphone will shut off automatically in a few seconds after the phone call is hung up.**