

3. Charge. (As the illustration dig. 2) :

- 3-1. Pull out the Charge Plug on Transfer Unit and insert it into the Charge Socket on the Earphone.
- 3-2. Insert the plug of power Adaptor into Charge Socket " Ⓢ " / " Ⓜ " on the Transfer Unit.
- 3-3. Plug on the power Adaptor into power socket.
- 3-4. The red indicators / " 🔴 " on Transfer Unit and Earphone light up when it's charging.
- 3-5. To have perfect performance, the Battery must be charged for 8 hours before Initial using. After the Initial charge of 8 hours, 4 or 5 hours charging will be workable.
- 3-6. Stand by 48 hours (could reach 72 hour at maximum).
- 3-7. Talk time 2 hours.
- 3-8. It's not facilitated with battery power off switch. Therefore, the kit must be recharged in 48 hours and we recommend keep charging it at anytime for convenient use.

When you get the sample of Hand Free Kit, it might have run out of energy. Therefore, **DO CHARGE THE HAND FREE KIT BEFORE USE IT.**
We charged the kit before send it out but user must charge it at least 8 hours for the first time use.