

4. Link Corresponding (Refer to the illustration dig 3) :

4-1. The devices are formatted in Spread Spectrum Technology. Therefore, they are assembled and equipped with corresponding codes. It can be use immediately after well charged.

4-2. Should it can't be linked and does not perform properly, please reset the Link Corresponding as following steps accordingly.

4-2-1. Pull out the Charge Plug on Transfer Unit and insert it into the Charge Socket on the Earphone as the mentioned step 3. Charge . And, plug the connecting wire into the signal socket / " " on Transfer Unit.

4-2-2. Keep pressing the Link Corresponding setting button / " " on back side of the Transfer Unit until the Connecting Indicator green LED / " " of both Transfer Unit and Earphone light up and off in the same time. The setting is done.

4-2-3. Link Corresponding can be set only when the battery is with power.

DIAGRAM - 3

